


大小规格： 70*70mm

英






Wireless & Wired
Kids Headphone
E69


1.Specifications


Working Range: 12m
Battery voltage: 3.7V
Battery capacity: 300 mAh
Battery Charging Voltage: DC4.2-5.5V
Charging Time: about 2.5 H
Working Time: about 28 H (Max. Volume)
Impedance: 32 ohm
Sensitivity: 85±3dB
Speaker diameter: 40mm

2. Button Function


1. “  ” Power on/Power off
2. “  ” Volume up: short press
Move next: long press
3. “  ” Volume down: short press
Move previous: long press

3. Function Description






1. Power on: Long press “  ” for more than 3 seconds,the headphone turn on and enter Bluetooth Mode.The blue and red lights flash alternately.



1

2. Power off: Long press “  ” for more than 3 seconds,the LED indicator light is off and the headphone turn off.

4. Button Guide

1.Hang on: Short press “  ” button when being called.
2.Hang up: Short press “  ”button when calling.
3.Dial back: Double click “  ” button.
4.Play music: Normally short press “  ”button to turn on the smart devices automatically to play music.
5.Continue to play music after the call: When there is an incoming call, the music will be automatically suspended. After the call, you need to short press the “  ” button to continue playing.

5. Bluetooth mode

Repairing: turn off the Bluetooth function of the connected smart devices, at this time,the Bluetooth headset and the last matching device got disconnected,LED light flashed between red and blue,and enter the Bluetooth pairing mode,then turn on the Bluetooth function of the smart devices, search the device named "E69" to get connected without a password, after pairing successfully, voice prompts "dada", the blue LED is on and flash per 2 seconds after working

Subsequent pairing: 3 seconds after powering on, it will automatically search and connect the smart device which paired last time


Warning voice of maximum volume: "Didi"

Power saving mode:headset will automatically power off after pairing continuously for 5 minutes; it will cut off power supply automatically after using Aux-in cable for power saving.


AUX-in Mode
In any modes, insert the AUX-in line, the headset automatically shut down, and switch to AUX-in function without power consumption.

6. LED indicator

Charging	Red light is on when charging, and light is off after getting full charged
Powering off	The indicator is off
Pairing	Blue and red LED flashes alternately



Headphone
Twistable



(Move next: long press) Volume +
ON/OFF
(Move previous: long press) Volume -
⚡ TYPE-C

4

FCC Caution:
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used exposure condition without restriction.

5

页面大小67x90mm, 纸张两边都要印。