mm




使用说明书



耳机x2pcs 充电仓x1pcs

Type-C充电线 x1pcs

说明书x1pcs



对耳机进行充电 耳机闪红灯 耳机电量不足 调整耳机放置的位置 调节音量或更换环境 耳机有回音 冒量太大或者环境太嘈杂 耳机有杂音 外界干扰严重或距离手机太远 更换地点或靠近手机 对方声音小 耳机佩戴不正确或音量太小 调节耳机佩带或音量大小 信号断续 外界干扰严重或距离手机太远 选择无干扰的环境或靠近手机

1.初次使用本产品前,请先充满电再使用。 2.产品不是玩具, 12岁以下儿童须在成年人监护下使用。 3. 请使用通过正规厂家安全认证的5V/1A充电器,避免支持高电压的快充充电器对产 4.请在安全的环境下充电,在给充电仓充电时,电量充满后请尽快将充电线拔出,避 免长时间充电对电池造成损坏。充电仓的充电方式为Type-C接口。 5.本产品内置不可拆卸的可重复充电电池,重复对耳机进行充电和放电将会随时间推 移而导致电池性能下降,这对于所有可以重复充电电池来说均属于正常现象。 6.本产品带有理电池,如长时间未使用,请至少一个月充电一次。 7. 因个体差异原因,如佩戴时感到皮肤不适,请停止佩戴并咨询医生。 8.在蓝牙连接本产品使用时,请将耳机声音调至合适音量大小,以免长期在大音量状

态下对听力造成损伤。

9.如果您在从事需要集中注意力的活动时使用本产品,应注意您自身和他人的安全, 例如驾车或骑自行车时,在道路、施工现场、铁路上或徒步行走时。您应取下耳机或 调整音量以确保可以听到周围的声音、包括警报和警告信号。 10.请遵守所在地区或国家的相关规定,驾车时按照要求使用本产品。 11.本产品含有磁性材料,使用或安放产品时,请远离具有强磁场或强电场的电器,如 微波炉、电冰箱等。

13.有明文规定禁止使用无线设备的场所,请勿使用本产品,否则会干扰其它电子设备

14.靠近医疗及工业设备或登飞机之前,请咨询当地工作人员能否使用。 15.对本产品清洁和维护前,请停止使用本产品,关闭所有应用,并断开与其它设备的 16.请根据本地法令,正确处置废弃电子产品,不可将电子电气设备、部件、电池与其

1.请遵循本说明书的内容进行使用,避免产品因错误操作损坏 2.本产品请远离儿童、火源、热源、冷冻源、水源及化学品。 3.请勿长时间使用大音量收听,以免对听力造成不良影响。 4.请勿将产品及附件浸入任何液体或用水冲洗产品,否则导致火灾或触电危险。 5.请勿将产品放置在太阳晒射或者温度高的地方。高温会缩短电子部件的使用寿 命、损坏电池、使某些塑料部件变形。 6.请勿将本产品放在尘土多、温度和湿度过高或过低的地方保存。 7.请勿将磁条卡(例如银行卡、公交卡等)长期接触本产品,否则可能导致磁条卡 8.请勿在本产品上施加较大的压力,或拆卸、摔打、震动本产品,以防产品损坏 9.请勿在靠近热源处使用本产品,如散热器、热风调节器、炉灶或其他产生热量

10.请勿堵塞本产品的开口处,如充电口、指示灯、麦克风等。

11.请勿在暴雨天气下使用设备,雷暴可能导致设备出现故障,增大电击的风 12.请避免本产品及其配件雨淋或受潮,且激烈运动或出汗较多时使用本产品, 防止液体渗透到产品内部损坏本产品。 13.产品属于内置聚合物理电池,不可更换,请勿丢弃或置以火中,以免爆炸、 起火等危险发生。

14.如因消费者违反上述警示而不恰当使用所造成的人身及财产损害将自行承担 一切后果本公司将不产生任何法律责任。

别是充电触点部位)上的汗水。避免使用湿纸巾直接接触充电触点。

--若出现单侧无声或音量不均,可能是左右耳机配对异常。

--解决方法:将耳机放回充电盒,在设备蓝牙设置中移除该耳机配对信息。关闭充电盒盖数秒后重新 打开取出耳机,待耳机指示灯显示配对状态(如随机闪烁),在设备蓝牙列表中选择耳机重新连接。

--运动后汗水可能腐蚀充电触点。请务必在耳机放回充电盒前,用柔软干布或纸巾轻轻擦干耳机(特

3.充电故障排除(端口清洁)

--充电失败常因充电触点(耳机或充电盒)沾染灰尘、汗渍或油脂导致接触不良。 ①准备干净棉签和高纯度无水酒精(如浓度≥70%的异丙醇或乙醇)。

禁用自来水、湿纸巾或含油清洁剂。 ②蘸取少量酒精,轻甩棉签至微湿不滴液。 ③轻柔地擦拭充电触点金属表面。动作务必小心,避免损坏。 ④清洁后,静置设备直至端口完全干燥(建议5-10分钟)。

--配对或连接过程中,单只耳机指示灯随机点亮属正常现象,非产品故障。 5.开放式设计特性

--本产品采用开放式声学设计。在较高音量下,周围人可能听到部分声音(漏音), 属设计特性,请理解。

6. 充电接触优化

--长期使用后,耳机与充电盒触点可能贴合不紧影响充电。 --解决方法: 放入耳机时,可轻微旋转调整耳机充电端位置,确保触点良好接触。

-避免用力拉扯耳机臂,以防夹持力减弱。

7.耳机夹力维护

--正确佩戴与调节:耳机臂内置记忆金属丝,佩戴时可根据耳廓厚度,轻微弯曲臂身以调节松紧度, 再轻柔贴合佩戴。



INSTRUCTION MANUAL



Headphones x2pcs Charging case x1pcs Type-C charging cable x1pcs Instruction manual x1pcs

the connection is complete. At this time of	an carry on the mobile phone call listen to music!
1.Cell phone connection	• Take out both ears after the headset is opened, turn on Bluetooth on the mobile phone, search for the device, the pairing name appears: click Connect. (Take out the headset, the white and orange lights of both ears flash, the white and orange lights of one ear flash after the interconnection of both ears, and the rear light of the connected phone is off, and the prompt tone is "connect")
2.Touch key function	 Music playing:Long press the left ear\right ear to wake up Siri
	 Music playing:Double click to pause or play left/right ear as well
	Music playback: Triple tap the left earbud to play the previous track, and triple tap the right earbud to play the next track.

3.手机可显示耳机电量

1.In-ear test:None 2.One ear can be used normally The phone can display the power of headphone

Please keep the distance between the Bluetooth headset and your mobile phone (or other connected device) within 1 meter, the closer the better. Enable the Bluetooth function of the user's mobile phone(or other Bluetooth devices)and search or scan. The mobile phone will search for nearby Bluetooth devices. Select the headset name from the list. After successful pairing, the headset indicator light will turn off, indicating power off The headphones are low on battery Charge the headphones The headphones are worn incorrectly or Adjust the headset wear or volume The signal is Serious external interference or too Choose a distraction-free environment or be close to your phone

 Before using this product for the first time, please fully charge it before using it. The product is not a toy, and children under the age of 12 must be used under the supervision of an adult. 3. Please use a 5V/1A charger that has passed the safety certification of a regular manufacturer to avoid damage to the product caused by a fast charging charger that supports high voltage. 3.Bluetooth headset phone function 1.Click once to answer/hang up the phone 4. Please charge in a safe environment, when charging the charging case, please pull out the charging cable as soon as possible after the power is fully charged to avoid 2.Hold down for3 seconds to reject the phone damage to the battery caused by long-term charging. The charging method of the charging case is the Type-C interface. 5. This product has a built-in non-removable rechargeable battery, and repeated charging and discharging of the earbuds will lead to a decrease in battery

> 7. If you feel skin discomfort when wearing it due to individual differences, please stop wearing it and consult a doctor. 8. When using this product with Bluetooth connection, please adjust the sound of the earphones to an appropriate volume to avoid hearing damage caused by long-term Please follow the relevant regulations of your region or country and use this product as required when driving.

performance over time, which is normal for all rechargeable batteries.

time, please charge it at least once a month.

This product contains a built-in rechargeable lithium battery. If not used for a long

10. If you use this product while engaging in activities that require concentration, driving or cycling, on roads, construction sites, railways, or walking. You should remove your headphones or adjust the volume to ensure that you can hear the sounds around you, including alarms and warning signals. 11. This product contains magnetic materials, please keep away from electrical appliances with strong magnetic or electric fields, such as microwave ovens, refrigerators, etc., when using or placing the product. 12. It is recommended to use this product in an environment with a temperature of

-0°C~45°C. When the ambient temperature is below +5°C, battery performance is 13. Do not use this product in places where it is expressly prohibited to use wireless equipment, otherwise it will interfere with other electronic equipment or cause other dangers. Before approaching medical or industrial equipment or boarding a plane,

please ask the local staff if they can use it. 15. Before cleaning and maintaining this product, stop using this product, turn off all applications, and disconnect all connections or cables to other equipment. 16. Please dispose of waste electronic products properly in accordance with local laws and regulations, and do not dispose of electrical and electronic equipment, parts, batteries and other household waste.

1. Please follow the content of this manual to avoid damage to the product due to incorrect operation. 2. Keep this product away from children, fire, heat, refrigeration, water and 3. Do not listen at a loud volume for a long time to avoid adverse effects on 4. Do not immerse the product and accessories in any liquid or rinse the product

5. Do not place the product in the sun or in a place with high temperature. High temperatures can shorten the life of electronic components, damage batteries, and deform certain plastic parts. Do not s tore this product in a place with a lot of dust, too high or too low temperature and humidity. 7. Do not contact the magnetic stripe card (such as bank card, bus card, etc.) with this product for a long time, otherwise it may cause the magnetic stripe card to be

8. Do not apply excessive pressure, disassemble, drop, or shake the product to

with water, otherwise it will cause fire or electric shock hazard.

damaged by the magnetic field.

9. Do not use this product near heat sources, such as radiators, hot air regulators, stoves, or other instruments that generate heat 10. Do not block the openings of this product, such as charging ports, indicator 11. Do not use the device in rainstormy weather, thunderstorms may cause the

device to malfunction and increase the risk of electric shock.

12. Please avoid using this product when this product and its accessories are exposed to rain or moisture, and when you exercise vigorously or sweat a lot, to prevent liquid from penetrating into the product and damaging this product. 13. The product belongs to the built-in polymer battery, which cannot be replaced, please do not discard or put it in the fire to avoid explosion, fire and other dangers. 14. If the consumer violates the above warning and inappropriate use, the personal and property damage will be borne by the company, and the company will not incur any legal responsibility.

between the radiator and your body.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. There is no guarantee that interference will not occur in a particular installation. If interference occurs to radio or television reception, the user is encouraged to try

one or more of the following measures: *Reorient or relocate the receiving antenna. *Increase the distance between the equipment and receiver. *Connect the equipment to an outlet on a different circuit from the receiver. *Consult the dealer or an experienced radio/TV technician for help. Caution: Any changes or modifications not expressly approved by the manufactur-

er could void your authority to operate this equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following conditions: 1.This device may not cause harmful interference. 2.This device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits for an uncontrolled

environment. It should be installed and operated with a minimum distance of 0 cm

1.Left/Right Earbud Pairing & Connection

-Solution: Place both earbuds back into the charging case. Remove the headphone pairing information from your device's Bluetooth settings. Close the case lid for a few seconds, then reopen and remove the earbuds. Wait until the earbud indicators show pairing status (e.g., random flashing), then select the headphones in your device's Bluetooth list to reconnect. 2.Cleaning & Maintenance

--Sweat after exercise may corrode charging contacts. Always gently wipe sweat from the earbuds (especially the charging contacts) with a soft, dry cloth or tissue before placing them back in the charging case. Avoid using wet wipes directly on the charging contacts.

alcohol). Never use tap water, wet wipes, or oil-based cleaners. ②Dip the swab lightly, then gently shake off excess liquid until damp but not dripping.

4.Indicator Light Status -Random lighting of a single earbud's indicator during pairing or Bluetooth connection is normal operation, not a product defect.

--Due to the open-ear acoustic design, sound leakage may be noticeable at higher volumes. This is an inherent characteristic of the design. We appreciate your understanding. 6.Optimizing Charging Contact --After prolonged use, the charging contacts on the earbuds and case may not align perfectly.

--Solution: When placing earbuds in the case, apply a slight rotation adjustment to the charging end to ensure good contact. 7. Maintaining Clamping Force

--Avoid pulling the earbud arms forcefully to prevent weakening the clamping force. --Correct Wearing & Adjustment: The earbud arms contain an inner metal core with shape memory. To wear, gently bend the arms to adjust the tightness according to your ear contour, then clip them comfortably onto your ears.

--If sound is absent from one earbud or volume is unbalanced, the earbuds may be improperly

3. Charging Troubleshooting (Contact Cleaning) --Charging failure is often caused by dust, sweat residue, or oils on the charging contacts (earbuds or case) leading to poor connection. --Professional Cleaning Steps: ①Use a clean cotton swab and high-purity anhydrous alcohol (e.g., ≥70% isopropyl or ethyl

③Clean the metal contact surfaces extremely gently. Exercise great care to avoid damage. After cleaning, let the device sit until the contacts are completely dry (recommended: 5-10 minutes). ⑤Attempt charging again once fully dry.

5.Open-Ear Design Characteristic