


MBTBUDS

MACALLY

WIRELESS BLUETOOTH EARBUDS

User guide



USER GUIDE

Thank you for purchasing the Macally MBTBUDS. The MBTBUDS is a Bluetooth 4.1 wireless headset, made of the finest materials, that allows you to enjoy your favourite music and make hands-free calls at the best audio quality and the most stable wireless connection up to a distance of 30ft/10 m.

This headset supports aptX audio technology for high-quality wireless audio and CVC 6.0 noise cancelling for a crisp and clean microphone sound.

The built-in 120 mAh rechargeable battery lasts up to 6 hours of music play time (varies according to audio format, volume level and other conditions), 8 hours of talk time and 150 hours of standby time. It only needs 1-2 hours of charging time.

A very cool feature of this headset is that the earbuds are magnetic. It allows you to magnetically turn on/off your headset. Simply detach the earbuds to turn the headset on and attach them to turn it off to save battery life. Besides, when you magnetically attach them you can keep the headset conveniently around your neck or store it easily in a bag or pocket

The headset has an extremely lightweight (approx. 21 g), behind-the-neck and in-ear design (3 sets of eardbud sizes included) for maximum comfort. Resistant to water splashes, sweat and the occasional unexpected downpouring of rain (IPX4 waterproof), the Macally MBTBUDS is ideal to listen to music during any activity.

About this guide

Before you start using the Macally MBTBUDS, be sure to read this guide in its entirety.

Safety instructions

Please read the following carefully before using this Macally product. Incorrect use of this product may result in reduced performance, permanent damage and void warranty:

1. Do not place this product near a heat source.
2. Operating temperature of 5°C to 40°C. Storage temperature of 0°C to 60°C.

3. Do not place this product near moisture nor liquids.
4. Operate and store at humidity of 5% to 90% (non-condensing)
5. Do not place heavy objects on this product.
6. Do not drop this product.
7. Do not dispose this product in the garbage. Take it to your local recycling centre.


Package contents

- Wireless Bluetooth earbuds
- USB charging cable (7.9 in / 20.06 cm)
- 3 pairs of earbuds and 3 pairs of in-ear supports (S, M and L)
- Storage pouch
- User guide

Important notes


- The MBTBUDS may not be fully charged when you get it. Please make sure you charge them. If the sync LED does not flash during pairing.
- Once paired to a Bluetooth enabled device, the ear buds will automatically turn off when magnetically placed together and automatically turn on/connect when separated.

Hardware basics




Charging the MBTBUDS

To charge your MBTBUDS simply connect the USB end of the charging cable to a USB charging adapter (adapter not included) and the Micro USB end into the MBTBUDS charging port. While charging, the battery status LED will stay solid red and then turn to white when fully charged.



MBTBUDS BUTTONS AND ACTIONS



Music Playback

- Volume Up/Next Song button
Press and release to increase the volume
Press and hold to skip to the next song
- Volume Down/Previous Song button
Press and release to decrease the volume
Press and hold to skip back to the previous song
- Play/Pause button
Press and release to play/pause your music as needed


Phone Calls

NOTE: During an incoming call your music will pause automatically and resume playback when the call has ended.

- Play/Pause button
Press once to answer the incoming call and a second time when you wish to end the call.
To ignore the incoming call simply let it ring out.
- Volume Up/Next Song button
Press and release to increase the volume
- Volume Down/Previous Song button
Press and release to decrease the volume

Swapping out the ear buds and in-ear supports

The MBTBUDS includes 3 different sized Ear buds and in-ear supports (S, M, L). To swap them out, simply pull off the existing set and attach a different sized one as needed. When re-attaching the in-ear support, make sure it sits up on the opposite side of the cable as shown in the images below.




PAIRING THE MBTBUDS





Pairing the MBTBUDS with iPhone, iPad or iPod

NOTE: The MBTBUDS may not be fully charged when you get it. Please make sure you charge them. If the sync LED does not flash during pairing.

1. Separate the ear buds and make sure the Bluetooth sync LED is flashing red/white. If it's not, press and hold the sync button on the headset for three to four seconds until it flashes.



2. Open the Bluetooth settings on your iPhone and make sure Bluetooth is set to "ON".




3. From the Bluetooth screen, wait for MACALLY MBTBUDS to show up then tap on "MACALLY MBTBUDS" and wait for the MBTBUDS to show "Connected".

NOTE: It may take up to a minute for the ear buds to show up on the screen. Once paired the ear buds will automatically turn off when magnetically placed together and automatically turn on and connect to your iPhone.


Pairing the MBTBUDS with Android smartphone or tablet

NOTE: The MBTBUDS may not be fully charged when you get it. Please make sure you charge them if the sync LED does not flash during pairing.

1. Separate the ear buds and make sure the Bluetooth sync LED is flashing red/white. If it's not, press and hold the sync button on the headset for three to four seconds until it flashes.





2. Open the Bluetooth settings on your Android and make sure Bluetooth is set to "ON".



3. From the Bluetooth screen, wait for MACALLY MBTBUDS to show up then tap on "MACALLY MBTBUDS" and wait for the MBTBUDS to show "Connected".


NOTE: It may take up to a minute for the ear buds to show up on the screen. Once paired the ear buds will automatically turn off when magnetically placed together and automatically turn on and connect to your smartphone or tablet.




Pairing the MBTBUDS with Mac

NOTE: The MBTBUDS may not be fully charged when you get it. Please make sure you charge them if the sync LED does not flash during pairing.

1. Separate the ear buds and make sure the Bluetooth sync LED is flashing red/white. If it's not, press and hold the sync button on the headset for three to four seconds until it flashes.





2. Click on the Bluetooth icon located on your Mac's menu bar located in upper right corner of your screen. Make sure Bluetooth is "ON" then select "Open Bluetooth Preferences" from the drop down menu.



3. From the Bluetooth screen, wait for MACALLY MBTBUDS to show up then click on "connect" and wait for the MBTBUDS to show "Connected".

NOTE: It may take up to a minute for the ear buds to show up on the screen. Once paired the ear buds will automatically turn off when magnetically placed together and automatically turn on and connect to your Mac.







Pairing the MBTBUDS with Windows

NOTE: The MBTBUDS may not be fully charged when you get it. Please make sure you charge them. If the sync LED does not flash during pairing.

1. Separate the ear buds and make sure the Bluetooth sync LED is flashing red/white. If it's not, press and hold the sync button on the headset for three to four seconds until it flashes.





2. Open your windows Bluetooth settings and click on "Add a device".



3. From the Add a device screen, wait for MACALLY MBTBUDS to show up then double click on "MACALLY MBTBUDS" and wait for windows to finish installing the driver.

NOTE: It may take up to a minute for the ear buds to show up on the screen. Once paired the ear buds will automatically turn off when magnetically placed together and automatically turn on and connect to your Windows PC.



Warning

1. *Listening at high volume levels can lead to hearing problems.*
2. *For traffic safety, do not use earphones while driving a motor vehicle or bicycle.*
3. *Keep out of reach of children as the parts included with this product can be a choking hazard.*

Technical support

For tech support please call +1 909 230 6888 or e-mail us at techsupport@macally.com. Tech support hours are from 8:30 AM to 5:30 PM Monday through Friday (Pacific Standard Time).

Warranty

Macally Peripherals warrants that this product will be free from defects in title, materials and manufacturing workmanship for one year in North America from the date of the purchase. If the product is found to be defective then, as your sole remedy and as the manufacturer's only obligation, Macally will repair or replace the product. This warranty is exclusive and is limited to the Macally MBTBUDS. This warranty shall not apply to products that have been subjected to abuse, misuse, abnormal electrical or environmental conditions, or any condition other than what can be considered normal use. The liability of Macally Peripherals arising from this warranty and sale shall be limited to a refund of the purchase price. In no event shall Macally Peripherals be liable for costs of procurement of substitute products or services, or for any lost profits, or for any consequential, incidental, direct or indirect damages, however caused and on any theory of liability, arising from this warranty and sale. These limitations shall apply notwithstanding any failure of essential purpose of any limited remedy.

MACALLY

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.