

	1	2	3	4	5	6	7	8	
						版本 00	版次 A0	更改记录	执行人 闫文双
A									
B									
C									
D									
E									
F									

版权所有:侵权必究

INSIDE BOX FRONT AND BACK QUICK START GUIDE INSERT

FRONT


BACK

205

172

ICON 1

QUICK START GUIDE

PLAYBOY | AUDIO

DESIGNED & ENGINEERED IN LOS ANGELES, CALIFORNIA

FOR COMPLETE USER MANUAL & ALL OTHER SUPPORT INQUIRIES PLEASE VISIT US AT:  
PLAYBOYAUDIO.COM


ICON 1 - 3 STEP WIRELESS BLUETOOTH PAIR & CONNECT

1) Turn your Bluetooth ON from your smartphone or Bluetooth enabled device settings.

2) From your PLAYBOY ICON 1 wireless headphones, press and hold the middle multi-function button (**see below**) for 3 to 5 seconds or until you see the LED light flashing blue & red (the blue / red LED blinking light indicates your ICON 1 headphones is in pairing mode and ready to connect to your Bluetooth enabled device).

3) Once in Pairing mode navigate to settings from your Bluetooth enabled device  
--- Tap Bluetooth & switch Bluetooth to the ON position  
--- Tap**PLAYBOY ICON 1** to connect  
(**PLAYBOY ICON 1** will be located under **OTHER DEVICES** in your Bluetooth settings)

ICON 1 - WIRELESS CONTROL BUTTONS




VOLUME (+) |  
BACK TO PREVIOUS TRACK

MULTI-FUNCTION BUTTON  
\* BLUETOOTH PAIRING  
\* POWER (ON/OFF)  
\* PAUSE / PLAY TRACK

VOLUME (-) |  
SKIP TO NEXT SONG

FCC Statement  
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates noise and can interfere with nearby wiring and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
- Reorient or relocate the receiving antenna.  
- Increase the separation between the equipment and receiver.  
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
- Consult the dealer or an experienced radio/TV technician for help.  
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) The device may not cause harmful interference, and (2) the device must accept any interference received, including interference that may cause undesired operation.  
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
RF warning statement:  
This device has been evaluated to meet general RF exposure requirement. The device can be used in public exposure condition without restriction.

材质性能: 157克双铜		■外表面视图	□内表面视图	设计:	客户	B280 SMBT-4068	料号	435-35001-0362		
印 刷: 4C 黑底 正反面印刷 对折		■ 啤面	□ 啤底	排版:	类型		编码			
接合方式:		裁切线 压痕线 开槽线 对位线	标示 半穿刀 成品线 牙刀	审核:	单位	比例	投影标识			
未注公差: +/-1				批准:	MM	1:1	第(1)页 共(1)页			
品 名: 说明书				<div><div>SIYOIO</div>东莞市实优特有限公司 包装部</div>						
环保 : ■符合RoHS要求 □符合HF要求										
说明: .图示尺寸为加工尺寸;										
备 注										

1	2	3	4	5	6	7	8
---	---	---	---	---	---	---	---

版权所有:侵权必究

F

A

B

C

D

E

F

INSIDE BOX FRONT AND BACK QUICK START GUIDE INSERT

FRONT

BACK

