

Wireless Pico Projector

— Quick Operation Guide —



ShenZhen QiSheng Technology Co.,Ltd

Phone: 86-755-88914934

Url: www.gaeasmart.com

Address: 12B, Blogck A, Hongsong Building, Tairan 6th Road, chegongmiao,
Futian District, Shenzhen


CATALOG

Projector Brief Introduction	3-5
1.1 Package	3
1.2 Appearance design	4
1.3 Remote control introduction	5
Projector Using Guide	6-18
2.1 Power on / Power off	6
2.2 Adjust focus / lightness	6-7
2.3 Bluetooth controller pairing	8
2.4 Connect Wi-Fi network	9
2.5 Operation of the main interface	10
2.6 Projection screen	11-14
3.1 Other function	15-16
3.2How to update firmware (local update)	17
Product Reference	18

Projector Brief Introduction



Projector



Adapter




Manual+Warranty Card



Remote Control


Projector Brief Introduction

1.2 Appearance design



Projector Brief Introduction

1.3 Remote control introduction



pairing mode

Holding "OK" and "Volume" button five seconds to start remote control pairing mode

Indicator light status

Slow flash: unpaired mode

Flash: in infra mode press each button will flash once

Projector Using Guide


2.1 Power on / Power off

1. Power on

Holding power button 5 seconds (P1).

2. Power off

Holding power button 3 seconds (P1).




2.2 Adjust focus / lightness

1. Adjust focus

Slide the gear to adjust the projection screen definition (P2).

2. Adjust lightness


In the mainpage chose "setting" - "projector setting" - "LED brightness".



Projector Using Guide

2. Main interface focusing

After entering the main interface, first click the middle circle of the top focus bar / or press the remote control to enter the focus mode interface . Then press the top or bottom of the tracing bar to adjust the focus until the picture is clear and release your hand. Press the back button to exit the focus.




3. Adjust the brightness

In the main interface, select "Settings" - "Projection Settings" - "LED Brightness"

Projector Using Guide

2.3 controller pairing



Press "back button" to skip this step

Pairing method:

After enter remote controller pairing page, hold "OK" button and "volume-" five seconds then loose and wait it till connect success.

Or: Enter into setting → according to the tips to connect the ir controller

Projector Using Guide

2.4 Connect Wi-Fi network



Press the Back key to skip this step

Or: Enter into setting → WiFi Setting → WiFi Setting, Searching and connecting.

Projector Using Guide

2.5 Operation of the main interface

