

# COUL


## V1 Ergonomic Keyboard

### Introduction

Congratulations on purchasing the COUL Ergonomic Keyboard. This Product Guide shows you how to install, pair, use and charge the keyboard. It also provides Important Safety Guidelines and Regulatory Information.

### Package Contents


- COUL Ergonomic Keyboard
- USB Cable
- Product Guide



### Setting Up and Pairing your COUL Ergonomic Keyboard


1. Slide the Power Switch (A) to the right for the ON position and check the Power LED indicator (B) status.
2. Once the power is ON, hold down the COUL Key together with one of the Bluetooth keys (F7 or F8 or F9) for approximately 3 seconds to pair with your PC, Mac or other device.

### Device Layout




- A. Power switch
- B. Power LED indicator
- C. Bluetooth LED indicators
- D. Touchpad
- E. VIM key (see [www.coul.com/support/vim\\_key](http://www.coul.com/support/vim_key))
- F. COUL key (see [www.coul.com/support/coul\\_key](http://www.coul.com/support/coul_key))
- G. FN Function key
- H. Delete key & Check Battery Remaining
- I. F12 & Windows OS key
- J. F11 & Mac OS key
- K. F10 & Linux OS key

### Check Battery Remaining



1. Press and hold the COUL key (F) whilst pressing the Delete key (H) to check how much Battery life is remaining.
2. Check the number of times the Power LED indicator (B) flashes to indicate the Battery charge that is remaining.

### Recharging the Battery



1. Use the USB Cable provided to charge your COUL Ergonomic Keyboard.
2. Check the LED indicator (B) for charging status, which will be red during charging.

## Safety Guidelines

It is important to achieve maximum safety when using the COUL Ergonomic Keyboard, so we suggest that you use the following guidelines:

1. Taking the device apart will void the warranty, so do not attempt to do this by yourself.
2. Do not attempt to operate the device under abnormal current load conditions.
3. Do not attempt to disassemble the COUL Ergonomic Keyboard. There are no user serviceable parts inside.
4. Do not expose the COUL Ergonomic Keyboard to direct sunlight.
5. Never expose this device to too high or too low temperature.
6. The suitable temperature for the product is 0°C to 35°C.
7. Keep the device and accessories away from a damp or wet environment.
8. Never expose this device to fire, dust, oil, moisture or smoke.

## Comfort & Ergonomics

When using the COUL Ergonomic Keyboard, it is important to find a comfortable posture and take frequent breaks in order to ensure optimum comfort and avoid injury. For information about ergonomics and safety, visit [www.coul.com/ergonomics](http://www.coul.com/ergonomics).

## Maintenance, Cleaning and Usage

The COUL Ergonomic Keyboard requires little maintenance, but we suggest that once a month, you disconnect the USB cable, power off the device and clean it using a soft cloth to minimize the build up of dirt. Do not use soap, detergents or chemicals to clean the device.

## FCC Notice

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC ID: 2ATWXV101

## Statement of Compliance with EU Directive

Hereby, COUL International Limited declares that this device is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU.

For the declaration of conformity, please visit the Web site [www.coul.com/certification](http://www.coul.com/certification).



## Waste Electrical and Electronic Equipment Disposal Information

The symbol shown below and on the product or its batteries or its packaging indicates that the product and/or its battery should not be disposed of with your household waste. It is your responsibility, when you decide that the product has reached the end of its working life, that you hand the product over to an appropriate environmentally safe collection point for the recycling of electrical and electronic equipment and batteries, in accordance with local environmental laws and regulations.



## Warranty Information

In order to activate your warranty, please register at [www.coul.com/warranty](http://www.coul.com/warranty).

For limited warranty information, please visit [www.coul.com/warranty](http://www.coul.com/warranty).

## More Information

For support and troubleshooting information, please visit [www.coul.com/support](http://www.coul.com/support).

## Contact Information

COUL International Limited, 27th Floor, World Wide House, 19 Des Voeux Road Central, Central, Hong Kong



[www.coul.com/support](http://www.coul.com/support)