


User Guide

1. EarTip
2. Multi-function Button(MFB)
3. Microphone
4. Charging Pin
5. Charging Port (Type-C)

2. Multi-function Button(MFB)
3. Microphone
4. Charging Pin
5. Charging Port (Type-C)



Fully charge to
first use.

Fully charge the earbuds along with the charging case before the first use.

1. Open the charging case (one hand holds one hand raised) and take the earbuds out or after one of them out, they'll all turn on and its pairing mode automatically.
2. Enable bluetooth on your device, search and select 28 EarPods connected earbuds, any other (T1) will lose pairing.
3. The earbuds have all of automaticity.
4. You can push touch to find charging case or (2) they'll already out of the charging case in pairing mode but without connected to device is 1 minute.
5. To manually power on/off, long press the M2 for 4 seconds when standby or pause mode, but it will not effect when in a call.



Eartips in different sizes choose the right size fitting for you. M size installed as eartips. Insert the earbuds into the inner canal of your ears, turn and lock to get a comfortable fit.

You can upgrade VPS to get certain features as follows:

Volume+ / Volume-
Double press HOME to get on HOME to get volume down, 1 effect under ear buds it side on X. You can press volume button

Volume+ / Volume-
Double press VOLUME to get volume add, double press VOLUME to get volume-downs, this function will not effect under car radio 2 side or 1 side use alone.
X-Box can press volume buttons on the connected device.

Establish Nest

Establish Host

Manually power off status, long press NFB for 5 seconds (press and), side at the same time when you can hearing pairing, choose the one you want to be the host, double press the NFB the host.

Answer / End a Call
When there's an incoming call, once to answer, you can end it.

Reject
When there's an incoming call,

Reject
When Fami's an incoming call, short press hot MFE once to answer, you can end it short press MFE again.

Mute
On a call, long press 1
and long press 2 twice.

On a call, long press Mute for 2 seconds to mute, and long press 2 seconds to resume microphone.

- Avoid dropping.
- Use original or certified replacement.
- Never disassemble or repair any reason to avoid any.
- Keep the outdoors dry and in winter.
- Keep out of reach of children. Included may be a check with the 1st indicator.

- Avoid dropping.
- Use original or certified cables.
- Never disconnect or modify your methods for any reason. Inevitably, you may experience a change. Keep the monitors dry and do not submerge in water.
- Keep out of reach of children. Small parts included may be a choking hazard, and avoid using the LCD indicator close to the eyes of children or animals.
- Do not use this headpiece during a thunderstorm to avoid lightning strikes and increased risk of the electric shock.
- Clean with dry, soft lint-free cloth. Do not use harsh chemicals or strong detergents to clean.
- The product shall not be exposed to excessive heat such as sunshine, fire or anything like that.

- To avoid heating damage, do not extend periods at high volume
- Do not turn the volume so high as to be able to hear your surroundings
- Do not use earbuds while driving
- You should use caution or keep the volume low if you are potentially distracted

- Do not turn the volume so high that you're unable to hear your surroundings.
- Do not use earbuds while driving.
- You should use caution or forego use altogether if you are potentially hazardous if at all times.

Parameters
Bluetooth's name
Bluetooth's version
Pairing's response
Bluetooth's Range

Bluetooth version	4.0
Bluetooth version	4.0.2
Emergency response	20142-20042
Bluetooth Range	12m/35ft
Battery	3.6V/400mAh
Charging Case	3.6V/400mAh
Input	3.6V/400mAh
Play time	3.6V/400mAh
Charging time	3.6V/400mAh
Bluetooth profile	3.6V/400mAh
Accessories	3.6V/400mAh

6-month Limited
Lifetime Technical

6-month Limited Warranty
Lifetime Technical Support

- Ⓐ The earbuds is not expanding from the charging case, it automatically.
- Ⓑ Please check the power of charging is no power the earbuds automatically when there out it should manually turn it on for 2 second.

- [illegible]

- A. Try to avoid prolonged use of your hearing to make sure you're continuously more than one interval wearing.
- B. Do not wear the earphones while driving.
- C. Avoid placing the earphones directly and hard on the ear.

Do not wear the earphones for more than one hour at a time to protect your hearing and be better for intervals wearing.

- dry and humid environments which will damage the wires a lot and affect normal use.

This product is covered by a limited warranty. Which of the following is NOT covered by the warranty?

- Carphone is broken
- User does not know how to use it
- Without the earpiece

This product is covered under warranty for a period of six months from the date of sale limited to normal use and maintenance of the machine parts, materials and functions. Problems and failures verified upon further identification, will be provided free repair and replacement parts. Limited to the following:

- Notes:** The warranty does not include product transport costs and does not provide on-

uso manutenção service.

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.