


A collection of white and pink wireless earbuds and their charging case. The earbuds have a large, rounded white body with a pink accent on the side. One earbud is shown with its long, white, textured charging case attached. Another earbud is shown without the case, revealing the pink interior of the ear tip. The charging case is white and oval-shaped, with a small gold-colored contact point visible inside.

User Manual




- power on/power off

power on	Open the charging box or press 2 seconds	blue lights flashes 3 times	Voice prompt: "power on"
power off	Put headset back into charging box and close the case or press 3 seconds	red lights flashes 3 times	Voice prompt: "power off"

Connecting your device

Before pairing, make sure your headset has enough power and your connected device within the valid range.




- **Pairing**
Open the charging box or press 2 seconds to enter pairing mode, blue light flashes slowly and the voice prompts: "pairing mode."
- **Successful connection**
If paired successfully, the LED turns light blue and the voice prompts: "Your phone is connected."
- **Pairing timing**
If fail to connect to device, the red and blue indicators flash alternately and automatically turn off after 5 minutes. The voice prompts: "Power off."
- **Disconnected**
If failed to establish Bluetooth connection on phone, voice prompt: "Your phone is disconnected" After 5 minutes turn off voice prompt: "Power off."
If failed to turn off of range, voice prompt: "Your phone is disconnected", and headset will turn off after 5 minutes.
- **Clear the pairing list.**
Turn on headset and press 15 seconds to clear the pairing list. Voice prompt: "Do."
- **Standby**
After pairing & connection headset will automatically enter standby state.
- **Search Headset**
On your wireless Bluetooth device (iPhone, iPad, iPod and Android smartphone or tablet).
- **Open the Settings page on your Bluetooth device.**
Make sure the "Bluetooth" option on your Bluetooth device is turned on and click "Search".
- **Wait for the Bluetooth name of the BST8700 to be displayed in the Bluetooth list of "Available Devices" on the SETTINGS Bluetooth name to start pairing and connecting with your Bluetooth device.**
- **The LED turns "off", indicating that your headset has been paired successfully, and you can start playing and listening to your favorite music.**

Note:


1. You have 5 minutes to connect the headset to your device, otherwise the headset will exit pairing mode and turn off. Pls tap control button 3 seconds to turn it on and re-enter the pairing mode.
2. Only the left earphone connect your device. The right earphone will connect the left earphone. Single Earbud Mode (Only Functional via Left Earbud)
3. If right / left earphones can't paired them automatically, please follow the re-set instruction.

Wearing

Try changing the ear caps for the best fit and sound effect. Better sealing for better sound effect.




Put the earphones in the ear canal. Gently turn to comfortable fit.




Tip: There are multiple ear caps for you. For the best sound effect, choose the one completely seals your ear canal. your left and right ears may need different size ear caps.

Play music

When Play music you can use any of the headphones to control it.



Call



Charge the headset


Put the headset into the charging case. Close the charging box completely. During the charging process, the box blue indicator light is always on, the headset starts to charge. The box blue indicator light is off after the battery is fully charged.

Headphone low battery

When battery is low, there will be a voice prompt: "Charge me", and the red light will flash.

Charge for charging box

Box indicator during headset in recharging		Box indicator during box in recharging	
charging	Box blue light on	charging	blue light flashes
complete	Box blue light off	complete	blue light on



Micro USB charging cable

Plug the charging cable into charge connector to charge the charging box and headphones. The indicator light of the charging box will light up while charging.

Specification

- Bluetooth Version: V5.0
- Weight : (headset:43g)
- Standby : 80 Hours
- Frequency Response : 20Hz – 20kHz
- Driver unit : Ø6mm
- Support protocols: A2DP, AVRCP, HSP, HFP
- Charging time : 1 Hour
- Music play : 3-4 Hours Call 3-4 Hours
- Distance : 10m
- Operating/storage/charging temperature : -10°C-50°C

Safety instructions

- For safety reasons, do not use headphones when riding a bicycle, motorcycle or while driving. It is dangerous to turn the volume too loudly to hear the outside sound. Please watch the surrounding vehicles drive carefully.
- Do not disassemble, jump, or squeeze the product.
- Do not place this product in a hot or humid environment.
- Do not put this product into fire, water or corrosive liquids.
- Do not place this product near flammable materials while charging.
- Do not remove and replace the internal battery by yourself, there is a danger of explosion.
- Avoid excessive volume or long-term high volume headphones to avoid hearing damage.
- Keep the headphones out of the reach of children to avoid the danger of improper use by children.

Frequently asked questions

- If the BSBT005 Wireless Bluetooth Headset does not turn on?
 - Check that your BSBT005 Wireless Bluetooth Headset has enough battery power.
 - If your computer's own battery is exhausted, your computer's USB port will not be able to charge the BSBT005's battery. Try charging the BSBT005's battery with a 5V (1A or 2A) USB charger. The charging time is about 2 ~3 hours.
- What if there is no sound playing music headphones?
- Check if the playing device and the Bluetooth headset are connected effectively. If the audio device is not connected properly, please reconnect and adjust the volume of the mobile phone and Bluetooth headset to the appropriate volume level.
 - Please confirm whether the Bluetooth of the mobile phone is in "Device Visible Mode". If the pairing is not confirmed a long time, the Bluetooth pairing will be automatically turned "Invisible". Please turn Bluetooth back on to "Device Visible Mode". If the phone program error occurs, please restart the phone. If the Bluetooth headset program is wrong, please restart the Bluetooth headset.