

Nice to meet you!

tonies® Instructions Parent's Guide

Welcome to the Tonie-Universe

I'm a Creative-Tonie and go with your new Toniebox. I'm really excited about all of our listening adventures! But first, let me tell you how everything works.

Setting up your Toniebox is easy! All you need is:



*Tip: You need to keep the Toniebox within close range of your Wi-Fi signal during setup. To achieve this connection, the adapter you use will greatly help.



Tip 3: Check the support code word

In case of more advanced errors, your Toniebox will ask you for a support code word. You can find out what it means and the instructions telling you what to do here: [tonies.com/support](https://www.tonies.com/support)

Tip 2: Reset the Toniebox to its factory settings

The last resort: setting everything to zero. To do this, turn the Toniebox with the connected charging station upside down and press both ears for about 10 seconds until you hear a sound. Making Bluetooth connections, contents and settings will be deleted.

Tip 1: The classic restart

If the Toniebox is having a hard time and nothing seems to work or you do not know what to do next, first try restarting the Toniebox. To do this, remove the Toniebox from the charging station, wait for 10 seconds and then place it back in the station (own) for approximately 10 seconds until you hear a sound.

Rough start?

Check these tips for some help getting started or visit this URL: [tonies.com/support](https://www.tonies.com/support)

Quick troubleshooting tips



Setting up your Toniebox


Set up your Toniebox and start listening

Before you can use your new Toniebox, you must first set it up. Just grab your smartphone, tablet or computer and get started.



You can also visit [my.tonies.com/setup-toniebox](https://www.tonies.com/setup-toniebox)

With your free Tonie-Account, you can always access your Tonies and Toniebox settings.



You can find answers, instructions and support on www.tonies.com/support

Get your Creative-Tonie ready to play!

Put your Creative-Tonie on top

Switch on the Toniebox by pressing an ear. When the square lights up solid green, put your new Creative-Tonie on the Toniebox and wait until you hear a voice message. Now you can see your Tonie info in the app and on my-tonies.com.



There are 2 ways to upload audio onto your Creative-Tonie

Option 1: Open the Tonie-App and sign in with your Tonie-Account.

Option 2: Visit my-tonies.com and sign in with your Tonie-Account.



Upload your audio

Sync and put Creative-Tonie back on top

Select one of the Toniebox ears for three seconds. LED goes on as soon as the light turns solid green again. The new content will be played and downloaded simultaneously.



Done! When the light turns green, everything has been downloaded and you're ready to listen!



I'M READY TO BE CREATIVE!



Error message: When an error occurs, the Creative-Tonie will flash red. If the light is red, you need a new Creative-Tonie (or a new Toniebox). For more troubleshooting, visit www.tonies.com/support.

Using your Toniebox



Charging your Toniebox

Even a Toniebox needs a little rest and relaxation now and then. To charge your Toniebox, place it on the charging station. The LED lights up green. If it's lit up, the LED lights up orange.

Skip back and forth

To skip back and forth between chapters, tap your Toniebox on the side. To fast-forward or rewind, tilt the box to one side.



LED Display Overview

The Toniebox has different LED indicators. Here you get a brief overview of what they mean.

Color	LED Display Meaning
Flashing green	Factory setting. Please install everything you need to use. The battery is sufficiently charged and the Toniebox is ready to play.
Green light	Everything is ready to use. The battery is sufficiently charged for new wireless internet connections.
Pulsing blue	This may mean the following: The Toniebox is downloading new Tonie content. And it is downloading new Tonie content. The content comes before it switches into connection mode. (lasts approximately 20 seconds).
Flashing blue	On the charging station to recharge the battery.
Orange light	Charging station is full. The battery is fully charged.
Red light	Charging station is full. The battery is fully charged.
White light	Offline mode.

Listening with the Toniebox is easy.

Using the Toniebox is so simple:

Turn on

Either press one of the ears with your thumb and forefinger or place the box on the charging station.



Playing and pausing

When the light on your Toniebox turns green, place a Tonie on it. Want to pause the story or song? Just take the Tonie off the box. When you put it back on, it will start again from the same place – as long as another Tonie hasn't been played in between.

Turning the volume up and down

Press the big ear to turn up the volume on the Toniebox. Use the little ear to turn it down.



YOU CAN SET MAXIMUM VOLUME AND MUCH MORE IN YOUR TONIE-ACCOUNT!



Welcome to the Tonie-Universe



Beep! beep!



Who's beeping?
Play me with funny audio
and let your friends
guess the sounds.

Shake it!



Let's shake a leg



The hit on every child's birthday:
Playtime and action songs



1,2,3 - I'M THERE



BONJOUR

Whatever language
you learn with
CreativeTonies it is
now even **easier** to
practice!



BOO

We can sleep upside
down like bats because
we are **magnetic!**



Can't sleep?

Time

Then we have
the perfect solution: **Lullabies.**

Happy BIRTHDAY TO YOU!

I'M VERY STUDY

I'M HAND-PAINTED

I'M COLLECTIBLE

Take your Toniebox with you.

With its offline mode
it is a great companion
on car trips.

Truly!

The Toniebox is
softly padded
so it can survive
adventures on the go!

I'll FALL ASLEEP WITH YOU

You fall asleep comfortably with
the Toniebox and it
switches itself off 10 minutes
after the end of the songs.

tonies®

People listen to us
all their lives!

ROAR!

from the Disney family

your favorites

Education / FAVORITES
MUSIC
AUDIOBOOK