

材质:105克 铜版纸 双面印刷 折页
尺寸:90x90mm

90.00 mm



BTS121


Specification :
Model Name : BT15121
Cell Type : Lithium Ion
Battery Capacity : 3.7V, 1800mAh, 6.05Wh
Rated Input : 5V/0.5A (Max.)
Rated Output : 5V/0.5A (Max.)
Bluetooth Version : 5.2
Support : Handsfree, MP3, MicroSD Card, U.S.B.
Speaker : 4x0.6Wx2, 0.62mm
Transmission distance : 10M
Frequency response : 10Hz~20KHz
Dimensions : 2.50x1.02x0.41/102x41x41mm

Especificación:

Modelo: BT8121
Tipo de celda: pin de tipo
Capacidad del cable: 6 mts.
Tensión de entrada: 3V-5V DC (max.)
Tensión de salida: 5V0.5A (máx.)
Versión de Bluetooth: V2.0
Compatibilidad: MacOS, Windows, PDA, Tarjetas Modem
Alcance: 100 metros
Distancia de transmisión: 10M
Resistencia de humedad: -20°C-20°C
Dimensiones: 70(L) x 10(W) x 10(H)mm
Peso: 85Grs.10g

Technische Daten:
Modell: B1S121
Zellenart: Lithium-Ionen
Abwichtertoleranz: 3,7V, 1800mAh, 6,65Wh
Eingangsspannung: 5V/0,5A (max.)
Ausgangsspannung: 5V/0,5A (max.)
Bluetooth: Version 4.0
Unterstützung: Freigabe, P2P, Micro-USB
Ladezeit: 4h 00min
Ladeeffizienz: 90%
Frequenz: 100Hz
Temperaturbereich: 0°C bis 40°C
Gewicht: 100g

Specification :
 Modèle : BTS 121
 Type de cellule : Lithium Ion
 Capacité de la batterie : 3.7V 1800mAh 6.65Wh
 Entrée : 5V/0.5A (max.)
 Sortie : 5V/0.5A (max.)
 Version Bluetooth : 3.2
 Version Orange : 1.0
 Marque : FMA Corp. (Mfr.) ID : US898
 Huit en dix : 410 6842 6822 mm
 Dimensions de l'écran : 320x 240 pixels
 Dimensions de l'appareil : 110x71x162mm
 Poids : 80.0g

[illegible]

1. Power On/ Off
2. LED Switch Button
3. Play/ Pause
4. Mode Button
5. Volume up/ Next Button
6. Volume Down/ Previous Button
7. Recharge Port (Type-C DC 5V)
8. Micro SD Card Slot
9. USB Flash Drive


How to USE ?

1. Power button: Turn on the power button to turn on or off the speaker.
2. Bluetooth: Turn on the speaker to enter Bluetooth pairing mode, enable Bluetooth connection on your device, and connect to the device (e.g., iTunes 2.7).
3. Pause and Play: Press the play/pause button on the device to play or pause the music.
4. Mode button: Press the mode button to switch to Bluetooth, FM, music SD card, or USB play mode.
5. Volume: Press the volume up/down buttons to increase or decrease the volume.
6. Stop: Press the stop button to return to the previous volume.
7. Play next/Previous song: Press the "+" button the play next song. Press the "-" button to play previous song.
7. Micro SD card slot: Insert a new SD card to the slot. The speaker will automatically switch to SD card mode, or use the mode button. The speaker supports MP3, AAC, WAV, FLAC, E-AC3, WMA, and other formats.
8. USB play: Insert USB flash drive to the USB port. The speaker will automatically switch to USB play mode, or switch to USB play mode.
9. USB-A output: Charge your device through USB-A output port.

10. Reaching port 1 to change the speakers connect the cabling cable to your speaker and a power source to light indicator.
 11. LED (light indicator) light indicates changing. Red light will shut off when the speaker is fully charged.
 12. F.M.
 - Long press the *Play* (pause/unlock) 1 sec to start the automatic tuning.
 - Once tuning is done, Press the *+* button or *-* button to switch between the stations.
 - Long press the *+* button or *-* button to decrease or increase in volume.
 13. Hands-free mode (Bluetooth):
 - Answer incoming call: Press play/pause button
 - Select incoming call: Press and hold play/pause button
 - Reject/Endless Press play/pause button
- NOTE: The battery life of this product is based on normal use as a battery and volume control.

Note: The battery life of this product is based on user's activity and volume control.

Package Content



BT812

User Menu

③ Charging Costs

FCC Statement

Federal Communications Commission (FCC) Statement: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

GDH device made according to procedure received. Attached interface may may cause unintended operation. This equipment has been tested and found to comply with limits for a class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates and can also take frequency energy and, if not properly installed or used, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try one of the following measures:

- Identify or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Correct the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or a experienced radio/TV technician for help.

Warning: Changes or modifications made to this device not expressly approved by the manufacturer may void the user's warranty.

Third-party indemnified Corp.
may utilize the FCC's authority to oversee the device's safety. The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

Safety Instruction

- [illegible]

WARRANTY

All products from the date of purchase are qualified for limited time warranty. For more warranty information, please visit <http://www.strongpointwebbank.com>

GARANTEE

Alle Produkte eignen sich ab dem Kaufdatum zu einer beschränkten Qualitätsgarantiezeit. Für zusätzliche Garantieforderungen bitten Sie bitte auf: <http://www.enordpumpenbankas.com>

GARANTEE

Tous les art de nos bénéficiaires d'une garantie limitée dans le temps à partir de la date d'achèvement de l'opération.

GARANZIA

GARANZIA

Tutti i prodotti della fascia di controprezzo della garanzia di tempo limitato. Per tutte le informazioni sulla garanzia, visita il sito: <http://www.energypowerbanks.com>



PowerSafe Management
Guarantees against short circuit and over-charging for your power bank and devices.



Customer Service
For any question about the product, please contact us at service@energizerpowerbanks.com



FCC ID: 2AU4P-BT512

©2004 Energizer. Energizer Character and certain graphic designs are trademarks of Energizer Holdings Inc. Energizer Batteries, Energizer, and Energizer logo are registered trademarks of Energizer Brands, LLC and related subsidiaries and are used under license by Tennant International Corp.

400