



Energizer

WCP113

EN

Specification:

Model Name : WCP113

Rate Input : USB-C 5V = 3A, 9V = 2.22A, 12V = 1.67A

Wireless Output : 15W/10W/7.5W/5W

Dimensions : 96.5*68.5*103mm

Weight : 69.7±5g

Made In Vietnam

ES

Especificaciones:

Nombre del modelo: WCP113

Entrada nominal: USB-C 5V = 3A, 9V = 2.22A, 12V = 1.67A

Salida inalámbrica: 15W/10W/7.5W/5W

Dimensiones: 96.5*68.5*103 mm

Peso: 69.7±5 g

Hecho en Vietnam

Package Contents

Contenido del paquete



① WCP113



② User Manual
Manual de usuario



③ Charging Cable
Cable de carga

How to USE Cómo recargar

LED Light Indicator

First charge	The green and blue lights flash alternately once.
Standby mode	Unlit.
Wireless charging work	Blue light always on.
FOD	Flash of blue light.

Indicador de luz LED


Primera carga	Las luces verde y azul parpadean alternativamente una vez.
Modo de espera	Apagado.
Carga inalámbrica activa	Luz azul encendida continuamente.
FOD	Parpadeo de luz azul.

Instructions

Connect the USB cable port to the power adapter and then plug the other side into the micro port of the charging pad.

Instrucciones

Conecte el puerto del cable USB al adaptador de corriente y luego enchufe el otro extremo en el puerto micro del cargador inalámbrico.



Adapter NOT included
Adaptador NO incluido

Customer Review

LED light will be blue finally when connected successfully; if not, please readjust the position of mobile phone to make it.

1. Mobile phones need to be equipped with wireless charging function to use this product.
2. Mobile phones do not support wireless charging.
You need to purchase a mobile phone receiver to use this product.

Attention

1. Please keep the charger away from water or other liquid.
2. If you need to clean the charger, please make sure it isn't connected with power supply.
3. Do not place too close to magnetic stripe or clip card (ID card, bank cards, etc) to avoid magnetic failure.

Wireless Charging - Questions & Tips

What to do when the phone is not charging properly using the wireless charging pad or charging yet slow?

1. Ensure to properly place the center of the phone's back on the center of the charging pad.
2. Remove any foreign materials between the wireless charger and the phone as they may cause the device not to charge properly.
3. Some kinds of back covers may also halt the wireless charging. Please check the back cover of your phone, or remove the back cover and then try to charge again.
4. When installing 3rd party wireless charging cards, be sure that it is installed correctly, and won't create bulge to the cover to interfere with wireless charging.

How long will it normally take to complete a full charge using the wireless charger?

Normally, it would take three hours for the battery to be fully charged using the wireless charger. However, the actual charging time may vary depending on the device status and charging conditions as mentioned above.

Can I use a third-party back cover during wireless charging?

If your phone can charge normally with the case, then that will not be a problem. Please place your phone very close to the charging pad in case the thickness of the phone case is too thick to prevent your phone from .
If it still doesn't work, please remove your phone case then charge again.

What to do when the wireless charging pad gets warmer while charging?

It's normal for the wireless charging pad to become warmer while charging. That depends on a device fault. According to the charging environment or device state, the wireless charging pad or device itself may heat up while charging. Normal as it's deemed, this should not affect the device's performance or life span.

Reseña del cliente

La luz LED se volverá azul una vez que se conecte correctamente; si no es así, ajuste la posición del teléfono móvil para lograrlo.

1. Los teléfonos móviles deben estar equipados con la función de carga inalámbrica para usar este producto.

2. Los teléfonos móviles que no admiten carga inalámbrica necesitan un receptor de carga inalámbrica para usar este producto.

Atención

1. Mantenga el cargador alejado del agua u otros líquidos.

2. Si necesita limpiar el cargador, asegúrese de que no esté conectado a la fuente de alimentación.

3. No coloque objetos magnéticos como bandas magnéticas o tarjetas con clip (tarjeta de identificación, tarjetas bancarias, etc.) demasiado cerca para evitar fallos magnéticos.

Carga inalámbrica - Preguntas y consejos

¿Qué hacer cuando el teléfono no se carga correctamente con el cargador inalámbrico o se carga muy lento?

1. Asegúrese de colocar correctamente el centro de la parte trasera del teléfono sobre el centro de la base de carga.

2. Retire cualquier objeto o material extraño entre el cargador inalámbrico y el teléfono, ya que pueden impedir que el dispositivo se cargue correctamente.

3. Algunos tipos de carcasa también pueden afectar la carga inalámbrica. Verifique la carcasa de su teléfono, o retirela e intente cargar de nuevo.

4. Al instalar tarjetas de carga inalámbrica de terceros, asegúrese de que estén bien colocadas y que no generen bultos que interfieran con la carga inalámbrica.

¿Cuánto tiempo tarda normalmente en cargarse completamente usando el cargador inalámbrico?

Normalmente, tarda unas tres horas en cargarse completamente con el cargador inalámbrico. Sin embargo, el tiempo real de carga puede variar según el estado del dispositivo y las condiciones de carga mencionadas anteriormente.

¿Puedo usar una carcasa de terceros durante la carga inalámbrica?

Si su teléfono puede cargarse normalmente con la carcasa puesta, entonces no habrá problema. Por favor, coloque su teléfono lo más cerca posible de la base de carga, ya que el grosor de la carcasa puede bloquear la carga. Si aún así no funciona, retire la carcasa y vuelva a intentarlo.

¿Qué hacer si la base de carga inalámbrica se calienta mientras carga?

Es normal que la base de carga inalámbrica se caliente durante la carga. Esto depende del dispositivo. Según el entorno de carga o el estado del dispositivo, la base de carga o el propio teléfono pueden calentarse. Mientras esté dentro de lo normal, esto no debería afectar el rendimiento ni la vida útil del dispositivo.

Safety Instruction

- Avoid water, heat, fire, penetration of the battery, and severe drops at all times.
- Do not insert other objects into the USB ports other than the USB connectors.
- Once the product is fully charged, your power pack automatically shuts off to save power.
- During charge & recharge, battery may feel slightly warm.
- Do not clean the battery with water or other cleaning products, clean the exterior with a lightly wetted cloth or napkin.
- Normally the battery performance will decline after 2 years
- Any intentional and physical damage to the battery will not be under the warranty conditions.
- Battery storage temperature is between -10°C~+60°C , operating temperature is 0°C~45°C.
- Fully charge the battery before first use to maximize the battery life.
- Do not place any metal or flammable object on top of this product.

Instrucciones de seguridad

- Evite el agua, el calor, el fuego, la penetración de la batería y caídas fuertes en todo momento.
- No inserte otros objetos en los puertos USB que no sean los conectores USB.
- Una vez que el producto esté completamente cargado, su batería se apagará automáticamente para ahorrar energía.
- Durante la carga y recarga, la batería puede sentirse ligeramente caliente.
- No limpie la batería con agua u otros productos de limpieza; limpie el exterior con un paño ligeramente humedecido o una servilleta.
- Normalmente, el rendimiento de la batería disminuirá después de 2 años.
- Cualquier daño intencional o físico a la batería no estará cubierto por la garantía.
- La temperatura de almacenamiento de la batería es entre -10°C y +60°C, la temperatura de funcionamiento es de 0°C a 45°C.
- Cargue completamente la batería antes del primer uso para maximizar la vida útil de la batería.
- No coloque ningún objeto metálico o inflamable encima de este producto.

WARRANTY

All products from the date of purchase are qualified for limited time warranty. For more warranty information, please visit: <http://www.energizerpowerpacks.com>

GARANTÍA

Todos los productos a partir de la fecha de compra califican para una garantía limitada. Para obtener más información sobre la garantía, visite: <http://www.energizerpowerpacks.com>

Warning:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

FCC Warning Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF exposure statement:

The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance between 20cm the radiator your body.



PowerSafe Management

Guarantees against short circuit and over-charging for your power bank and devices.



Customer Service

For any question about the product, please contact us at service@energizerpowerpacks.com

Dispose the battery properly, seek for local disposal facility for advice. Do not dispose, dissemble, damage, or incinerate the battery at all time.

Deseche la batería correctamente, busque un centro de eliminación local para obtener consejos. No deseche, desarme, dañe o incinere la batería en ningún momento.



©2025 Energizer. Energizer, Energizer Character and certain graphic designs are trademarks of Energizer Brands, LLC and related subsidiaries and are used under license by TennRich International Corp.