

PARENT USER AND INFORMATION GUIDE



WWW.LOOKOUTFORSOUT.COM

FOR PARENTS ONLY HOW TO USE YOUR SPECIAL STAR TO LEAD SANTA'S SCOUT TO YOUR YARD...

1. On Christmas Eve, hang your Special Star outside where Santa's Scout will arrive in your yard.
2. With children, read the story of Santa's Scout to learn what he is all about.
3. Prompt children to place their own Scout in a window with glowing nose facing out.
4. At night, use the remote control to activate your Special Star when it's time to see Santa's Scout in your yard.
5. Tell children to search about, look out windows and doors and spy the yellow star nose of Santa's Scout!
6. Once they SEE Santa's Scout, laugh and shout then hurry them to bed and turn the lights out! Santa is on the way!



www.lookoutforscout.com

PRODUCT USAGE- READ BEFORE USE

CHILD'S LIGHT UP SCOUT REINDEER

FEATURES

Star shaped Glow in the Dark Nose

Parents: To activate Star shaped Glow in the Dark Nose, expose the nose to bright light

PARENT'S LIGHT UP STAR with WIRELESS REMOTE

FEATURES

ON/OFF Switch: To conserve battery life, switch to OFF when not in use

3 MODES Include: Flashing Light, Steady Light, OFF

Parents: To operate the light up star, point the wireless remote control in the direction of the star (up to 15 meters) and select the desired mode (flashing, steady, off) on the remote control.

PLUSH CARE: SURFACE CLEAN ONLY

Gently wipe with a damp cloth.
Do not use detergent or stain removers.
Do not get wet.
Product and colors may slightly vary.

Retain this information for future reference.

2018 Family Holiday Traditions, LLC
168 West Main Street # 700
New Market, MD 21774, U.S.A
Tel: (833) 287-2688
www.lookoutforscout.com

CONFORMS to Safety Standards ASTM/CPSIA/FCC



The logos, graphics, packaging and product are
© TM ® of Family Holiday Traditions, LLC

All Rights Reserved MADE IN CHINA

This Activity Kit contains:

One child's Scout Reindeer with glowing nose,
One adult's light up Special Star with wireless
remote (batteries included) and User Guide, One
beautifully illustrated Family Story book.
Parental Supervision Required.

IMPORTANT INFORMATION



WARNING: NOT RECOMMENDED FOR CHILDREN UNDER THREE YEARS OF AGE. CONTAINS SMALL PARTS WHICH PRESENT A CHOKING HAZARD FOR YOUNG CHILDREN.

WARNING: THIS PRODUCT CONTAINS BUTTON CELL BATTERIES. Hazardous if swallowed- see full instructions.

CAUTION: Adults please remove and dispose of all packaging, fasteners and ties before use. Parental Supervision Required

Requires 6 x 1.5 V LR44/SR44 button cell batteries (star) and 1 x 1.5 V button cell battery (remote). See important battery use and disposal information below. Contains button coin cell battery.

Hazardous if swallowed- see information below. **KEEP BATTERIES OUT OF THE REACH OF CHILDREN.** Parental supervision is required when replacing batteries. Dispose of batteries safely and based on waste regulations.



As with all small batteries, the batteries used with this product should be kept away from small children who still put things in their mouths. This product contains a Button or Coin Cell Battery. A swallowed Button or Coin Cell Battery can cause internal chemical burns in as little as two hours and lead to death. Dispose of used batteries immediately. Keep new and used batteries away from children.

If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention. Promptly see a doctor and the doctor phone (202) 625-3333 collect. If you reside outside of the United States, have the doctor call your local poison control center.

TO AVOID BATTERY LEAKAGE

Always follow the instructions carefully. Use only batteries specified and be sure to insert them correctly by matching the + and – polarity markings.

DO NOT mix old batteries and new batteries or standard (carbon-zinc) with alkaline batteries.

Remove exhausted or dead batteries from the product.

Remove batteries if product is not to be played with for a long period of time.

Do not short-circuit the supply terminals

Do not mix rechargeable batteries with any other types of batteries. Rechargeable batteries are not recommended in the use of this product.

Should this product cause, or be affected by, local electrical interference, move it away from other electrical equipment. Reset (switching off and back on again or removing and re-inserting batteries) if necessary.

TO REPLACE BATTERIES

Use a Phillips/cross head screwdriver



FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

**-Reorient or relocate the receiving antenna
-Increase the separation between the equipment and receiver
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
-Consult the dealer or an experienced radio/TV technician for help**

CAUTION: Changes or modifications to this unit not expressly approved by the party responsible for compliance would void the user's authority to operate the equipment.