

User Manual

Aroma Diffuser

GN-WA010, 168GW, LM-168W, LM-168GW, 168GM

FCC ID: 2AUC3-168GW

START GUIDE

SMART WI-FI ESSENTIAL OIL DIFFUSER

| | |
|-------------------------------------|----|
| Contents | |
| • Start Guide | 01 |
| Product Diagram | 01 |
| Download & Register | 01 |
| Getting Ready | 02 |
| Using Controls | 04 |
| Cleaning | 04 |
| Connect (Easy Mode) | 05 |
| Connect (AP Mode) | 06 |
| Questions, Troubleshooting, Notices | 08 |
| • Voice Control Guide | 11 |
| Google Assistant | 11 |
| Amazon Alexa | 13 |

FCC Notice

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not expressly approved by the manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Amazon Alexa

03

- **Authorize your account with Smart Home Skills** using the username and password from your app.
- **Choose "Discover Devices"**. After a few seconds your devices will be displayed under Smart Home in the Alexa app.

04

- **"You can reconnect your devices in the app, and Alexa will refer to them by the same name."**

Alternatively, you can create an Alexa group, the "Bedroom" or "Bathroom", and add the devices to the group.

Important information:

Before installing, read and follow all precautions, including the following:

CAUTION: Not for use with ground-fault circuit-interrupter receptacles or receptacles with residual-current devices. To reduce the risk of fire or electric shock, do not use this device with a cord/cable in which the first opening does not coincide with the blades. To reduce the risk of electric shock, this product has a first grounding pin and will only fit into a 3-prong grounded outlet. Do not use if the plug does not fit.

CAUTION: Contact for correct use only. **DO NOT EXCEED WATER CAPACITY.**

START GUIDE

What's in the Box

- Smart Wi-Fi Essential Oil Diffuser
- Measuring Cup
- Power Adapter

Get Ready

- **Know your Wi-Fi network and password**
- **Make sure your mobile device is running iOS 9 or higher or Android™ 5.0 or higher**
- **Make sure you're connecting to a 2.4GHz Wi-Fi network. 5GHz networks can't connect to 5GHz networks.**

Things you can say!

"Alexa, discover my device."

"Alexa, turn on the bedroom light."

"Alexa, set the bedroom light to orange."

"Alexa, turn off the coffee machine."

"Alexa, set the living room to 55%."

"Alexa, turn on the diffuser."

Google Assistant

03

- Choose from the list of Home Control partners.

04

- Authorize your account with Google Assistant using the username and password from your app.

At any time, go into the "Home Control" section of the Google home app to set preferences and learn more for your devices. **Do not remove your device from the app, and Google Assistant will refer to them by the same name.**

For if you reconnect a smart plug to "Living Room" or a nickname like "Bedroom", then Google Assistant will use that same name later on. **You can always give a nickname using the Google home app as well. You can also assign plugs to a specific room, the "Bedroom" or "Kitchen."**

Google Assistant will be able to control devices by room.

Product Diagram

Download & Register

STEP 1

- Download the App from App Store or Google Play.
- Register an account on your App.

Download & Register

02

- Enter the verification code and create a password.
- Log in to the App.

STEP 2: Getting Ready

- Remove the outer cover.
- Add purified water.

Things you can say!

"Hey Google, turn on all the lights in my bedroom."

"Hey Google, turn off fan."

"Hey Google, set the bedroom light to orange."

"Hey Google, set the coffee machine."

"Hey Google, set the living room to 55%."

"Hey Google, turn on the diffuser."

VOICE CONTROL GUIDE

Thank you for purchasing your smart home product. Make sure your device are already set up using the app, then follow these steps.

Smart Wi-Fi Essential Oil Diffuser each appliances using the app and your voice assistant will recognize and follow instructions to control that Smart Wi-Fi Essential Oil Diffuser.

Name and Control Each Device by Voice

| | |
|-----------------------|----|
| Contents | |
| • Voice Control Guide | 11 |
| Google Assistant | 11 |
| Amazon Alexa | 13 |

Getting Ready

03

- Add the essential oil.

04

- Replace the outer cover.

04

- Plug the AC Adapter into the outlet.

Using Controls: Cleaning

STEP 3: Using Controls

03

- **Light Button (Left)**
- **Mist setting & Wi-Fi (Middle)**
- **Mist Button (Right)**

STEP 4: Cleaning

For safety, it is suggested to clean the diffuser every 6-8 days or after 3-5 uses. The cleaning procedure are as follows:

Troubleshooting

- **Connect connect to your Wi-Fi network.**
- **Reset the device.**
- **System Requirements**
- **Technical Specifications**

Questions: Troubleshooting: Notices

Frequently Asked Questions

- **Can I share with family and friends?**
- **Can I group multiple devices together?**
- **How Many Device Can I Control?**
- **My device has a funny name. How do I remove it?**
- **The device appears offline or unreachable, what should I do?**
- **What's the Wireless Range?**
- **If my Wi-Fi/Internet goes down, will still work?**

Cleaning: Connect (Easy Mode)

STEP 5

Easy Mode

01

- In the app, on the top corner of the Devices screen, click **+**.

02

- Make sure the indicator light on the device is flashing rapidly green, indicating the device is ready to connect using Easy Mode. If not, press and hold the Light button for 3 seconds until the indicator light is flashing rapidly, then press "Next Step".

Connect (Easy & AP Mode)

03

- Enter your Wi-Fi network and password.

04

- The app will try to connect your device. NOTE: not connect to 5GHz networks. If the connection fails, try to connect using AP Mode.

Add device Backup AP Mode

01

- Make sure the device is in AP Mode, indicating slowly "Next Step" light is flashing green.

02

- In the app, on the top corner of the Devices screen, click **+**.

03

- Click Next and enter your Wi-Fi details.

Connect (AP Mode)

04

- Follow the instructions to choose the device from your Wi-Fi list.

05

- The device will connect. NOTE: can't connect to 5GHz networks.

How do I reset the device and what does the blinking light mean?

Reset the diffuser by pressing and holding the Light button for 3 seconds until the indicator light is flashing rapidly.

- Press on the green and hold to reach Easy Mode (Fast blinking, 3x per second)
- Press again (press and hold) to reach AP Mode (Slow blinking, every 3 seconds)

FCC STATEMENT:

This device complies with Part 15 of the FCC rules and Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or change to this equipment. Such modifications or change could void the user's authority to operate the equipment.

This radio transmitter (identify the device by certification number or model number if Category II) has been approved by Industry Canada to operate with the antenna types listed below with the maximum permissible gain indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement.

To maintain compliance with FCC's RF exposure guidelines, this equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body.