

## USER MANUAL



# AIRBUDS

WIRELESS EARBUDS • CHARGING CASE  
HANDS FREE CALLING WITH BUILT-IN MICROPHONE

### Specifications:

True wireless stereo (TWS), real no wires design, individual left and right channel, HIFI sound, both the left and right earbud are Wireless enabled, can be used separately, or used as one pair.

Wireless version:	V5.0+EDR (both sides), ultra low consumption
Wireless Mode:	A2DP1.3/HFP1.6/HSP1.2/AVRCP1.6/D11.3.
Wireless Frequency:	2.4GHZ
Wireless Range:	10 Meters with no obstacles
Battery capacity:	Earbud: 50mah rechargeable Li-ion battery Charging dock:400mah
Talk/Play time:	Play Time: 3+ hours Talk Time: 90-150 Minutes
Standby time:	72 Hours

### Pairing Instructions:

1.Pairing with one earbud: long press the multi-function button until the led flashing in red and blue alternately Turn on the Bluetooth on your device and select "AirBuds"on your list, there will be reminding voice saying"Connected". Once you can enjoy music or making phones calls, it supports reporting incoming calls.

2.Pairing with both earbuds:

a.Press & hold the multi-function buttons of **both** earbuds at the same time until the led flashing in blue and blue alternately.

b.Turn on the Bluetooth on your device and choose "AirBuds"to connect  
Battery status is displayed on your device.

1

# AIRBUDS

### Wireless Usage:

#### 1.Making phone calls:

Be sure the Airbuds are connected with your mobile phone, then you can begin to make/recive phone calls. Incoming calls broadcast calling numbers/contacts. To answer calls: press the power multi-function button one time. To reject calls: quickly press the multi-function button 1 times. When the earbuds are in music mode, you can dial your most recent number by quickly pressing the multi-function button 3 times(redial the latest number).

#### 2. Listening to music:

Be sure the earphone connected with your mobile phone, then you can listen to music on your music apps. Press the multi-function button to pause the music and tap it again to play.

Keep pressing 2 seconds on right / left earbuds:next music.

#### 3.Powering off.

Press and hold the multi-function button until LED changes to red. When the Earbuds are not in use they will disconnect from Bluetooth and power off after 5 minutes.

#### 4.Charging:

There is a sound reminder when battery is low, also the LEDs on the AirBuds will display red. The LED turns blue when fully charged.  
Note: the earbuds will force shut down when charging even if they are powered ON before charging.

2



### Warnings:

1.Do not overuse the earbuds or put it under heavy pressure.  
Keep away from water and high temperatures.

2.Keep away from WIFI routers or other high frequency transmitting equipment to prevent interruption of signal receiving.

3.Please use this earphone under its working range (10meters). Sound quality is better if there are no obstacles between the connected devices.

3

## Summary

- 1 Dust-proof Mesh
- 2 Multi-function Button
- 3 Microphone
- 4 AirBud Charging Port
- 5 Charging Case Indicator Light
- 6 Micro-USB Charging port



## FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: --Reorient or relocate the receiving antenna.

--Increase the separation between the equipment and receiver.

--Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

--Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.