

K07012BK User Manual



-  Head up
-  Foot up
-  Head and foot up
-  One button flat
-  Head and foot down
-  Head down
-  Foot down

1. Process of test

1.1 Head UP

Press and maintain, head lift stretches out

1.2 foot up

Press and maintain, head lift retracts

1.3 Head and Foot up

Press and maintain, Head and foot lift stretches out at the same time.

1.4 FLAT

Press and release the FLAT button on remote, the head and foot actuators moves to lower position(when the actuator is free, can turn off the vibration motor and turn off the indicator light when press once), stop when press any button;

1.5 Head and Foot down

Press and maintain, head and Foot lift retracts

1.6 Head down

Press and maintain, head lift retracts

1.7 Foot down

Press and maintain, Foot lift retracts

2. Remote control pairing

Unplug the control box (model: MC20101, FCC ID: 2AUMIDDCMC20101) from the power source. Then press and hold the Button  and Button  simultaneously for about 5 seconds till the backlights of the remote control are off. Plug the control box, two sounds from the buzzer, means the pairing is successful.

FCC Warning:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.