




Media Center

Gauge Style Media Center



INSTALLATION OVERVIEW




OPERATION

The button layout below will give you a quick overview of the button functionality.

BUTTONS:

- 1 - Power
- 2 - APS
- 3 - Band
- 4 - Mode
- 5 - Volume +
- 6 - Volume -
- 7 - Play/Pause
- 8 - Tune Up
- 9 - Tune Down



Function:

	How To:
Power On	<u>Press the Power (1) button once.</u>
Power Off	<u>Hold the Power (1) button for 2 seconds.</u>
Volume Up	<u>Press the VOL + (5) button.</u>
Volume Down	<u>Press the VOL - (6) button.</u>
Seek Up	<u>Press APS (2) once.</u>
Tune Up	<u>Hold down Tune Up (8).</u>
Tune Down	<u>Hold down Tune Down (9).</u>
Pause/Play	<u>Press Play/Pause (7) once.</u>
Mute	<u>Press Power (1) button once.</u>
Audio/Settings	<u>Hold down Mode (4) button.</u>

Sources

To change any of the sources, press the Mode (4) button on the Radio. Continue to press Mode until the desired source is reached.

OPERATION

FM Source:

Function:

Seek Up:

Press the APS (2) button once.

Tune Up:

Hold Tune Up (8) button for 1 second. Then press (8) once.

Tune Down:

Hold Tune Down (9) button for 1 second. Then press (9) once.

Mute:

Press the Power (1) button.

AM Source:

Function:

Seek Up:

Press the APS (2) button once.

Tune Up:

Hold Tune Up (8) button for 1 second. Then press (8) once.

Tune Down:

Hold Tune Down (9) button for 1 second. Then press (9) once.

Mute:

Press the Power (1) button.

Presets:

Press and Hold APS (2) button. Programs strongest stations into FM and AM Presets. Pressing Tune Up (8) and Tune Down (9) will change preset stations. To set a custom preset, press Tune Up (8) for desired preset number. Then use Manual Tune to change to desired station. Press Play/Pause to set new station into preset number.

OPERATION

Sources

USB Source:

Function:

Next Track:

Press the Seek Up (8) button once.

Previous Track:

Press the Seek Down (9) button once.

Fast Forward:

Hold Tune Up (8) button.

Rewind:

Hold Tune Down (9) button.

Pause:

Press the Play/Pause (7) button.

Repeat:

Press APS (2) to Repeat 1, Press again to Repeat all.

Search:

Press and Hold APS (2) to search a specific track #, then press VOL+ (5) or VOL- (6) to change to that track #.

Bluetooth (BT) Source:

Function:

Next Track:

Press the Seek Up (8) button once.

Previous Track:

Press the Seek Down (9) button once.

Pause:

Press the Play/Pause (7) button.

BT Source Cont.

Pairing Mode:

When BT MUSIC is flashing, the marine audio is in pairing mode.

5 Locate the device name on your phone to pair.

OPERATION

Device Name: Media Center

Disconnect Device:

Press APS (2) button.

Settings

Press and Hold Mode (4) to enter Settings Menu. Press and Release Mode (4) to change Menu Items. To adjust setting, press VOL+ (5) or VOL- (6). Adjustable settings are: Bass, Treble, Balance, Fader, Beep, EQ, Loud, and Tuner Region.

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.