

Distinguished Customers

Thank you for purchasing wireless Headphone. Before getting started, please read the user's manual carefully so as to ensure proper operation and optimized performance of this product. With stylish outer appearance, compact structure, high fidelity sound and multi-functionality, it has obtained patent concerning its outer appearance and adopted advanced electric and sound technology in the industry, ultimately making itself the best choice to hook up with your devices such as tablet, cell phone and digital music player etc. perfectly by presenting you exceptional stereo effect at home, on vacation or at work. Please pay attention to following points:

1. Please follow the operating instructions in this user manual.
2. Please do not charge with any charger with an output voltage of more than 5V, otherwise it may cause damage to the earphone battery.
3. Please store this product at normal room temperatures.

Operating Instruction on the headphone:

ANC ON/OFF:

Slide the swift to turn ON/OFF the ANC function.

Power ON:

Long press the MFB for about 3sec till the LED flashes to blue and red light alternatively and headset enter into Bluetooth pairing mode.

Power OFF:

Long press the MFB for about 5sec to power off the headphone. If the battery is low, the red light will flash fast and then turn the headset into power off mode.

Pairing:

1. Power on the headphones by pressing and holding the Power / Play / Pause Button for about 3 seconds until the blue and red LED lights turn on and start flashing.
2. This means now the headphones are in Bluetooth pairing mode.
3. Activate the Bluetooth® on your phone and search for "friendie AIR PRO 4.0". Select "friendie AIR PRO 4.0" from the device's list to connect.
4. Should you be asked for a password, please enter the Bluetooth Default Password of 0000.
5. When successfully paired, the blue LED light will flash.
6. The device is now ready to make / receive calls and playback music.
7. Music tracks can be selected either on the headphones or on your phone.

Play/Pause:

Short press the MFB once to play/pause the music.

Next / Previous Song:

Long Press the Volume+ / Next button to change the music to next song. And similarly long press the Volume- / Previous button to change the music to previous song.

Volume Up/ Down:

Short press the Volume+ / Next button in regular intervals to increase the volume levels and similarly short press Volume- / Previous button in regular intervals to decrease the volume levels.

Answer the call / Hang-up:

Short press the MFB to answer / hang up the call.

Call Reject:

Long press MFB for two seconds to reject the call.

Note: When the phone call out or answer the call, if the Bluetooth headphone are playing the music, the music will pause automatically and enter the waiting state, the music will go on play automatically after hang up.

Operating Instruction for Line-IN Mode:

Insert the audio cable to the interface of headphone and then you can hear songs with it as normal headphone, in that case Bluetooth state will turn into OFF mode.

The audio cable can only work on the phone.

Play/Pause: Short press the button on the cable once to play/pause the music.

Next/ Previous song: Press the button on the audio cable twice to change the music to next song.

Press the button on the audio cable three times to change the music to previous song.

Answer the call / Hang-up: Short press the button on the cable to answer / hang up the call.

Call Reject: Long press button on the cable three seconds, the phone will reject the call when release the button

Instructions for Charging:

1.Before charge the Headphone, please turn the ANC and BLUETOOTH function off.

1.Before use the headphone for the first time, please charge it full.

2.Charge the headphones with 5V DC. The indicator will glow red when it is charging, and after full charge the LED light will become OFF

SAFETY PRECAUTIONS

- This product is not intended for commercial use and has been tested for household use only.
- This product is not intended for use by small children, or persons with diminished mental capabilities. Please ensure that the use of this product is monitored by a guardian or parent.
- To reduce the risk of fire or electric shock, never use your headphones near water or in areas where it can come into contact with water. Never handle the headphones if they have been dropped into water or any other liquid. If the product comes into contact with water while switched off, this poses a safety hazard.
- Always make sure your hands are dry before touching the plug or power connections.
- CAUTION: Do not remove the panel covers by unscrewing them. To reduce the risk of electric shock, do not remove the cover. No user-serviceable parts inside. Refer servicing to a qualified service personnel.
- DO NOT use any accessories, plugs or power cables not recommended by this document, or of a lesser Amperage or Voltage.
- DO NOT operate the product with a damaged cord or plug, or after it has malfunctioned, it has been dropped or damaged in any way.
- WARNING: Always keep optional accessories, small parts and packaging out of the reach of

babies and small children, as these items may pose a choking hazard.

- DO NOT overcharge your headphones; doing so may shorten the lifespan of the built-in batteries and could also cause your device to overheat.
- CAUTION: Do not disassemble the battery or dispose of it in a fire.
- CAUTION: Should your battery show signs of overheating, smoke or fumes being emitted during charging, remove the charging cable immediately.
- Do not use any harsh or abrasive cleaning chemicals or materials on your headphones; doing so may damage or scratch the surface finish.
- Do not expose your headphones to direct sunlight or high temperatures for extended periods of time.
- Do not store in temperatures over 60°C.
- Do not expose the battery to excessive heat such as sunshine, fire or the like. Store in a cool, dry place.

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.