

说明书正反印（双面）刷。

正面

FCC ID: 2AURSFRIENDIE2

AIR ZEN
WIRELESS IN-EAR HEADPHONES

friendie

Please read the instructions carefully before using the product

Components:

Charging:

Your friendie AIR Zen is powered by rechargeable li-ion batteries. Please ensure that the battery is fully charged before using the headphones for the first time.

To charge your charging case:

1. Insert USB charging cable into a USB port.
2. Connect USB cable into the Micro USB port on your charging case.
3. Red indicator light shows the battery is charging.
4. When fully charged the light will turn blue.
5. It takes approximately 3 hour to fully charge the charging case.

To charge your earphones:

1. Place your earphones in the charging case to charge.
2. Ensure the charging lid is closed.
3. Red light on the charging case shows the battery is charging.
4. When fully charged the light will turn blue.
5. The earphones can be charged up to six (6) times in a fully charged case, before you need to recharge the case.

Charging case controls:

Charge case indicator light	Battery low: Red light flashing. Charging: Red light displayed. Fully charged: Blue light displayed.
Earphone charging indicator light	Charging: Red light displayed. Fully charged: Blue light displayed. After 10 seconds the blue light will turn off.

Please ensure the charging lid is on and the indicator light is red to charge.

Pairing: (Connecting to your phone/tablet)

Pair the AIR Zen to your device (phone/tablet/laptop).

1. Remove both earbuds from the charging case.
2. On your device, enter settings and select bluetooth. Scroll to the bottom of the screen and select "AIR Zen" from the devices to pair.
3. Your device and headphones should now be paired.
4. Next time, the headphones will automatically pair to each other and to the last connected device when turned on.

Earphone general controls:

Auto On/Off	On: Remove headphones from charging case. Off: Place headphones in charging case.
Power off	Hold down multi-function button on one headphones until red light blinks.
Charging	Place earphones in the charging case. Place the charging lid on to charge.
Low battery	Red light flashes and you will hear "battery low, please recharge".
Change language	In the pairing state, double click the multi-function button on the R and L headset.

Earphone phone controls:

Answer / End	Press the multi-function button.
Reject call	Hold down the multi-function button until you hear a tone.
Mute	During a call, double click the multi-function button. You will hear a prompt "silent mode". To end mute, repeat the operation.

Troubleshooting:

Bluetooth not connecting	Restore factory pairing settings: Turn off bluetooth on your phone. With your earbuds turned off, hold down power button until they blink red and blue. Once paired only one earbud will blink blue.
Bluetooth name not appearing	Ensure earphones and device (e.g. phone) are within 8 meters with no interference. Ensure they are not paired to another device.
Dropouts occur in one ear	Ensure you have no interference from other 2.5G devices, e.g. cordless phones, WiFi.
Volume	Volume up: Triple click right earbud. Volume down: Triple click left earbud.
Got another question?	Please contact us at support@friendie.com.au or visit support at www.friendie.com.au.

FCC Warning:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Specifications:

Charge Case:	Battery Size: 750mAh Li-Po Charge time: 4 hours (5V/1A) Usage: 6 charges (12 hours of usage) Dimensions: Micro USB2.0 Additional: 5cm x 5cm x 3cm Key chain loop, magnetic lid.
Earphone:	Size: 50mAh Li-Po Charge time: 1 hour (via charge case) Music playback: 4 hours usage Talk time: 2.5 hours
Audio:	Sensitivity: 101dB +3dB Impedance: 32 Ω Frequency: 20-20KHz Speaker: 8mm Noise Cancelling: CVC 6.0
Wireless Connections:	Standard: BT 5 + EDR Frequency range: 2.5G ISM (2.4GHz – 2.8GHz) Distance range: 5 meters (dual earphones) Protocol: HSP/HFP/A2DP/AVRCP/EDR
Weight:	Charger case (including earphones): 52 grams Earphone (each): 4.8 grams

WARNING:
Listen responsibly. Headphones are capable of delivering sounds at loud volumes and high pitched tones. Prolonged exposure to loud sounds can cause irreversible hearing damage.

www.friendie.com.au
f: sharewithfriendie
i: friendie_audio

432 mm

72.0 mm

116mm