6. Pair with your indoor chime

Click the SETTING button on the chime, and the chime will be in pairing mode for 20 seconds, with its red LED flashing.




2 Press the doorbell button to send a pairing signal, and your chime will sound to react, together with its blue LED flashing. Chime pairing succeeds.



Chime settings.




Click to enter/quit pairing mode; Press & hold for 5 seconds to restore factory defaults.



level 1: 110 dB; level 2: 100 dB level 3: 90 dB; level 4: 80 dB

🎢) Ringtone selection.

Click to change ringtone (4 ringtones available).



7. Install Your doorbell

1 Select location for your doorbell.




Select a location.


It is suggested to mount the doorbell at least 4 feet (120 cm) above the ground for optimal angle of view and best motion detection performance.

2 Mount your doorbell.





Mount the rear mount to Adhesive tapes are optional to mount the o your wall with screws doorbell on flat surfaces. and tools.



8. Accessory (Optional)

P Doorbell Angle Mounts

You can purchase the following angled brackets so as to point your doorbell to a specific view angle.





9. Trouble Shooting

Q1: Is the video doorbell powered by battery?

A1: Yes, there is a Li-ion battery built-in. Thanks to the low power consumption technology, a full charge lasts for more than 2 to 3 months in our lab test environment (Lab test condition: 10 events per day, 15 seconds video recording per event).

Q2: Does it support legacy hardwire power source?

A2: No, it doesn't. If you need longer battery endurance, suggest that adding a solar battery charger for your doorbell, if only there is sunshine in your doorbell location. You can contact our after-sale service to know where to buy.



Q3: Does it work with existing mechanical chime?

A3: No. The doorbell comes with a battery powered wireless chime to notify people when your visitor presses the doorbell button. And our wireless chime is 100% wireless, you can place it almost everywhere you like. The transmission distance in open space is more than 100 meters (328 feet).

Q4: How many wireless chimes can be added to the doorbell?

A4: You can add several wireless chimes to work with your video doorbell. And one chime can be paired with upto 8 video doorbells.

Q5: Does it support customized Motion Detection Zones.

A5: Yes it does. You can customize the detection zone in the doorbell settings.

Q6: Does the doorbell support cloud storage?

A6: Your doorbell support local video storage by TF card . And you can also activate the cloud storage service in the App so as to back up video clips into the cloud server. There is a 7-day-free cloud recording trial service.

button to run a test.