


# 魔声INSPIRE说明书

MONSTER®

ENGLISH

## Pairing

1. Ensure that your phone or music player is switched on.
2. To pair the headphone if it **has been** previously paired with another device, **switch on** the headphone, it will enter the pairing mode automatically and the blue and red indicator light starts to alternately flash quickly. The headphone is ready to pair with your device.
3. To pair the headphone if it **has not been** previously paired with a device, ensure that the headphone is **switched off**, and press and hold the multifunction key (for about five seconds) until the blue and red indicator light starts to alternately flash quickly.
4. Activate the Bluetooth feature on your phone or music player, and set it to search for Bluetooth devices.
5. Select your Monster Device from the list of found devices on your phone or music player.



Product Diagram

1. Type-C Charging Port
2. ANC Button
3. Volume + / Next Track (long press)
4. Volume - / Previous Track (long press)
5. MFB Button (Power on/off/Play /Pause /Call/End/ Paring)
6. 3.5mm Audio Port
7. LED Indicator
8. Microphone

Note:

- A voice prompt will be heard when the battery is low.
- Switch the ANC **switch** to activate /deactivate the noise cancellation function. The LED indication will stay solid green when the noise cancellation is on.
- To guarantee your personal safety, please ensure that these headphones are not worn or kept in the immediate vicinity (not less than 10 cm) of a pacemaker.

## Headphone Controls

| Function                                    | Operation   |
|---|---|
| Power on                                    | Press and hold the MFB Button for 3 seconds until the blue indicator flashes twice              |
| Power off                                   | Press and hold the MFB Button for 3 seconds until the red indicator flashes twice and turns off |
| Play / Pause / Answer / Hang up phone calls | Short press the MFB Button once   |
| Reject phone calls                          | Press and hold the MFB Button for 1 second  |
| Redial                                      | Double-click the MFB Button   |
| Volume + / -                                | Press the Volume + / - Button   |
| Previous / Next Track                       | Press and hold the Volume + / - Button for 1 second   |
| Device change                               | Press and hold the Volume + (During the call)   |
| Mute/unmute call                            | Short press the Volume + / - Button (During the call)   |

正面

尺寸: 80\*190mm

材质: 128G铜版纸

MONSTER®

## Guide to Indicator Lights

| INDICATOR LIGHT                         | DESCRIPTION   |
|---|---|
| Red Flash                               | Low Battery Warning   |
| Red Flash X2                            | Power Off   |
| Red & Blue Alternate Flash              | Paring  |
| Blue Flash Once Every 5 seconds Quickly | <ul style="list-style-type: none"><li>• Connected</li><li>• Connect Successfully</li><li>• Play Music</li><li>• Active Call</li><li>• During Call</li><li>• Standby</li></ul> |
| Blue Flash X2                           | <ul style="list-style-type: none"><li>• Power On</li><li>• Incoming Call</li></ul>  |
| Green Light                             | ANC ON  |

You can use your On-Ear headphone as a wired headphone to save batteries or if your batteries are not charged.

### Disconnect the Headphone

To disconnect the headphone from your device, switch off the headphone, or disconnect it in the *Bluetooth* menu of your device.

### Reconnect the Headphone

To connect the headphone to the phone or music player that you last used with it, switch on the headphone and bluetooth of your device to make the connection.

### FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates use and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.

### FCC Notice

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

### FCC Caution

- Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.
- This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

背面