



QUICK INSTALLATION GUIDE B021

LIST OF ACCESSORIES




Control Remoto x1



AAA batteries x2

Hardware Configuration

Number of buttons	20
Button size	141*48*21 (mm)
Shell plastic material	ABS raw material (odorless, non-doped material), thickness $\geq 2.0\text{mm}$
Shell color	Plastic color, black
Operating temperature	0~50℃
Infrared wavelength	950±50nm
Infrared carrier frequency	38.0±0.3KHz
Bluetooth carrier frequency	2.400GHz~2.4835GHz
Operating voltage range	2.2~3.6V
Working current	<40mA
Remote control distance	>12M
Bluetooth version	BT4.2



INSTRUCTIONS

1. Indicator Light: press any key to make the light flash; If battery replacement is necessary, this indicator light will flash rapidly.

2. Bluetooth pairing: press the “OK” + keys "Volume Down" together on your remote control for 10 seconds.

3. Voice Search: Press the “Google Assistant” button on your remote control and speak clearly to access entertainment, control smart devices, get on-screen responses and more using your voice.

Note: The functions of the remote control may be different for different applications.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment of and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.**
- Increase the separation between the equipment and receiver.**
- Connect the equipment into an outlet on a circuit diferent from that to which the receiver is connected.**
- Consult the dealer or an experienced radio/TV technician for help.**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.