







1. Remove back cover.




2. Take out the battery.
Lift from white arrow.



3. Insert nano SIM card by following the arrows.
For extra memory, insert micro SD card.
To remove, press the edge of the SIM or SD card.




4. Place back battery and back cover.
Fully charge the phone.



5. Press and hold the power button
to turn on your Fairphone 3.

New to Android?



Don't worry, we'll go through it with you,
step by step. Check out
fairphone.com/androidsetup


FAIRPHONE

Change
is in your
hands

To learn more on how we're
changing the industry go to
fairphone.com/story

0000-0000-000000-0005

No charger,
less electronic
waste




We don't include a USB-C cable and
power adapter because you probably
already own one. If not, order at
fairphone.com/charger

Your phone
your style,
your
accessories



Discover our Fairphone 3
accessories collection at
fairphone.com/accessories

Care for the
planet



Recycling your old phone is a great
way to show you care about fairer
electronics. Learn how at
fairphone.com/recycle

Designed
to open



With the screwdriver in this box, you
can take extra care of your phone.
Find out more at
fairphone.com/support

FAIRPHONE

Take a
look
inside

Fairphone 3
Quick Start Guide