




Label locates inside the battery compartment and viewable to the users as they install the SIM