


55x72mm

3-In-1 Foldable
Wireless Charging Stand
(USER MANUAL)



Thank you very much for using this product. Please read this manual carefully before use to avoid product damage caused by improper operation.


Special Features

- Charge 3 Devices (Phone + Watch + Earbuds) Simultaneously
- Unique Foldable Design
- Phone Charges in Portrait or Landscape
- Foldable Magnetic Charger Mount Design For Phone And Watch
- Magnetic Case Compatible
- Integrated With Fast And Safe Charging Technology

Specifications

Product Size	79*79*30mm (Foldable)
Material	ABS+PC
Color	Black/White
Input	DC5V/3A,9V/3A
Phone Output	5W/7.5W/10W/15W(Max)
Watch Output	2.5W(Max)
Earbuds Output	5W(Max)
Input Interface	USB-C
Package Contents	3-In-1 Foldable Wireless Charging Stand, USB-C Cable, User Manual

Diagram




Charging Status LED Indicator Light Color

Status	LED Indicator
Connected to power	Blue for 3 seconds, then off
Charging your phone	Blue
Metal objects detected in phone charge area	Flashing Blue
Charging your earbuds	Blue
Metal objects detected in earbuds charge area	Flashing Blue
Charging your watch	Blue
Metal objects detected in watch charge area	Flashing Blue

Important Safety Instructions

1. Read all instructions and warnings prior to using this product. Improper use of this product may result in product damage, excess heat, toxic fumes, fire or explosion.
1. Avoid dropping.
2. Do not disassemble.
3. Do not expose to liquids.
4. This product is suitable for moderate climates only.
5. The maximum ambient temperature during use of this product must not exceed 45°C.
6. Open flame sources, such as candles, must not be placed on this product.
7. Only use a dry cloth or brush to clean this product.
8. To reduce the risk of injury, close supervision is necessary when the product is used near children.
9. Do not put fingers or hands into the product.
10. Do not expose to rain or snow.

11. Do not use in excess of its output rating. Overload outputs above rating may result in a risk of fire or injury to persons.
12. Do not use if damaged or modified. Damaged may exhibit unpredictable behavior resulting in fire, explosion, or risk of injury.
13. Do not expose to fire or excessive temperature. Exposure to fire or temperatures above 100°C may cause explosion.
14. Switch off the charger when not in use.



Notice

1. Connect the wireless charger to a Quick Charge 2.0/3.0 or Power Delivery wall adapter. Do not connect to a 5V/1A wall charger or a USB port on a computer as it may affect the wireless charging function.
2. Do not place any foreign objects between your device and the wireless charger's surface, including metal pads on a car mount, magnetic cards, door keys, coins, NFC cards or other metal objects, as they could potentially demagnetize the wireless charger, affect the charging speed, or cause overheating.
3. Wireless chargers make charging more convenient than wired chargers, but confined by current wireless technology, their charging speed.