



Warning

Do not keep the device too low or too high (below 0C or above 40C) for long periods of time, extreme temperatures can cause the device to deform, reduce the charging capacity of the device, and shorten the life of the device.
 Do not use this device in thanderstorms, which can cause

How to charge the charging compartment and



294 504 794 1004

Power on: open the charging computations cover, the headset will turn on automatically (the headset reach is be powered on), of a long press the cohole and for 3 cossion half powersat's precost (fishing blue light) when it is off; Power offit in the power on state, pat the headset into the charging position of the charging computations and close the cover with the blue light fishing, the shall down or press the touch area for 5 seconds to shart down.

Charging the cell phone by the charging compartment

This product has the function of power bank. Ceensect the charging compartment with the mobile phone according to the figure below to charge the mobile phone





How to connect TWS headset with mobile plane (and the plane) and the plane (and the plane) and t

Pairing mode of left and right earphones

arameter			
Product name	SM-01	Version	V5.0
Headset battery capacity	Stanti	Working bown	581
Steadby time	20001	Earpheae weight	43g
Output current and vallage	500mA/5V	Product size	22*22*10
Battery capacity of charging chamber	2500uswH	Work area	1556
Ellurtooth protocols	HFP1.7 HSP1.2 A2DP1.3 AVRCP1.6 SPP		

Serial number	Questions	Solutions	
1	Left and right herdphones can't listen to music at the same time	See left and right headphone pairing t details	
2	Heodphones don't charge	Check that the bendphones are in place	
3	Hendset comes be connected to mobile phone	Delete the associated \$36-01 device on phone and reconnect	
4	Occasional signal interruption	External interference	
5	There is noise in the cell	Change location or close the distance between headset and sound source equipment	
-6	Bod signal, noisy	Please place the mobile phase on the so side of the host or away from extense interference signals	
7	The besdeet has an echo	Adjust the volume or change the plac	

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.