

# WIRELESS SPEAKER DIFFUSER INSTRUCTION MANUAL

## DO NOT PRINT THIS LAYER


PRINT BACK TO BACK

PAIRING NAME: "SPEAKER DIFFUSER"

Dieline

Scoring Lines

## FOLDING INSTRUCTIONS



**ZEN ROX**  
Wireless Speaker Diffuser  
INSTRUCTION MANUAL

**Bluetooth®**

**FC** **BC**

**Using the Aromatherapy Fan**  
1. Add 1-2 drops of essential oil to one of the supplied scent pads. Rub the pad and let the oil permeate.  
2. Remove the fan cover from the speaker and carefully place the sponge onto the platform.  
3. Replace the cover and power the fan ON. The speaker will emit the aroma of the essential oil.  
**Note:** Quality of aroma can differ based on the amount of essential oil used, the brand of essential oil, and the environment (temperature, humidity, wind conditions, etc.)

**Bluetooth Pairing**  
1. Power the speaker ON. A tone will be heard and the Bluetooth LED indicator will quickly flash blue.  
2. Set your mobile device to search for Bluetooth devices. When it appears, select "Speaker Diffuser" from the list of found devices.  
3. Once successfully paired, a tone will be heard and the Bluetooth LED indicator will turn **Slowly Flash Blue**.  
When power ON, the speaker will automatically reconnect to the device it was most recently paired to, so long as that device is enabled.

**Playing Music**  
To listen to music on your speaker, make sure it is paired to a Bluetooth-enabled device. For more on pairing the speaker to your device, please consult the **Bluetooth Pairing** section of this instruction manual.  
Once paired, you can control media playback and volume adjustment with the control on your paired device.

**Package Includes:**  
Wireless Speaker Diffuser (x1)  
Charging Cable (x1)  
Scent Pad (x3)  
User Manual (x1)

**LOCATION OF CONTROLS**

**LED INDICATOR**

- Quick Flashing BLUE: Speaker is ready to pair
- Slowly Flashing BLUE: Speaker is paired
- Solid RED: Speaker is charging

**FCC STATEMENT**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
• Reorient or relocate the receiving antenna.  
• Increase the separation between the equipment and receiver.  
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
• Consult the dealer or an experienced radio/TV technician for help.  
**Caution:** Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.  
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

**Charging the Speaker**  
Attach the small connector to the supplied micro-USB cable to the USB port on the back of the speaker. Attach the large connector to the USB port on a computer, a USB charging device, or a 5V USB adapter (not included) and plug into an electrical outlet. The charging LED indicator will turn red while charging and turn off when fully charged. When low on power, a tone will be heard, indicating that the speaker should be charged.

**Using the Speaker**  
• Slide the (Power) switch to middle position to power the speaker ON. Slide to the left to Power the speaker and lights ON.  
• Slide the (Power) switch to the right position to power the speaker and lights OFF.  
• Slide the (Fan) switch to the right position to power the fan ON. Slide to the left position to Power the fan OFF.

© 2020 Zeikos, Inc. iHip is a trademark of Zeikos, Inc. Registered in the U.S. and other countries. The illustrated product and specifications may differ slightly from that supplied. All other trademarks and trade names are those of their respective owners. United States and international patent pending. All Rights Reserved. For ages 12+ up. This is not a toy. Designed by iHip. Manufactured in China.  
The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by iHip is under license. Other trademarks and trade names are those of their respective owners.  
Limited One Time Warranty.  
To activate your product warranty go to our website, [www.iHip.com](http://www.iHip.com) & register this product.

**iHip** 19 Progress St  
Edison, NJ 08820  
[www.iHip.com](http://www.iHip.com)

**#iHip**

**Find us on Facebook.**  
Keyword: iHip Portable Entertainment