


<Photographs of EUT>

Refer to the EUT external photographs.

<Antenna Location>



The separation distance for antenna to edge:

Shenzhen UnionTrust Quality and Technology Co., Ltd.

Address: Unit D/E of 9/F and 16/F, Block A, Building 6, Baoneng science and technology park, Longhua district, Shenzhen, China
Tel: +86-755-28230888 Fax: +86-755-28230886 E-mail: info@uttlab.com <http://www.uttlab.com>
UTTR-SAR-IEEE Std 1528-2013-V1.0_Appendix D

Exposure Position	Separation Distance from the Antenna to the Outer Surface
Upper Front	<5 mm
Top	<5 mm
Upper Left	<5 mm
Upper Right	<5 mm
Upper Rear	>10 mm
Bottom	>190 mm

<Photographs of SAR Setup>



Upper Front Side of EUT with 0 cm Gap



Upper Rear Side of EUT with 0 cm Gap



Upper Left Side of EUT with 0 cm Gap



Upper Right Side of EUT with 0 cm Gap

Shenzhen UnionTrust Quality and Technology Co., Ltd.

Address: Unit D/E of 9/F and 16/F, Block A, Building 6, Baoneng science and technology park, Longhua district, Shenzhen, China
 Tel: +86-755-28230888 Fax: +86-755-28230886 E-mail: info@uttlab.com <http://www.uttlab.com>
 UTTR-SAR-IEEE Std 1528-2013-V1.0_Appendix D