

Enbrighten VIBE Spectrum Tape Lights – Manual – 85822

[Insert Thank you for your purchase info]

Overview

1. This product is our company's latest design product. It adopts the control method of infrared remote control plus WiFi graffiti.
2. It can quickly and conveniently realize full-color adjustment and brightness adjustment, and can meet the application needs of our customers.

INSTALLING BATTERY (REMOTE)

1. Simultaneously push in the tab as you pull out the battery drawer.
2. Place a new CR2025 battery in the drawer with (+) side of the battery facing up (see diagram on back of remote).
3. Push the battery drawer into the remote until it snaps into place.

TEST YOUR TAPE LIGHTS

Test your tape lights before you begin installation.

1. Fully extend the tape light.
2. Connect the power adapter to a 120VAC 60Hz wall outlet.
3. Press the ON/OFF button on the in-line controller to ensure tape lights work properly.

CAUTION: Do not plug in the tape light until it is removed from the reel and fully extended, as it can get hot and damage the product.

SETUP

Remotely operate your smart tape lights with the easy-to-use Enbrighten app. Follow the available instructions and resources to set up your smart device.

[Insert standard 4-square design with the following text]

Download the app

Scan the QR code or search Enbrighten on the Apple App Store or on Google Play

Setup and installation

1. Create an account in the Enbrighten app
2. Assemble the smart tape lights according to the provided instructions

Setup and installation

3. Plug the smart tape lights into a wall outlet
4. Add devices, control the tape lights from anywhere and create schedules

Voice control

Voice control works with Amazon Alexa or Google Assistant

Select "Support" in the Enbrighten app or follow the steps in the Amazon Alexa or Google Home app to connect your Enbrighten account

INSIDE THE BOX

[Images of each item with corresponding letter and text shown below. Be sure to point out programming button on power cord, as well.]

- A. RGBIC LED tape lights (10ft.) x1
- B. Power adapter with 5ft. cord, pairing button and mic for MusicSync
- C. IR remote control with CR2025 battery

INSTALLATION

- **CAUTION:** Do not connect the power supply while installing the tape lights.

1. Determine the best placement for your tape lights, making sure to adhere to the following:
 - Remove any nails, metal or other conductive objects from the installation surface before attaching tape lights, as it could cause the lights to short circuit.
 - Do not stick the tape lights to a glass surface.
 - Avoid installing lights near heat sources or potentially dangerous sources, such as sharp objects, candles, liquids, corrosive chemicals, etc.
 - Select a location within reach of the nearest wall outlet.
2. Clean the mounting surface.
3. Connect the tape lights to the in-line controller.
4. Remove the adhesive backing from the back of the tape lights, then firmly press the tape lights onto a flat surface.
5. Avoid bending the tape lights where the LEDs and circuits are located, as it could cause damage. If bending the tape lights is required for your chosen location, bend the lights in a loose loop (see Fig. 1).
6. Connect the power adapter to the in-line controller and plug it into a 120VAC 60Hz wall outlet.

MANUAL OPERATION

ON: Press the button once.

OFF: Press the button twice.

Change-color mode: Press and release the button to advance through a variety of preset color combinations and effects. Additional options are available through the Enbrighten app.

Pairing mode: Press button for 10 seconds for app pairing mode.

REMOTE CONTROL OPERATION

The remote control uses infrared (IR) technology to communicate with the tape lights. When using the remote control, point it at the tape lights' IR receiver on the in-line controller, making sure there are no obstructions in the signal path.

Use the included IR remote to cycle through the various modes, adjust brightness settings and more. Avoid any extra IR interference by pointing the remote at the in-controller.

[Insert image of remote with the following button callouts]



1. ON/OFF: Press to activate or deactivate lights
2. White Select: Press to select warm white (3000K) or cool white (4000K)
3. Modes: Press to change modes
4. Directional Modes: Press to change direction of active mode
5. MusicSync: Press for lights to react to sound
6. Single Color: Press repeatedly to advance through color options
7. Multicolor Modes: Press to select preset multicolor modes
8. Set Mode: Press and hold to enter SET mode.
9. Increase/Decrease:
 - a. In static mode, press to adjust brightness level of single color
 - b. In dynamic mode, press to adjust light speed
 - c. In SET mode, press to increase or decrease the number of ICs

WiFi CONTROL OPERATION

1. First connection: Long press button to enter the network configuration mode, click button to switching mode, connect the power controller and light strip, the light flashes and enters the network distribution mode, open the Tuya app.
2. Automatically identify devices and add them. You can confirm whether to add the device by clicking the Add option.
3. Add a device Enter the WiFi name and password to connect to the device and proceed to the next step (WIFI can only use 2.4g, other devices may not be recognized and may not be connected).
4. Enter the WiFi name and password to directly proceed to the next step of adding the device, wait a few seconds and then add it successfully.
5. After adding successfully, click Finish to proceed to the next step.
6. After clicking Finish, you can adjust the color, brightness, dynamic mode, dynamic mode speed and timing function of the light strip according to your direct preferences.

TROUBLESHOOTING

PROBLEM	CORRECTIVE ACTION
Cannot pair to the Enbrighten app	<ul style="list-style-type: none">• Confirm the tape lights are powered.• Enable Bluetooth on your smartphone.• Position the tape lights and smartphone within 6ft. of the Wi-Fi router.• Ensure your smartphone is connected to a 2.4GHz Wi-Fi network – 5GHz not supported.• Verify your Wi-Fi network name and password.• Try manual setup mode – see app for details.
Device offline	<ul style="list-style-type: none">• Confirm the tape lights are powered.• Verify your Wi-Fi is working.• Remove the tape lights from the app and pair it again.
Remote not working	<ul style="list-style-type: none">• Battery may be installed incorrectly. Reinstall battery.• Battery may need to be replaced. Install new CR2025 battery.

REMOTE CONTROL

Functional range*: Up to _____ [Max distance at which remote will work the lights]

Battery type: CR2025 (included)

*Functional range may be adversely affected by one or more of the following factors: radio frequency interference, low battery level and obstructions between the remote control and receiver.

[Insert black box warnings with the following]

WARNING

RISK OF ELECTRIC SHOCK

- DO NOT SUBMERSE
- DO NOT USE AROUND AQUARIUMS
- DO NOT USE IN WET LOCATIONS
- FOR ADULT USE ONLY
- BE CAUTIOUS OF STATIC ELECTRICITY DURING INSTALLATION AND USE

RISK OF FIRE

- NOT INTENDED FOR USE NEAR OPEN FLAMES OR ABOVE STOVES, COOKTOPS, SINKS OR OTHER HEAT-PRODUCING APPLIANCES, SUCH AS COFFEE MAKERS, TOASTERS OR TOASTER OVENS
- USE INDOORS ONLY
- TURN OFF THE POWER AND UNPLUG THE ADAPTER WHEN TAPE LIGHTS WILL NOT BE USED FOR A LONG TIME

WARNING

- DO NOT MIX OLD AND NEW BATTERIES
- DO NOT MIX ALKALINE STANDARD (CARBON-ZINC) OR RECHARGEABLE (NICKEL-CADMIUM) BATTERIES
- DO NOT USE IN WET LOCATIONS
- BATTERY MAY LEAK HARMFUL LIQUIDS OR IGNITABLE MATERIALS OR EXPLODE, CAUSING INJURY OR PRODUCT DAMAGE
- REPLACE FULLY DISCHARGED BATTERY IMMEDIATELY
- REMOVE BATTERY IF PRODUCT IS TO BE UNUSED FOR EXTENDED PERIOD
- STORE INDOORS WHEN NOT IN USE

WARNING

- **INGESTION HAZARD:** This product contains a button cell or coin battery.
- **DEATH** or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause **Internal Chemical Burns** in as little as **2 hours**.
- **KEEP** new and used batteries **OUT OF REACH of CHILDREN**.
- **Seek immediate medical attention** if a battery is suspected to be swallowed or inserted inside any part of the body.
- LITHIUM COIN CELL BATTERY #CR2025
- 3 VOLTS
- Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate.
- Even used batteries may cause severe injury or death.
- Call a local poison control center for treatment information.
- Non-rechargeable batteries are not to be recharged.
- Do not force discharge, recharge, disassemble, heat above [60° C or 140° F] or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.
- Ensure the battery is installed correctly according to polarity (+ and -).
- Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the battery and keep it away from children.

WARRANTY INFORMATION

IMPORTANT – PLEASE READ

Refer to the manual or visit www.enbrightenme.com/warranty for limitations and restrictions on warranties and the product registration information.

This Jasco product has a limited-lifetime replacement warranty. Please contact our U.S.-based Consumer Care at 1-800-225-0653, M-F, or www.enbrightenme.com/warranty if the unit should prove defective within the warranty period.

FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. In order to avoid the possibility of exceeding the FCC radio frequency exposure limits, Human proximity to the antenna shall not be less than 20cm(8 inches)during normal operation.

That changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

CAN ICES-3(B)/NMB-3(B)

App Store is a service mark of Apple Inc.

Google, Google Play and Google Home are trademarks of Google LLC.

Amazon, Alexa and all related logos are trademarks of Amazon.com, Inc. or its affiliates.

MADE IN CHINA

Distributed by Jasco Products Company LLC,

10 E. Memorial Rd., Oklahoma City, OK 73114.

This Jasco product has a limited-lifetime warranty. Visit www.enbrightenme.com/warranty for warranty details.

Questions? Contact our U.S.-based Consumer Care at 1-800-225-0653, M-F.

[Insert new patent statement, cETLus and any required specifications per engineer - waiting until final ETL file is published.]