

Model No.: MHZ2188

MONSTER

BLUETOOTH HEADPHONE

OPEN EAR AC311

快速指南 / Quick Start Guide / クイックスタートガイド

请仔细阅读本快速指南并妥善保存以备将来使用。
本产品由中国平安网络公司承保
Please read this Quick Start Guide carefully and keep it for future use.
このクイックスタートガイドををよくお読みの上、将来のために大切に保管してください。

产品概述

*耳机x 2 (左&右)
*充电仓
*USB-C充电线
*快速指南与保修单

123

45

67

1. LED指示灯
2. 多功能触控键 (MFB)
3. MIC 孔
4. 发声位置
5. 充电触点
6. USB-C充电接口
7. 充电盒指示灯

充电

请在使用此设备前先给耳机和充电仓充满电，此设备可以通过Type-C USB接口进行充电。

Type-C 接口处

电源开、关

打开充电盒盖，拿出两只耳机，将自动开机。想要关闭耳机，请将耳机放入充电盒，耳机关机同时进行充电。

配对

打开充电盒，拿出两只耳机，它将自动开机。待几秒钟后左、右耳机自动连接上，之后您可以听到 "Pairing" 语音提示。对于新设备连接，请打开蓝牙设备并搜索 "Monster OPEN EAR AC311" 进行连接。配对成功后，您会听到 "Connected"语音提示。
如果耳机之前已配对过，开机就会尝试连接上一次的设备。

佩戴

拿出耳机，将Monster OPEN EAR AC311 顺着耳后佩戴，并轻轻旋转至舒适位置，以确保获得最佳的佩戴效果和音质体验。

1

2

3

4

按键操作

L/R

x1

L/R

2s

L/R

2s

L/R

x1

L

x3

R

x3

R

x2

L

x2

恢复出厂设置
开机状态下连续6击耳机触控键（左右耳机皆可），耳机将自动关机，恢复出厂设置。

更多操作

接听	单击左或右耳
挂断	单击左或右耳
拒接	长按MFB 2秒
LED 指示灯（耳机）	
配对模式	主耳红白灯交替闪；副耳不亮灯
耳机连接后待机	主副耳不亮灯
充电中	白灯亮
充满	关
电量低	红灯每5s 闪1下
LED 指示灯（充电盒）	
充电中	红灯慢闪
充满	红灯长亮
电量低	白灯慢闪

注意

*不建议未经许可私下更换电池。
*电池(电池组或电池组合)不得暴露在照明,烘烤或类似过热的环境中。
*耳机充电仓在外接电源充电时,输入电压电流标准≤ 5V/1A;

封面

Product Overview

Earphone x 2 (left & right)
Charging Case
USB-C Charging Cable
Quick Start Guide and Warranty Letter

123

45

67

1. LED Indicator
2. Multi-function touch button (MFB)
3. MIC hole
4. Vocal position
5. Charging contact
6. USB-C charging port
7. Charging case indicator light

Charging case charging

Use the USB-C charging cable provided with the product to charge, and the charging case indicator shows the charging status. When the charging case is fully charged, the charging case indicator lights up.

Type-C Port

Power On/Off

When taken out of the charging case, the earphones will turn on and pair with each other automatically. To turn off the earphones, put them in the charging case, then the earphones will be turned off and start charging.

Pairing

The earphones will turn on and pair with each other automatically when taken out of the charging case. A "pairing" voice prompt will be heard after they pair successfully.
For new device connection, turn on the Bluetooth in your device and choose "Monster OPEN EAR AC311" from the

Bluetooth list to connect. You will hear "connected" after the earphones are paired to the device.
If the earphones have been paired before, they will connect to the last paired device automatically after being turned on.

Wearing

Put the **Monster Open Ear AC311** onto your ears and rotate to fit comfortably to get the best wearing and sound quality experience.

1

2

3

4

Key operation

L/R

x1

L/R

2s

L/R

2s

L/R

x1

L

x3

R

x3

R

x2

L

x2

Factory reset
When the earphones are not removed in the case, after opening the cover of the charging case, long press the button on the back of the bin to 5S to clear the pairing record of the earphones and mobile phones, and the earphones will automatically enter the device search and pairing mode (the two earphone will automatically team up). If the new devices are not connected within 3 minutes, the earphones will automatically shut down.

Additional Operation

Answer call	Press L or R once
End call	Press L or R once
Reject call	Press MFB 2seconds
LED indicator (earphone)	
Pairing	Red-White flash
Standby	LED off
Charging	White off
Fully charged	Red off
Low battery	The red light flashes every 5 seconds.
LED indicator (charging case)	
Charging	Red light blinks slowly
Fully charged	The red light keeps on.
Low battery	White light blinks slowly

Attention

*Private replacement of batteries without permission is not recommended.
*Batteries [battery packs or battery combinations] should not be exposed to lighting, baking or similar overheating environments.
*The input voltage and current standard ≤ 5V/1A when charging the headset charging compartment from an external power source;

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.
FCC ID: 2AVD2-MHZ2188

パッケージ内容

*イヤホン x 2 (左&右)
*充電ケース
* USB-C充電ケーブル
* 日本語説明書/保証カード

123

45

67

1. LED指示灯
2. 多機能タッチ式操作ボタン (MFB)
3. MIC穴
4. 発声口
5. 充電接続点
6. USB-C充電口
7. 充電ケース指示灯

充電

初めて利用の準備、イヤホンや充電ケースをフル充電してからご利用ください。

Type-C充電口

電源オン/オフ

充電ケースからイヤホンを取り出すと、起動します。充電ケースにイヤホンを入れると自動オフ、イヤホンに充電します。

ペアリング

充電ケースの蓋を開けてイヤホンを取り出すと、自動的に電源が入って検索できるようになります。"pairing"の提示音が鳴ります。新しいデバイスに接続するには、bluetoothをオンにして「**Monster OPEN ERE AC311**」を検索してペアリングしてください。接続に成功すると、"connected"の提示音が鳴ります。
前回接続したデバイスに自動ペアリングする仕組みです。

つけ方

イヤホンを耳の上から掛けます。掛けてから位置を調整して、より良い使用体験を獲得しましょう。

1

2

3

4

操作一覧

L/R

x1

L/R

2s

L/R

2s

L/R

x1

L

x3

R

x3

R

x2

L

x2

リセット
イヤホンがオンで設備と接続していない状態で、右/左のイヤホンを素早く6回タッチして、自動オフしてリセットします。

操作および状態説明

受話	右/左のイヤホンを1回タッチします
終話	右/左のイヤホンを1回タッチします
着信拒否	右/左のイヤホンを2秒ほど長押しします
イヤホンのLED指示灯説明	
ペアリング	赤と白の指示灯が順次点滅します
ペアリング後の待機状態	指示灯が消えます
充電中	白い指示灯が光ります
フル充電	指示灯が消えます
電池残量が少ない	赤い指示灯が5秒ごとに1回点滅します
充電ケースのLED指示灯説明	
充電中	赤い指示灯が点滅します
フル充電	赤い指示灯が常時点灯します
電池残量が少ない	白い指示灯が点滅します

ご注意ください

電池を修理または交換することを禁止します。
電池を高温高湿の場所に置かないでください。
充電ケースが外部電源に接続して充電する時の入力電圧の規格は5V/1Aです。

75X95MM 105G双胶+1专1黑+骑马钉