


Model No: MH22228

MONSTER™


Clarity 200 ANC

QUICK START GUIDE
Please read this Quick Start Guide carefully and keep it for future use.

Product Overview




Charging
Before using the "Monster Clarity 200 ANC", please connect the USB-C cable to a power adapter to begin charging. Fully charge the earphones and the charging case before the first use.



Power On/Off
Open the cover of the charging case, the earphones will turn on automatically. If you want to turn off the earphones, please put the earphones into the charging case and close the cover, the earphones will power off and charge at the same time.


Pairing
Open the cover of the charging case, the earphones will turn on automatically.

Wearing
Put the "Monster Clarity 200 ANC" onto your ears and rotate to fit comfortably to get the best wearing and sound quality experience.



For new device connection, turn on the Bluetooth in your device and choose "Monster Clarity 200 ANC" from the Bluetooth list to connect. You will hear system prompts after the earphones are connected to the device. If the earphones have been connected before, they will connect to the last connected device automatically after being turned on.

MFB Operation



Additional Operation

Answer call	Press L or R twice
End call	Press L or R twice
Reject call	Press MFB on the left or right earphone for 2 seconds
Ambient sound	Press MFB on the right earphone for 2 seconds to switch music mode noise canceling/transparency mode and game mode.
LED indicator (earphone)	
Power on	White flashes
Power off	The orange light on 2s and then turn off
Pairing is successful	The white light on 1s and then turn off
Pairing timed out	The orange light on 2s and then turn off
Disconnect the phone	White flashes
Low battery	Orange light flashes slowly
LED indicator (charging case)	
Charging	The red light continues to flash slowly, and the red light is full and on
Discharge	When the charging case charges the earphones, the white light stays on and turns off when it is full
Low battery	When the earphone put into or take out the charging case, the red light on 1s and then turn off

Reset
In the power on state, press the MFB of the earphones 5 times (two earphones at the same time), and the earphones will automatically shut down to reset. Put the earphones in the charging case and then take them out, the earphones will turn on automatically, and enter the pairing mode.

Attention

- *Private replacement of batteries without permission is not recommended.
- *Batteries [battery packs or battery combinations] should not be exposed to lighting, baking or similar overheating environments.
- *The input voltage and current standard ≤ 5V/1A when charging the headset charging compartment from an external power source;

FCC ID:2AVD2-MH22228


Model No: MH22228

MONSTER™


Clarity 200 ANC

快速指南
请仔细阅读快速指南并妥善保存以备将来使用
本产品由中国平安保险公司承保


产品概述



充电
请在使用此设备前先给耳机和充电盒充满电, 此设备可以通过USB-C接口进行充电。




佩戴
拿出耳机, 将 "Monster Clarity 200 ANC" 放入耳中, 并轻轻旋转至舒适位置, 以确保获得最佳的佩戴效果和音质体验。




电源开、关
打开充电盒盖, 耳机将自动开机。如果想要关闭耳机, 请将耳机放入充电盒, 耳机会关机同时进行充电。

配对
打开充电盒, 耳机将自动开机。对于新设备连接, 请打开蓝牙设备并搜索 "Monster Clarity 200 ANC" 进行连接, 配对成功后, 您会听到系统提示音。
如果耳机之前已配对过, 开机就会尝试连接上一次的设备。

佩戴拿出耳机, 将 "Monster Clarity 200 ANC" 放入耳中, 并轻轻旋转至舒适位置, 以确保获得最佳的佩戴效果和音质体验。



按键操作



更多操作

接听	双击左或右耳
挂断	双击左或右耳
拒接	长按左或右耳MFB键2秒
环境音	长按右耳MFB键2秒切换音乐模式-降噪模式-通话模式-游戏模式
LED指示灯(耳机)	
开机	白灯快闪
关机	橙灯长亮2S熄灭
配对成功	白灯长亮1S熄灭
配对超时	橙灯长亮2S熄灭
断开手机连接	白灯快闪
低电提醒	橙灯慢闪
LED指示灯(充电盒)	
充电	红灯持续慢闪,充满红灯长亮
放电	仓位耳机充电时白灯长亮,充满熄灭
低电提醒	耳机每次出入仓,红灯亮1秒熄灭

恢复出厂设置
开机状态下连续5击耳机触控键(双耳同时), 耳机将自动关机, 恢复出厂设置。耳机放入充电盒再取出, 耳机重新开机, 进入配对模式。

注意

- *不建议未经许可私下更换电池。
- *电池[电池组或电池组合]不得暴露在照明, 烘烤或类似过热的环境中。
- *耳机充电仓在外接电源充电时, 输入电压电流标准≤ 5V/1A;

封面

75X95MM 105G双胶+4C+186C印刷+风琴折

FCC Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.