





正面

<p><b>Wireless Earphones</b></p>  <p>User Manual</p>	<p><b>Product specification</b></p> <p>Bluetooth version: 5.0 Battery input: DC 5V Earphone battery: 25mAh Charge case battery: 180mAh Working time: About 5-6 hours Sensitivity: 103±3dB Frequency: 20-20000Hz Profile support: HSP/HFP/A2DP/AVRCP</p> <p><b>Operation instructions</b></p> <p><b>Binary Function:</b> Single touch: Play/ Pause Answer/End a call Touch twice on L: Next song Touch twice on R: Previous song Touch 3 times on L: Vol + Touch 3 times on R: Vol - Touch 4 times on L/R: Switch music mode or game mode Touch and hold 2 sec: Wake up voice Assistant</p>  <p>① Charge Case ② Charge Case Indicator ③ Charging Port ④ Earphone Indicator ⑤ Touch Area ⑥ Earphone Charging Port</p> <p><b>Charge case</b> Working time: light flashes Full power: light remains on Charging time: about 1.5 hours</p> <p><b>Pairing for operating</b></p> <p>Step1: Open the lid of charge case or long touch earphones to turn them on, they will be automatically paired. After the pairing is successful, one earphone's LED will flash, and the other earphone's LED will not flash. Step2: At this point, open the mobile phone's Bluetooth to search earphones' Bluetooth name then connect with it.</p> <p><b>Turn on the earphone</b></p> <p>Method A: Touch and hold the area for 2 seconds. Method B: Open the lid of charge case, they will automatically power on, and enter automatic pairing.</p> <p><b>Turn off the earphone</b></p> <p>Method A: Touch and hold the area for 5 seconds. Method B: Put earphones into the charge case and close, they will automatically shut down and enter charging.</p> <p><b>When the earphones disconnected for 5 minutes, it will automatically turn off.</b></p> <p><b>Calling</b></p> <p>When connected with mobile phone, touch once any earphone to answer current call. Long touch for 2 seconds to reject the call. If you want to end the current call, touch once any earphone to stop.</p> <p><b>Warning:</b></p> <p>1. To ensure the battery life of the earphone, the earphones and the charge case should be charged once in a month. 2. When charging with charge case please use the 5V/1A charger. Please don't use the fast charger which over 5V, to avoid damage on the charge case.</p> <p><b>FAQ</b></p> <p><b>A. When the earphones can't be turned on</b></p> <p>Check if the earphone has power (after the charge case is connected to the USB, and the earphone is charged in the charge case for more than 1 hour).</p> <p><b>B. When the earphones have only one side sound or earphones can't pair successfully</b></p> <p>1. Make sure that both earphones are powered and can be turned on normally. 2. Touch 3 seconds to turn on the earphones or open the lid of charge case (when the charge case is powered) the earphone will power on voluntarily, then you can connect with the device.</p> <p><b>C. When the mobile phone cannot find the device</b></p> <p>Method A: Touch and hold the area for 2 seconds. 2. Check if the earphone is connected to other devices. 3. Change a clear area and reconnect it again.</p> <p><b>D. When the earphones is stuck or disconnect while talking or playing music</b></p> <p>1. The earphone is low on battery. 2. The distance between the mobile phone and the earphone is more than 10 meters. 3. There is large area of signal obstruction between the mobile phone and the earphone, such as a wall. 4. The left and right ears are not paired and synchronized, and need to be shut down and re-paired.</p> <p><b>Attention</b></p> <p>1. Please don't change the built-in battery by yourself. 2. Please don't put the headset under wet or rainy place.</p> <p><b>FCC Statement</b></p> <p>Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: - Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. - Consult the FCC OMB Circular 1790 (75 F.R. 28626, May 15, 1990). This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> <p>Made in China</p> 
--	--

反面

<p><b>无线立体声耳机</b></p>  <p>说明书</p>	<p><b>产品规格</b></p> <p>蓝牙版本: 5.0 电源输入: DC 5V 耳机电池容量: 25mAh 充电盒电池容量: 180mAh 音乐播放时间: 5-6小时 灵敏度: 103±3dB 频率范围: 20-20000Hz 支持协议: HSP/HFP/A2DP/AVRCP</p> <p><b>操作使用:</b></p> <p><b>双耳操作:</b> 单击: 播放/暂停 来电接听/挂断 触碰2次左耳: 上一曲 触碰2次右耳: 下一曲 触碰3次左耳: 音量 + 触碰3次右耳: 音量 - 触碰4次左/右耳: 切换音乐模式或游戏模式 长按2秒左/右耳: 激活语音助手</p>  <p>① 充电盒 ② 充电盒指示灯 ③ 充电盒充电口 ④ 耳机指示灯 ⑤ 触控区 ⑥ 耳机充电触点</p> <p><b>充电盒</b> 充电盒充电时: 充电盒指示灯亮 充电盒满电: 充电盒指示灯长亮 充电时间: 1-1.5小时</p> <p><b>注意事项:</b></p> <p>1. 为保证电池寿命建议每个月份耳机进行充电。 2. 充电时, 推荐使用5V/1A的充电插头, 切勿使用输出电压大于5V的快充产品进行充电, 以免对充电盒造成损坏。</p> <p><b>耳机配对:</b></p> <p>第1步: 打开充电盒盖或长按开机, 耳机自动配对, 配对成功后一个耳机闪灯, 另一个耳机不闪灯。 第2步: 此时打开手机的蓝牙搜索蓝牙名称, 点击连接。</p> <p>※耳机再次连接同一个设备, 开盖可以自动开机, 自动与设备进行回连, 语音提醒“Connected”。</p> <p><b>开机:</b></p> <p>方法1: 长按3秒开机。 方法2: 打开充电盒盖自动开机, 然后耳机可以进行连接设备。</p> <p><b>关机:</b></p> <p>方法1: 长按5秒关机。 方法2: 将耳机直接放入充电盒, 耳机会自动关机并开始充电。</p> <p>※耳机不连接状态下5分钟内自动关机。</p> <p><b>通话:</b></p> <p>方法1: 耳机处于电量状态。 方法2: 将耳机直接放入充电盒, 耳机会自动关机并开始充电。</p> <p>※耳机与手机之间有大面积的信号遮挡物, 如墙体。 4. 左右耳没配对同步, 需关机后重新配对连接。</p> <p><b>常见问题</b></p> <p><b>1. 耳机无法开机</b></p> <p>检查耳机是否有电, 主要通过充电盒连接USB线后, 对耳机进行一个小时以上充电来判断。</p> <p><b>2. 耳机只有一边有声音或耳机无法配对成功</b></p> <p>1. 确认两个耳机是否有电且可以正常开机。 2. 长按3秒开机或打开充电盒盖自动开机, 然后耳机可以进行连接设备。</p> <p><b>3. 耳机无法识别蓝牙设备</b></p> <p>1. 确认两个耳机是否已经开机。 2. 检查耳机是否有连接到其它蓝牙设备。 3. 换一个空旷的区域, 重新开机后配对操作。</p> <p><b>注意事项:</b></p> <p>1. 请勿自行更换内置电池。 2. 请勿将耳机放在潮湿或多雨的地方。 3. 请勿对耳机端部靠近火源, 以避免电池遇火发生事故。 4. 非专业人士请勿拆卸耳机。</p>
---	---