

1. Photographs of Dynamic Frequency Selection Test Configuration

AP Router (Master) mode:

FRONT VIEW



CLOSE-UP VIEW



Slave mode (Slave without radar detection):

FRONT VIEW



CLOSE-UP VIEW



—THE END—