


# NFC SecureCard Manual (Ver. 1.2)


## Contents

1. Basic UI Configuration -----	2
2. Card Activation -----	3
3. Fingerprint Registration -----	4
4. Fingerprint Delete -----	6
5. Fingerprint Verification -----	8
6. Status LED Display -----	9
7. FCC Warning Satemen-----	10

# 1. Basic UI Configuration




## 2. Card Activation



- Insert SecureCard into the cradle
  - \* When SecureCard is recognized, the color of the Status Display Window changes and status notice is displayed.
  - \* Information on operation steps are displayed in Information Display Window.
  - \* Up to 3 user fingerprints can be registered in SecureCard.
  - \* The fingerprint registration status can be monitored in Fingerprint Enrollment Window.
  - \* Only selectable buttons are enabled.

### 3. Fingerprint Registration




- Click enabled [**Enroll**] button to enroll user fingerprint in SecureCard.

- SecureCard waits for user to scan fingerprint. [User needs to scan fingerprint 8 times.](#)

- When fingerprint is scanned image is displayed and scanning status is displayed.

### 3. Fingerprint Registration




- When fingerprint is scanned 8 times, a window pops up to input user name.

- When fingerprint is enrolled successfully, Enrolled username appears under fingerprint icon.

- Above image shows 3 fingerprints are enrolled.


## 4. Fingerprint Delete



- Click enabled **[Delete]** button to delete enrolled fingerprint in SecureCard.


- SecureCard waits for user to scan fingerprint. User can scan up to 10 times.

## 4. Fingerprint Delete



- When a fingerprint is scanned, the name of the matched fingerprint is displayed in Fingerprint Enrollment Window.
- The matched fingerprint is deleted.

## 5. Fingerprint Verification



- Click enabled **[Verify]** button to wait for fingerprint scan.
- SecureCard waits for user to scan fingerprint. User can scan up to 10 times.
- When a fingerprint is scanned, the name of the matched fingerprint is displayed in Fingerprint Enrollment Window.

# 6. Status LED Display

## 1. When cradle is connected




	On	Off
Green	Power On	Power Off
Blue	Under USB communication with PC	No USB communication
Red	Charging*	NA

\* Charging time : Battery is completely charged with 3 hour charging

- Cradle is connected to PC through USB Cable.
- Insert SecureCard such that the fingerprint sensor on SecureCard and Insertion Mark on Cradle (marked with red circle) are on the same side.

## 6. Status LED Display

2. When cradle is not connected



	<b>On</b>	<b>Off</b>
Green	Power On	Power Off
Blue	Fingerprint Match Success	N/A
Red	Fingerprint Match Failure	N/A

## 7. FCC Warning Statement

### FCC Part 15.19

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### FCC Part 15.21

Any changes or modifications (including the antennas) to this device that are not expressly approved by the manufacturer may void the user's authority to operate the equipment.