

Wireless Device User's Guide

1. Remote control wireless adjustment

- ① The adjustment switch on the back of the product must be in the MODE position to enable remote operation.
- ② If the switch is in the ON position, remote control will not operate

2. The power used is (Battery) DC 12 V, 27 A.

3. This wireless device enables open sign product on/off operation and blinking function. This wireless device is only available for open sign products.

4. Precautions for Use

- ① Use power should only be used with products that meet the specifications. (This can cause failure or product failure when using products that do not meet specifications.)
- ② This product is complete and cannot be dismantled or modified
- ③ Damage and failure caused by arbitrary disassembly or careless handling shall be notified even during the A/S period.

5. Product Specifications

Power Operation: DC 12V

Rated RF Power Output : 11 mW

Operation Frequency: 315 MHz

6. A/S and Exchange Contact:

2111 7th Ave, Seattle, WA 98121 United States

Customer Service Phone Support

- US & Canada : 1-866-216-1072 - Global : 1-206-266-2992

FCC ID : 2AVQT-RF-OPEN01KM