

操作手順	
Bluetoothペアリング	Bluetoothペアリング
デバイスの設定	デバイスの設定
ファームウェアの更新	ファームウェアの更新
音楽のダウンロード	音楽のダウンロード
充電方法	充電方法
低電力	低電力

## Quick Start Guide

Galerdo Beker Pro is an AI Enabled Tracker and Voice Coaching device for swimmers.



For a complete User Manual, please visit the link <https://www.galerdo.net/support>

### For initial setup, follow the steps below:

#### Step 1: Charging

Please check the "How to charge the device" description.

#### Step 2: Installing the Galerdo App

For iPhone users:

go to App Store and search for "Galerdo". Click install.

For Android users:

go to Google Play store and search for "Galerdo". Click to install.

#### Step 3: Log in to the Galerdo App and Register Your Account

The Galerdo App provides 3 options for you to log in:

- (1) Your phone number
- (2) Your Facebook account
- (3) Your WeChat account

You can use any of the options above to register. Simply follow the option specific instructions to register your new account.

#### Step 4: Power Up Galerdo Beker Pro

Press the power button for 2 seconds and you will hear a "Power On" voice notification.

Turn on the device and it will enter standby mode. At the same time, the device will activate Bluetooth so you can use your Galerdo App to pair. Please note that when you are in standby mode, you will not be able to play any music or use any voice feedback features. Do not start swimming when you are in standby mode because you will not be able to use any feature. You also will not be able to track any swimming data.


#### Step 5: Pairing Bluetooth

When Beker Pro is in standby mode and Bluetooth has been activated, you can log in to the App, and do the following:

1. Click on the "My" logo
2. Click on "Add a Device"
3. You will see "Beker Pro" listed in the search results
4. Select "Beker Pro" and start pairing Bluetooth

#### Charging Your Beker Pro

There are 3 options for you to charge your Beker Pro:




#### Step 6: Upgrading Firmware

After you have successfully paired your Beker Pro with the Galerdo App, click on "My". You should now see "Beker Pro" listed under the "My Device" title. Click on "BekerPro" and in the new window, click on "Firmware Version". Upgrade to the new firmware version if there is one, otherwise go directly to Step 7.

#### Step 7: Preset Swimming Pool Length

Log in to the Galerdo App and click on "My". Select "BekerPro". In the new window, click on "Length of swimming pool" and select the appropriate length. Please note that you must specify the correct length so the algorithm can accurately calculate your swimming distance. The default setting for length is 50 meters.



## Step 8: Setup Voice Notification

The default setup for voice notification is automatically enabled and the default language used is English. If you need to change the default settings, go to your "My Device" settings to change your language selection.

#### Step 9: Upload Your Own MP3 Music

Connect the Beker Pro to your PC or Mac. In your PC window, you will see Beker Pro is automatically detected as an external hard drive. You can then download your favorite music from your PC to Beker Pro. For best results, please upload MP3 files only. For MAC, you may need to enable the external drive to be detected.

#### Step 10: Start Your Swim

1. Press the power button for 2 seconds to turn on Beker Pro.
2. Place the device on the back of your head, under your swimming cap (Beker Pro logo face up).
3. Insert your ear plugs fully so that you can hear enough sound from the Beker Pro through the bone conduction feature.
4. Press the power button again and you will hear the countdown "3, 2, 1, Go." You will then hear the pre-loaded music confirming the data tracking has been activated.
5. You are now in swimming mode. You may begin swimming.

#### Step 11: Finishing Your Swim

1. After you have finished swimming, press the power button for 3 seconds.
2. You will hear voice feedback indicating your total swimming time and the distance you've swum.
3. The device will automatically go into standby mode. At the same time, Bluetooth will be activated and ready for you to pair with the Galerdo App.

#### Step 12: Synchronize Your Swimming Data

1. When Beker Pro is in standby mode, pair the Galerdo App through Bluetooth with your phone.
2. Open the Galerdo App and click on the "Sync" icon.
3. In the "Synchronization" window, click on "Data synchronization" to transfer your swimming data from Beker Pro to the Galerdo App.
4. After your data has been successfully transferred, Beker Pro will go into standby mode again.
5. Beker Pro will automatically turn off in 15 minutes if you have not performed any actions.

## Using Galerdo Beker Pro

### Swimming Mode

Adjust Volume		When in swimming mode, press the '+' button once and the volume will be increased by one level. Press the '-' button once and the volume will be decreased by one level. There are a total of 9 levels. The loudest is level 9. If you keep pressing when in levels 9 or 1 the device will produce a short beep sound.
Training Mode		If you turn the volume to the lowest level the music will stop playing. The data tracking mechanism and the voice feedback features will continue to work.

### Operating Procedure

Bluetooth Pairing		When in standby mode, the device will automatically activate Bluetooth. Now you can open the Galerdo App on your smartphone and start device pairing.
Setup Device		When in standby mode, the device will automatically activate Bluetooth. Now you can open the Galerdo App on your smartphone and setup voice assistance, voice notification language, swimming pool length, etc.
Upgrade Firmware		For best results, it is highly recommended that you wear ear plugs so that any music or sound quality will not be distorted when you take a breath while swimming.
Download Music		Turn on Bluetooth on your smartphone. Use the Galerdo App to connect to Beker Pro. Click on "My Settings". You should now see "Beker Pro" listed under the "My Device" title. Click on "Beker Pro" and in the new window, click on "Firmware Version". You can then select the "Firmware Version" feature to upgrade your firmware.
Charging Options		Default setup: Voice notification is enabled, voice notification language is English, and the swimming pool length is 50 meters.
Battery Low		Turn on Bluetooth on your smartphone. Use the Galerdo App to connect to Beker Pro. Click on "My Settings". You should now see "Beker Pro" listed under the "My Device" title. Click on "Beker Pro" and in the new window, click on "Firmware Version". You can then select the "Firmware Version" feature to upgrade your firmware.

### Button Functions



### General Functionality

#### Turn On, Standby Mode, Turn Off

Turn On		When Beker Pro is off, press the power button (A) for 2 seconds. The blue led light will turn on and the "Power On" voice notification will start to play. The device is now turned on and will go into standby mode.
Turn Off		When Beker Pro is in standby mode, press the power button (A) for 2 seconds. The red led light will turn on and start to play a "Power Off" voice notification. Beker Pro is now turned off.
Standby		<ul style="list-style-type: none"> <li>When in standby mode, the blue led light will blink 3 times every 10 seconds. You can perform Bluetooth pairing while in standby mode.</li> <li>When in standby mode, the device will be automatically turned off if you have not performed any operations in 15 minutes.</li> </ul>

#### Swimming Mode

Start Swimming		When in standby mode, press the power button (A) to hear "3, 2, 1, GO" audio notification. You are in swimming mode and the music will start to play.
Finish Swimming		When in swimming mode, press the power button (A) for 2 seconds. You will hear a voice notification about your total swimming distance and total swimming time. Your swimming session is completed; the device will go into standby mode.
Check Status		When in swimming mode, press the power button (A) once. You will hear a voice notification about your current swimming distance and current swimming time. Swimming time definition: Accumulated total time from the time you push away from the wall, stroke time and open turn time, etc.
Change Music Play Mode		When in swimming mode, press the "Switch music" button (B) to change the play mode. Default mode is sequential play. Press once to jump to the next song. Press 2 times to jump to the previous song. Press 3 times to play from the first song. Press 2 seconds and the led light will blink 3 times. The play mode will now go into random play. When in random play mode, press 2 seconds and the led light will blink 2 times. The play mode will now be changed back to sequential again.

### Warning

12. This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions  
(1) this device may not cause harmful interference, and  
(2) this device must accept any interference received, including interference that may cause undesired operation.

### 12. FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### Limited Warranty

- We provide a 1 year warranty (from the original date of purchase) due to defects in material, workmanship, or primary functions.
- Conditions such as normal wear and tear, damage due to external force, subjective determination of sound quality, swimming data not 100% accurate, etc. are not covered under this warranty.
- When requesting warranty service, please provide detailed information such as a sales receipt and location of purchase. Consumer's rights, under certain jurisdictions, may not be restricted under this limited warranty. If not restricted by law, this warranty may not be transferred to others.

### GALERDO APP

The Galerdo App contains the following features:

1. Account Registration
2. Synchronized swimming data between the device and App
3. Bluetooth pairing
4. Device settings: Voice assistance, voice notification language & swimming pool length
5. OTA firmware upgrade
6. Personalized profile setting
7. App language setting

#### Download From

iOS: go to the App Store, search for "Galerdo" and download the App  
Android: go to the Google Play Store, search for "Galerdo" and download the App