


User Manual			
FLUID WIRELESS HEADPHONE	Tips:	FCC statement:	 WARNING:
 Package Contents: - 1 (One) RGB Wireless Headphones 5.98in. x 3in. x 7.28in. (15.2cm x 7.6cm x 18.5cm) - 1 (One) USB-C Charging Cable 5.9in.(15cm) - 1 (One) Instruction Manual	• Low Battery: LED light flashes red. • To Charge: 1. Insert the USB connector end of the included cable (see packing list) into the USB jack on the charger or USB port on the computer. 2. The indicator light will be red while charging. 3. When the headphone is fully charged, the indicator light will turn from red to blue. Please unplug your charger from the power source. 4. Please use a qualified charger to recharge your headphone, If not, it may result in damage or even explosion. 5. Repeated charging and discharging of the headphone will lead to decreased battery life over time, which is normal for rechargeable batteries. 6. You must charge the Bluetooth® Heaphone if it has not been used for more than 6 months. 	This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. NOTE This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the the following measures : • Reorient or relocate the receiving antenna. • Increase the separation between the equipment and receiver. • Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.	RF warning statement: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. FCC ID: 2AW5BMU01051 Distributed by 1616 Holdings, Inc. 701 Market Street, Suite 200 Philadelphia, PA 19106 Made in China Keep All Relevant Information For Future Reference 
Button Description:	Technical Specifications:	 WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  WARNING: This product can expose you to chemicals including Bisphenol A (BPA), which is known to the State of California to cause birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.  CAUTION: FOR YOUR SAFETY, the charging cable included with this item is intended for use with this product only.	
"⏻": ON/OFF/Pause/Play "+": Short press to increase volume / long press for Next song "-": Short press to decrease volume / long press for Previous song How To Use: • Power on: Press the key "⏻" 3 seconds when it is off. The blue LED light will turn on, and begin to alternate blue/red LED light. A voice will prompt "pairing", indicating the headphone is in pairing mode. • Pairing: Activate the Bluetooth® function on your phone within range and select "FLUID BT HEADPHONE " from the list shown. When the blue/red LED light stops flashing, it has paired successfully and you will hear " connected ". The blue LED will flash slowly when playing music. • Play/Pause: When it is playing, press the key "⏻" to pause, then press the key "⏻" again to play. • Volume up: Press "+" once to increase the volume. • Volume down: Press "-" once to decrease the volume. • Previous song: Hold down the "-" to play the previous song. • Next song: Hold down the "+" to play the next song. • Phone Call: Press "⏻" to answer/end a call. Double click the button "⏻" to redial. Press and hold "⏻" for about 1.5 seconds to reject an incoming call. • Power off: When the headphone is on standby or in operation, press the key "⏻" 3 seconds to shut down the headphone (voice prompt "power off "). • Switch RGB light mode: Triple click the button "⏻" to switch on/off RGB light.	• Model Number: MU01051 • RGB Light Up • Battery Capacity: 3.7 V / 200 mAh • Buttons: 3 (On/Off/Play,Volume Up/Next, Volume Down/Back) • Play Time: 3-4 hours • Charge Time: 2-3 hours • Frequency: 20Hz - 20kHz • Impedance: 32 ohms • Working Distance: 10 m • 3.5mm auxiliary jack (cable not included) • Operating temperature range: 0-45 °C • USB-C Cable Rating 1.0A Max FAQ: 1) Why can't I start my Bluetooth® headphone? Answer: Please ensure that the headphone is fully charged for your first use. 2) Why won't sound come out of the headphone? Answer: Check whether the playback device and the Bluetooth® headphone are successfully established. If the audio device is not properly connected, please reconnect. Please also adjust your mobile phone or Bluetooth® headphone volume to a suitable volume level. 3) Why can't I find this headphone in my Bluetooth® options? Answer: Make sure the Bluetooth® is in "visible mode". If no pairing occurs, the Bluetooth® function will automatically shut off. Please reopen Bluetooth® to "visible mode". If there is a program error, please reboot your phone, and if a program error is caused by your Bluetooth® headphone, please restart the headphone.		