

Cover

NM1274CB

Quick Installation Guide

AC1200 Dual Band Wi-Fi Router

Package content

NM1274CB x 1

Power Adapter x 1

Ethernet Cable x 1

Quick Installation Guide x 1

Ports and indicators

LAN PortPower PortWPS Button

WAN PortReset Button

1. Hardware connections

① Connect one end of an Ethernet cable to the WAN port of modem, or connect the broadband network port.

② Connect a computer to the LAN port using the Ethernet cable (optional).

③ Use the included power adapter to connect the power socket to a power outlet.

2. Wi-Fi connection

● Using SSID

Use the **SSID** and **Wireless Key** on the device label to connect wireless to the device. On your smartphone or notebook, find this **SSID**. Enter the Wireless Key to connect.

● Using WPS

Press the **WPS** button on the device and the WPS indicator will blink. Then press the **WPS** button on the client. If the WPS method fails, use the SSID and wireless key to set up a WiFi connection.

3. Configure on the Web

Configure the device on the web page according to the information on the device label.

Open a web browser, enter the IP address and **Login Password**, and then click **Login**.

“This device complies with relevant RF radiation exposure limits when positioned at least 20cm away from your body.”

The WLAN function for this device is restricted to indoor use only when operating in the 5150 to 5350 MHz frequency range.

User has the choice to give his product to a competent recycling organization or to the retailer when he buys a new electrical or electronic equipment.

4. LED Indicator Explanation

After the power is turned on, the LED indicator will be solid red (about 30 seconds), indicating that the router's system is starting. After the start is complete, the description of LED indicator's status is as follows.

State	Description
Solid Blue	The router is on-line.
Flashing Red	The router is off-line.
Flashing Blue	The device is being connected through WPS function.

5. Button Explanation

Name	Explanation
RESET	Hold down for more than 5 seconds and release to restore the factory settings.
WPS	Press the button for 1 to 5 seconds to build mesh network. Hold down the button more than 5 seconds and release it to use the WPS connect the device.

6. Environment

Operating Temperature	0°C~40°C
Storage Temperature	-40°C~70°C
Relative Humidity	10%~90% non-condensing
Storage Humidity	5%~95% non-condensing

Frequency band:

Wi-Fi(2.4GHz & 5GHz), Bluetooth 2.4GHz RF Frequency Range :

2402MHz~2480MHz

2412MHz~2472MHz

5150MHz~5250MHz, 5250MHz~5350MHz,

5470MHz~5725MHz, 5725MHz~5850MHz

FCC warning Statement :

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in

accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons.

110mm

95mm

Folding mode

Technical requirements:

1) Material: 80g Writing paper

2) Size: 95x110mm, Dimensional tolerances ±2mm

3) Printing: Black