


English

Instructions & Safety Warnings for product use.
Please observe all safety warnings. The Speaker Light with Warmer is not a toy, treat it as a piece of equipment.

To prevent damage or harm to those using this product and those around them, we ask that you observe all warnings.
Please exercise caution when using this product; it runs on a charged battery.
Follow all instructions properly for charging and disposing of this battery.



Labels in diagram: Internal Battery, LED Light, USB Type-C Port, LED Light On/Off Button, Speaker, Volume, Speaker On/Off Button/Multifunction Button, Microphone, LED Reading light.

Input Power: DC 5V 1.0A (USB charging system)
Charging Battery (built-in): Nickel-metal hydride rechargeable batteries 3.6V, 2000mAh
Charging Time: Up to 4 hours
Continuous Operating Time: Speaker—Approx. 12 hours
LED Light—Approx. 21 hours
Speaker size / quantity: 0.98 x 0.47inch / 2 PC
Maximum output power: 1 W + 1 W / 8 Ω
Connectivity: Bluetooth 5.2
Compatible profile: A2DP, AVRCP, HFP
Physical Range: Approx. 10 M (Connectivity distance may differ depending upon environment)
Specified Frequency band: 2.4 GHz band (2.402 GHz~2.480 GHz)
Dimensions / Body Weight: Approx. 73 x 1.4 x 10 / Approx. 70g
Material: Body: ABS, Arms: Silicon, Iron, & copper
Accessory: USB charging cable
Country of Origin: China


11

12

HOW TO CHARGE


Battery needs to be fully charged before use.

1. Insert provided USB end of charging cable plug into a power source: AC USB adapter, portable charger, or PC USB port.
Be sure power source is equal to or greater than 5 V 1.0A.
2. Insert the Type-C USB charging cable plug into the small port on the product.
Always fully insert USB charging cable into both power source and product when charging.
3. While charging, LED will flash pink then automatically turn off when fully charged. Remove cable once completely charged. Never overcharge battery.
After approximately 500 full charges, the battery life will slowly start to decline. Always store with a full charge, especially for long periods of time with no use. Nickel Batteries are not replaceable.
This product contains NiMH batteries, so please recycle and/or dispose of based on regional laws.



Device Pairing

Press the power button to turn on the power.

 **Bluetooth ON/OFF**

Press and hold the Multifunction button for more than 3 seconds, and the blue LED will blink to indicate that the device is ready for pairing with another Bluetooth device. Prior to pairing, please review the instruction manual.
Press and hold the Multifunction button again for more than 3 seconds to turn off the power.

[Name of device: Speaker Light]
You will hear a sound effect if the pairing is successful.
It will automatically connect to the last connected device from the next startup.
To connect with a different device, set to pairing mode again.







How to use speaker

1. To turn on, press & hold Speaker on/off button for 3 seconds. Surrounding light will light up blue when on.
2. To play & stop music, push the Speaker on/off button.
Use the +/- button to control volume.
3. To turn off, press & hold Speaker on/off button for 3 seconds.

13

14

<div><div>Bluetooth®</div><p>Communication distance between Bluetooth-equipped device and this device is approximately 10m. However, the communication distance may vary depending on the surrounding environment. Wireless communication with all Bluetooth-enabled devices is not guaranteed. For compatibility between this device and Bluetooth-compatible devices, please refer to the instruction manuals supplied with each Bluetooth-compatible device. The Bluetooth function of this product conforms to and has been certified by Japanese domestic standards and FCC standards (US standards). The use of the Bluetooth function may be restricted in some countries and regions. Please check the conditions such as laws and regulations of the country/region when using this product overseas. In the frequency band used by the Bluetooth function, in addition to home appliances, industrial, scientific, and medical devices, wireless stations that require a license, certain low-power wireless stations that do not require a license, and amateur wireless stations are operated. Make sure that no other wireless stations are operating nearby before using this product. In the event of an incident of radio interference between this product and other wireless stations, change the location where this product is used or stop the operation of the device (stop emitting radio waves) immediately. The Bluetooth® word mark and logo are registered trademarks and are owned by Bluetooth SIG, Inc. "SPICE CO., LTD." uses these marks and logos under license.</p></div>	19
20	20

<p>Since a nickel battery powers this product we have put together some useful information about the battery. Please read the below information.</p> <p>Q: My battery won't stop charging! The light indicating this product is charging does not shut off. I am not sure if the product is defective or not...</p> <p>A: Don't worry this product is not defective. To help the light on this product function normally please use & charge this product consecutively 2-3 times. The charging light should begin to operate normally.</p> <p>How to properly use and care for this product nickel battery Letting the battery die is one major cause of a shortened battery life</p> <p>"Letting the battery completely drain out before re-charging will enhance battery life, allowing this product to operate for longer later" is a common misconception and will actually shorten the lifespan of this product Nickel batteries, like the one in this product, are strong and have long run times, thus they run better and more efficiently when charged regularly.</p> <p>This product's on/off button will flash pink indicating when the battery life is low, around 25%. Please charge this product as soon as possible when the pink light begins flashing.</p> <p>Always store this product with a full charge, especially when not in use for an extended period of time such as six months or more.</p>	21
<div><div><p>During the summer the internal temperature of a car can easily rise about 158F or 70C, so please do not leave or store this product in hot car or similar temperature conditions</p></div><div><p>Be sure you store this product in a cool dry environment so it is ready to use when you need it! Ideal storage temperature 40F-100F. Use this product in temperatures between 40F-122F.</p></div><div><p>Always handle product with care. We know you know this, but this product is not a toy, so please do not throw. Discontinue use immediately if broken.</p></div><div><p>Intended for use by individuals 12+.</p></div><div><p>This product arms are flexible, please do not rotate/bend to either side beyond 180 degrees.</p></div><div><p>This product is perfect for humid climates, but not in the rain as it is not waterproof. Wipe product dry if it gets wet.</p></div></div>	22

<p>How to use with phone</p> <ol style="list-style-type: none">1. To answer an incoming call when listening to music, press the Multifunction button. To reject an incoming call press & hold the Multifunction button for 3 seconds.2. After answering a call, push the Multifunction button and you will hear the other person's voice on your phone speaker. Push the Multifunction button a second time and their voice will be projected on the Speaker Light speaker.3. To end a call, push & hold the Multifunction button for 3 seconds.4. Music will resume automatically after the end of a call.5. To completely turn off phone connection, push & hold the Multifunction button again for 3 seconds. <p>How to use LED Light</p> <ol style="list-style-type: none">1. To turn on LED Light, press & hold the LED Light button for 3 seconds and the light around the button will light up yellow and the LED lights will flash.2. Press the LED Light again and enjoy continuous light.3. To turn off, press & hold the LED Light button for 3 seconds.	<p>⚠ CAUTION if used incorrectly, there is risk of serious injury or death.</p> <ul style="list-style-type: none">• When using, if this product overheats, smokes or emits any strange smell immediately turn off product and discontinue use. If this happens while charging, disconnect USB charging cable at once.• Please do not modify or try to repair this product as this may result in electric shock or fire.• This product may stop working if dropped or exposed to high impact. Do not violently shake this product.• If this product malfunctions or is damaged, please discontinue use.• Please handle USB charging cable with care, avoid bending or twisting.• When unplugging USB charging cable, always pull gently while holding on to plug portion.• Always fully insert USB charging cable into both power source and product when charging. Once product is fully charged, disconnect USB charging cable immediately.• Do not connect or disconnect the USB connector with wet hands.• Disconnect the USB plug from the USB port when cleaning.• Do not shine lights directly into eyes or face as this may impair vision.• This product is not waterproof, so avoid using in rain or other wet environments. If product does get wet, wipe water away immediately.• Avoid handling product with dirty hands. If this product gets dirty, gently wipe clean with dry cloth.• Do not use while sleeping or in the bathtub.• Do not let those who cannot communicate if a problem occurs or those who are handicapped use this product.• Product is intended for individuals 12+.• Do not leave or store this product in car, near heat source, direct sunlight or any high temperature environment.
15	16

<p>⚠ WARNING if used incorrectly, there is risk of injury or physical damage.</p> <ul style="list-style-type: none">• This product is not a toy.• This product requires a power source equal to or greater than 5V 1.0A for charging.• Understand specs and warnings for AC USB adaptor, portable charger or PC USB port before pairing with this product.• Always disconnect USB charging cable prior to use.• Operation is not guaranteed for simultaneous use with other USB devices.• When battery is low, the LED Light on/off button will glow pink.• Avoid shining light at directly at others.• Light head arms are flexible and may be bent or rotated up to 180 degrees. Do not bend beyond this point.• Please stop use if any part of the product or cord becomes discolored, deformed or damaged.• Before turning on, make sure volume is low. Sudden loud sounds can impair hearing.• Protect ears & hearing by not listening at a high volume.• Respect others around you and do not use in prohibited areas like airplanes, medical facilities, waiting rooms, etc. as radio waves may interfere or have a negative impacts.• If user has a pacemaker or other medical device, please consult with a doctor before using.• Avoid using around another direct heat source.• When used in dry climates, user may experience higher than normal levels of static electricity in areas that contact this product. This is not a product malfunction.• Please stop use immediately and consult a doctor if any skin irregularities, rashes, irritations, etc form.• Please do not use with pets or other animals.• Best to avoid contact with sunscreen or lotions as this may dull or change product color.	<ul style="list-style-type: none">• Wipe off sweat.• Store in a cool dry place.• Color may fade or change due to friction or when used in direct sunlight for long periods of time. <p>⚠ DANGER DISPOSAL OF THE PRODUCT</p> <p>This product contains NiMH batteries, so please recycle and/or dispose of based on regional laws.</p>
17	18

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment