



<div><div>LED Wireless Charging Bluetooth Speaker</div><div>S300</div><div></div></div>	<div><div>Instructions for using the wireless charging speaker</div><div></div><div><div>Wireless charger use: plug in the charger to automatically turn on</div><div><div><div><div>1</div><div>Long press power short press light switch</div></div><div><div><div>2</div><div>Long press function switch 3754C-FM mode, short press power 30Hz</div></div><div><div><div>3</div><div>Short press long 1550S3, long press the Bluetooth coupled</div></div><div><div><div>4</div><div>Short press the next song, long press to add the volume</div></div><div><div><div>5</div><div>Short press the last song, long press to reduce the volume</div></div><div><div><div>6</div><div>Alarm clock setting</div></div><div><div><div>7</div><div>Chase Settings</div></div></div></div></div></div></div></div></div></div></div></div>	<div><div>Technical parameter</div><div>Wireless charging power: 10W Bluetooth version: 5.3 Music format: S300 Output power: 30W2 Bluetooth frequency: 2.4GHz ± 40MHz Transmission distance: 10 meters Frequency response range: 50 Hz-20 kHz Signal noise ratio of white: greater than 75 db Built-in 3000mAh battery, 5.7V Charging input: DC5V/500mA Product size: 180*100*50mm Battery Specification: 1800mAh</div><div><div>Operation description of the key function</div><div><div>1</div><div>Start up: long press the start button for two seconds to start up, start up the default heating light</div></div><div><div>2</div><div>The Bluetooth functionality is available for use.</div></div><div><div>3</div><div>The audio supports the use of Bluetooth devices with A2DP function, but default into the Bluetooth mode, Bluetooth indicates blue light shining, accompanied by voice prompt, when the device is waiting for pairing, connections, only in this state, can be paired and connected with the Bluetooth audio.</div></div></div></div>	<div><div>2. Mobile phone connection</div><div>The first step is to open the phone Bluetooth setting switch in the phone settings and choose search device The second step, when the available device displays the S300 character indicating that the phone finds the Bluetooth device, click S300 to enter the pairing mode. After the phone is successfully paired with the device, there will be a voice prompt and display the connected. 3. TF storage function (this function is suitable for Bluetooth mode only) When you have two S300 Bluetooth speakers, by long pressing one of the keys to switch, Bluetooth connection to both effect, the two speakers will automatically become the left and right sound channels to produce stereo sound effect, achieving real wireless stereo. <div><div>Light use</div><div>1) The S300 Bluetooth speaker is equipped with 13 lighting effects 2) Start the default warm light effect of the equipment, and press the light key to adjust the light</div></div><div><div>FM radio use</div><div>At long press to switch to the FM function, connect the charging cable to the product type C interface as a radio antenna, the other end does not need to connect any equipment, through the push button to enter the radio, automatic search and automatically save, the radio station through + - saved station selection</div></div><div><div>TF card/disk function for use</div><div>By pressing the TF card / U disk into the card slot, the corresponding voice prompt will</div></div></div></div>	<div><div>speaker. The product will automatically read the audio file in the card and play it.</div><div>The use, just use the voice to control the music with the speaker + button.</div><div><div>Clock Setting</div><div>Press the clock key to enter the clock mode setting, press/hold the hour/minute + - &gt;</div></div><div><div>Alarm clock setting</div><div>+ - &gt; Press the alarm button to enter the clock mode setting, press / adjust the hour / minute, press the alarm key and then press / (hold) your favorite alarm, there are 4 groups of alarm time, and long press to alarm key to open the alarm clock (the alarm mark appears on the screen after successful setting). When the alarm rings, press key to cancel the alarm. When no one turns off, the alarm will automatically turn off for 1 minute (the alarm will ring normally in the standby state, please cancel the alarm clock without the music). Cancel alarm setting long press the alarm key (the alarm sign disappears on the screen after successful cancellation).</div></div><div><div>White noise mode</div><div>M to switch to white noise mode, press / choose your favorite sleep music + - &gt;</div></div><div><div>Safety instructions:</div><div><div>1</div><div>Do not expose the product into the water or humid areas, such as bathrooms.</div></div><div><div>2</div><div>Please do not let or drop the product heavily to avoid repeat damage.</div></div><div><div>3</div><div>After not in use for a long time, please turn off the power.</div></div><div><div>Warranty and After Sales Service</div><div>If you have any questions during use, please feel free to contact us, we are responsible for every customer.</div></div></div></div>
<div><div>FCC Statement</div><div>This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause unwanted operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not shielded and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or a qualified radio/TV technician for help. Caution: For safety, do not attempt to service (open or replace) any part of this product except as indicated in the instructions. If you are not a qualified technician, please contact a qualified technician for service. Charger is not included and not required to be used. It is recommended for equipment used and for user's safety to use the equipment.</div><div><div>Radiation Exposure Statement</div><div>This device complies with FCC radiation exposure limits and both for an uncontrolled environment. For RF safety the device can be used as portable equipment without restriction for normal range use. The device must operate with a minimum distance of 35 cm between the device and user body.</div></div></div>				