



Bonkers Toy Company, LLC
8787 Complex Drive, Suite 206
San Diego, CA 92123

WARNING:
CHOKING HAZARD - Small parts.
Not for children under 3 years.

Please keep outer packaging and instructions (if included) for future reference, as they may contain important information.

Communicator Watch Instruction:



- Slide the On/Off switch to ON or OFF position to power on or off the Walkie Talkies.
- Please note both Walkie Talkies must be turned on in order to send and receive messages.
- Press and hold the "PTT Button" while speaking into the microphone.
- Please note messages cannot be received while your "PTT Button" is being pressed.

Troubleshooting:

- If one or both Walkie Talkies do not work, please try to replace with new 3 AAA batteries for each unit. (alkaline batteries are recommended)
- The performance of Walkie Talkies will be affected by obstacles such as trees, buildings, metal structures, electric motors, power lines or other signal-disrupting objects. You may have to change your location.

Battery Replacement Instructions:

- Do not mix old and new batteries.
- For best performance use only batteries recommended.
- Ensure batteries are inserted using the correct polarity.
- Different types of batteries or new and used batteries are not to be mixed.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Keep packaging for reference since it contains important information.
- Remove exhausted batteries from unit and dispose of in accordance with battery maker's recommendations.
- Do not attempt to recharge non-rechargeable batteries.
- Rechargeable batteries should only be charged under adult supervision.
- Remove rechargeable batteries from the toy before charging.
- The supply terminals are not to be short circuited.
- Remove batteries if the toy will not be used for an extended period of time.
- Use a screwdriver to open the battery compartment door and replace old batteries.
- Keep new and used batteries away from children. If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.
- The Wheelie bin symbol indicates that the product and the batteries must not be disposed of with other household waste as they may contain elements which can have a harmful effect on the environment and human health. Please use designated collection points or recycling facilities when disposing of the item and the batteries. To help locate your nearest facility see: www.recyclenow.com



Unique identifier

SUPER SPY RYAN'S MYSTERY MISSION CASE

Model Number: 717

FCC compliance statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Information to user

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

Responsible party information

Bonkers Toy Company, LLC
8787 Complex Drive, Suite 206
San Diego, CA 92123
WWW.BONKERSTOYS.COM

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

NB Warning:

Manufacturer's Name: BONKERS TOYS CO. LLC
Sample Description: Ryan's Mystery Mission Case - Communicator Watches
Trade Mark: BONKERS
Model number: 717

Operating Temperature: - 10° C to 40° C

This product is a portable device. To comply with RF exposure requirements, a minimum separation distance of 0mm must be maintained between the user's body and the device, including the antenna. Use only the supplied or an approved antenna.

This device in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. All essential radio test suites have been carried out.

1. CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS

2. The device complies with RF specifications when the device used at 0mm from your body. This restriction will be applied to all Member States of European Union.