


Quick Start Guide

2、Function Indicator




3. Introduction to Desktop

3.1 Windows 10 start screen image:


On the start screen, many applications are shown on the initial page. These applications are displayed in the form of “magnet”. You can easily run any application by simply clicking on it.

You need to log on your Microsoft account before the application program runs.




3.2 Introduction to app Interface


Besides the applications initially shown on the start screen, you can also start other applications in the all application programs section, such as other software applications attached to the PLATINUM AIO PC.



If you want to pin more applications on the start screen, see the operation in the figure below: (1) Click the properties icon, (2) press and hold the application program magnet for about one second and then let go (3) Choose Pin to start




Conversely, if you want to cancel or delete a certain application from the start screen, (1) lightly touch, (2) press and hold the application program magnet for about one second and then let it go and run, and select




4.. Start Menu


Under PC mode, press the Start icon; the Start Menu will display, including Start, Device, Setup, Share, and Search Program.




Usually: File Explorer, Settings, Power, and All apps




Can Sleep/Shut down/Restart the ZAITHBOOK.



Can let you search the files and application programs in the PLATINUM AIO PC.




Can let you set up the Table PC.



Can scan more apps

Action Center




Setup Menu




Action Center is a notification center that also allows quick settings such as Tablet / PC mode, Wi-Fi, Bluetooth etc.

5. Multitasking Operating Interface


Slide the window to the right from the left side of the screen, Let go when the running applications appear. Then you can enter the application, or delete it.



Action Center





Setup Menu



Action Center is a notification center that also allows quick settings such as Tablet / PC mode, Wi-Fi, Bluetooth etc.

6.. Basic Operations

Sleep, Restart and Power Off



FCC Caution:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC RF Radiation Exposure Statement:

1. This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
2. This equipment complies with RF radiation exposure limits set forth for an uncontrolled environment.
3. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.