

Handscape

使用说明书

魔加Mini智能游戏触控板

使用产品前请仔细阅读本使用说明书，并妥善保管

产品参数

- 蓝牙版本:4.2
- 尺寸:87.36*26.2*38.81mm
- 支持操作系统:iOS / Android
- 电池容量:90mAh
- 充电时长:2h
- 工作电流:工作电路<8mA
- 充电电压:+5V/50mA
- 续航时长:20h
- 温度范围:0°C~50°C
- 产品重量:24.5g

此产品废弃时不可随意弃置，须分类收集，专门处理。

产品介绍

1

2

3

4

5

①触控区 ②指示灯 ③开关键 ④按键 ⑤充电口

包装清单:魔加Mini、充电线、产品说明书(含保修卡)、激活器(安卓)

操作指南

● 第一步

先将手机卡入魔加Mini的头部

● 第二步

再拉出底部拉杆扣住屏幕

安装时请先卡后拉,避免损坏手机屏保

不按顺序正确安装可能造成手机屏幕损坏现象

操作指南

● 扫描下方二维码,关注“szHandScape”公众号

● 下载安装M+助手, 查看详细操作步骤

iOS端用户可直接从苹果官方“App Store”搜索“M+助手”下载安装
安卓端用户可从应用商店下载或从公众号底部菜单栏下载安装。(如下图)

苹果端M+下载

安卓端M+下载

产品介绍

M+下载

操作指南

游戏攻略

基本操作与指示灯说明

LED灯光智能提示工作状态

开机	上推开/关机键	蓝灯慢闪, 等待连接状态
连接	连接成功	蓝灯常亮2s, 熄灭
	未连接成功	蓝灯慢闪
关机	下推开/关机键	蓝灯熄灭
电量	电量低于20%时	蓝灯快闪两下, 间隔0.5S后重复循环
	充电时	蓝灯快闪
	充电完成	蓝灯常亮

注:

●开机键与关机键为同一个键

●当蓝灯慢闪一分钟时, 蓝牙未进行连接, 则自动关机

常见问题

1.蓝灯闪烁后熄灭, 但M+助手中显示蓝牙未连接?

(1) 打开手机蓝牙, 查看设备是否已连接。若未连接, 查看是否连接到其他手机;若已连接, 请忽略蓝牙设备(取消蓝牙配对), 手动开关一次蓝牙, 然后重新搜索连接设备

(2) 从后台关闭APP, 重新打开APP

(3) 重启手机, 在APP里搜索蓝牙, 连接设备

2.安卓模式与苹果模式切换问题?

当魔加Mini连接安卓M+助手后会自动切换为安卓模式, 连接苹果M+助手会自动切换为苹果模式, 玩家在自动切换模式后重新连接一下魔加Mini即可

3.无法进行固件更新?

(1) 检查网络信号是否稳定

(2) 检查魔加Mini与手机蓝牙是否断连

(3) 魔加Mini电量不足, 连接电源线后重新打开M+助手进行固件更新

保修卡

出厂日期

检验员

为了您的权益, 请您认真填写, 并妥善保管, 作为维修时的凭证:

经销商信息: 产品型号 经销商名称

联系电话 销售日期

用户信息: 用户姓名 联系电话

通讯地址 email@QQ

保修内容	保修日期

HandScape & Rock 产品售后服务承诺对照表

产品类型	承诺政策	服务方式
游戏触控板	一年保修	客户送修
随机配件不在保修范围		

尊敬的客户:

您好!

承蒙惠顾由汗思凯普科技有限公司研发的产品, 谨致谢意! 为保障您的权益, 在购买本产品后请仔细阅读以下内容:

本保修卡作为本产品保修的唯一凭证。

凭本保修卡和相关销售发票可获得本公司免费保修服务, 如您不能出示销售证明, 该产品的免费保修期将自其生产日期算起。

产品自售出之日起7日内, 发生性能故障, 产品本身及包装完整, 外观无损; 可以选择退货、换同型号同规格产品或免费修理。

产品自售出之日起15日内, 发生性能故障, 产品本身及包装完整, 外观无损; 可以选择换同型号同规格产品或免费修理。

产品在本公司对应保修期内, 可享受免费保修服务(人为因素除外)。

在保修期内修理两次, 仍不能正常使用的产品, 可凭保修记录和证明, 调换同型号同规格产品或按有关规定退货。

因修理者自身原因使修理超过90日的, 由其免费为消费者调换同型号同规格产品, 费用由修理者承担。

返修产品若需要邮寄, 邮寄费用由发送方单向负责。

经销商向您作出的非深圳汗思凯普科技有限公司保证的其他承诺, 概不承担任何责任。

下列情况不属于免费维修范围, 深圳汗思凯普有限公司可提供有偿服务, 敬请注意:

未能提供保修卡和相关销售发票。

产品的清洁和正常情况下的损耗(如外壳、接插件的自然损耗, 老化及磨损)。

未按使用说明书要求安装、使用、维护、保管导致的产品故障或损坏。

擅自涂改、撕毁产品条形码或保修卡。

已经超出保换、保修期限。

产品保修卡上的产品序列号或者型号与产品本身不符。

未经深圳汗思凯普有限公司允许, 擅自改动本身结构、电路, 擅自拆装、改装。

因意外事故、人为滥用使用导致的产品损坏, 例如输出短路、高压输入、超负荷工作、高温、进水、机械破坏、摔坏、产品严重氧化或者生锈等等。

客户发回定途中由于运输、装卸所导致的损坏。

因不可抗力如地震、火灾、水灾、雷击等导致的产品故障或损坏。

其他非产品本身设计、技术、制造、质量等问题而导致的故障或损坏。

该条于发布之日起生效。

保修卡内容的最终解释权, 修改权归深圳汗思凯普有限公司。

联系方式

Handscape

生产商:深圳汗思凯普科技有限公司

地址:深圳市宝安区西乡街道金海路10号华盛商业大厦512

网址:www.sz-hand scape.com

执行标准:GB 4943.1-2011

Handscape

User Manual

MUJA Mini Smart Touchpad

please read this instructions completely and keep it properly.

Specifications

- Bluetooth Version: 4.2
- Dimension: 87.36*26.2*38.81mm
- Supported Operating System: iOS / Android
- battery capacity:90mAh
- Charging Time: 2h
- Working Current: working circuit <8mA
- Charging voltage: +5V/50mA
- Use Time pre Charge:20h
- Temperature Range: 0°F ~ 122 °F
- Weight:24.5g

This product should not be disposed of casually when it is discarded. It needs to be collected separately and treated specially.

Product Introduction

1

2

3

4

5

①Touch area ②Indicator light ③Power button ④Button ⑤charging port

Packing List: MUJA Mini 、 Charging Cable、 Product Manual(Warranty card) 、 Activator (Android)

Steps For Usage

● Step 1

First put the phone into the top of the MUJA Mini

● Step 2

Pull out the bottom rod to grip the screen

Please followd steps above to avoid damage to the screen saver.

Failure to install properly in order may cause damage to the phone film

Steps For Usage

●Download the M+ assistant App.

iOS users can download and install "M+ Assistant" from Apple's official "App Store"

Android users need to open the website "www.handscape.com" go to the download page and download the "M+ Assistant" You can also scan the QR caod below to download the Android version M+ assistant.

● Or scan the QR code below and follow the "szHandScape" public Wechat number and see the detailed steps.

Operation and indicator description

LED smart working indicator status

Power on	Slide up the "ON/OFF" button	The blue indicator flashes slowly and enters the Bluetooth searching state.
Connection	Connected	The blue indicator long light for 2s and then off
	Not connected	The blue indicator flashes slowly.
Power off	Slide down the "ON/OFF" button	The blue indicator is off
Electricity	When the battery is below 20%	The blue indicator flashes twice, repeat the cycle after 0.5s interval
	When charging	The blue indicator flashes quickly
	When charged fully	The blue indicator light is always on

Note:

●The "On" button and the "Off" button are the same button.

●When the blue indicator flashes slowly for one minute, and Bluetooth is not connected it will automatically shut down

Question and Answers

1.The blue light flashes and then goes out, but the M+ assistant shows that Bluetooth is not connected?

●Turn on the phone Bluetooth and check if the device is connected. If not connected, check if it is connected to other mobile phones; if connected, ignore the Bluetooth device (cancel Bluetooth pairing), manually switch Bluetooth once, and then search for connected devices again.

●Close the app from the background and reopen the app.

●Restart the phone, search for Bluetooth in the app, connect the device

2.How to switch Android/iOS mode to use in Android/iOS phone?

When MUJA Mini connects to Android M+ assistant, it will automatically switch to Android mode. When connected to Apple M+ assistant, it will automatically switch to Apple mode. Players can reconnect MUJA Mini after switching modes automatically.

3.Why I cannot upgrade the firmware?

●Check if the network signal is stable

●Check if MUJA Mini and mobile phone Bluetooth are disconnected

●May be MUJA Mini is low on battery. Reconnect the M+ assistant for firmware upgrade. Connecting MUJA mini with power cable.

Warranty Card

Release date

Inspector

For the sake of your rights and interests, please fill in it carefully and make good safekeeping, which is as the voucher for repair.

Dealer's Information:

Product Type Dealer Name

Contact Tel Sales Date

User's Information:

User's Name Contact Tel

Postal Address: email & QQ

Warranty Content	Warranty Date

HandScape & Rock product after-sale service commitment table of comparison

Product Type	Commitment policy	Service mode
GAME Smart Touchpad	one year warranty	customer delivery for repair
Components and spare parts beyond the scope of warranty		

FCC STATEMENT:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Contact

Handscape

ShenZhen HandScape technology Co., Ltd.

512 Huashenghui Commercial Building,

Xixiang Street, Baoan District, Shenzhen

Website: www. handscape.com