


## TOY RC CARS LIGHTS AND SOUNDS


AGES  
6+

### CONTENTS


- 1 x R/C Police Car
- 1 x R/C Robber Car
- 2 x Remote
- 1 x Police Officer
- 1 x Robber




POLICE & REMOTE



ROBBER & REMOTE



POLICE CAR




ROBBER CAR

### FEATURES

- Easy to use controls
- Working lights
- Realistic sounds
- Removable character

### PLAY



- Press the left white button to go forward.
- Press the right white button to make a circle.
- Press any of the center buttons for fun sounds.

**Note:** For best results, operate on a smooth, hard surface.

### BATTERY WARNINGS

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.
- Alkaline batteries are recommended. Use only the specified voltage.
- Insert batteries using the correct polarity. Always use, replace, and recharge (if applicable) batteries under adult supervision.
- Do not attempt to charge non-rechargeable batteries.
- Do not short-circuit the battery supply terminals.
- Do not dispose of batteries in fire: batteries may explode or leak.
- Remove batteries before storing.
- Recycle or dispose of batteries according to federal, state, and local laws.
- Keep these instructions for future reference.

### SAFETY WARNINGS

- Not for children under the age of 3.
- For indoor use only.
- Do not expose to moisture or extreme temperatures.
- Do not use people or animals as obstacles.
- Do not run car into furniture objects or hard surfaces as this will cause damage to both the objects and car.
- Keep fingers, hair and loose clothing away from the tires, gears and motor while car is switched to "ON".
- Remove all batteries when not in use to avoid accidental operation.
- Adult supervision is recommended when operating car.
- Thoroughly inspect products before every use. If the product appears worn, frayed/splintered, cracked, or broken in any manner, discontinue use and discard immediately.



### WARNING:

CHOKING HAZARD-Small Parts.  
Not for Children under 3 years.

Model No.: 1012191

KEEP THIS INSTRUCTION MANUAL AS IT CONTAINS IMPORTANT INFORMATION FOR FUTURE REFERENCE.

Due to continuous product improvements, the pictures on this manual may differ slightly from the actual product.

FAO® and FAO Schwarz® names and logos are trademarks or registered trademarks. Distributed by and © 2020 MerchSource, LLC. Irvine, CA 92618. All rights reserved. © 2020 MerchSource, LLC. Irvine, CA 92618. All rights reserved. For technical support, please call 1-800-374-2744. Printed in China.