

User manual

Power on: Take both earbuds out of the charging case

Power off: Put both earbuds into the charging case

Pairing: Take both earbuds out of the charging case, both earbud's indicator light blinks alternately, then wait for the two earbuds to pair with each other first (IMPORTANT), once paired, only one earbud's indicator light blinks alternately. Now the earbuds are ready to connect to your device.

Play/pause: Press the L/R button once to play or pause music

Previous/Next songs: Long press the L/R button 2 seconds to change the music

Volume Adjust: Double press the L/R button to adjust the volume

Answer incoming call/End call: Press the L/R button once to answer the incoming call or End call.

Reject call: Long press the L/R button 2 seconds to reject the call

Redial: Press the L button three times to redial

Voice assistant: Press the R button three times to control voice assistant Note: your device needs to support this feature.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Rerorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

