

hoco. WATCH



Watch strap replacement: Push the metal lever inward and pull the watch strap upwards at the same time to easily remove the strap.

Y24

Smart Watch

Thank you for choosing our product!

To have a comprehensive understanding and using this device, to know all the features and simple operation methods, please read this manual first.

This device is mainly connected to the mobile phone through BT for adaptation and use. It provides a variety of practical functions and services to facilitate the operation of the mobile phone. It has also developed many functions for human sports and health. This device is not a medical device, and it measures data. The results are for reference only, not as a basis for diagnosis and treatment. The functions on the user manual may be little different with physical, please make the final products as the standard.

The typing errors in this manual and discrepancies will be timely updated with the latest products. The company reserves the right to modify the contents of this manual without any prior notice. Our company reserves the right of final interpretation.

Remark: The product supports waterproof with IP67 level, it is available to wear it while wash hands, swim, in raining, etc.

⚠ Do not use it when have a hot shower/bath or sauna to prevent water vapor. If water enters due to failure to follow the instructions, our company will not provide free warranty.

Y24**Smart Watch**
※ Operation guide

Upper button: Short press to enter the main menu/return to the previous level. Double-click on the menu page to switch menu styles.

Short press to turn the screen on/off, long press to power on/enter/slide shutdown/factory reset/restart.

Swipe function:

Swipe left to enter smart components. The system presets 8 components, with up to 5 that can be added. Click "a" to add or delete components.

Swipe down to enter quick functions.

Swipe up to enter the message page.

Y24**Smart Watch**

Scan the following QR code, download and install the App.

Charging and Active:

Before using the watch for the first time, it needs to be charged and activated; use the equipped magnetic charging dock to attach to the metal contact points on the back of the watch, then connect the other end of the charger to a USB power adapter or computer USB port for charging.


※ How to connect

1. Open the App and set up your profile.
2. Go to the [Device], click [Add a Device].
3. Choose your device on the scanning list, finish.

The MAC address on the "Setting"- "About" page could help you identify your device on the scanning list.

Y24**Smart Watch**
What if I don't get the notice?

1. First, the notification function of the watch is only for synchronizing the notification function of the phone, such as incoming emails, WhatsApp, WeChat reminders. If you haven't received the notification on your phone, the watch will also not receive it. To set up the notification function on your phone, find the corresponding APP, open notifications, and allow all.

2. Due to the non-uniform BT protocols of each mobile phone brand, sometimes the BT connection between the phone and the watch is unstable. You can turn off the BT on your phone and reconnect it, or restore the watch to its factory settings.

3. Delete "RWFit" and download it again. Please note that all permissions should be opened during the installation process, and then the watch should be reconnected.

Warranty

1. If there are any quality issues caused by manufacturing, materials, or design within one year (from the day of purchase), as well as issues with the battery and cable within 6 months, we will provide free warranty. The condition is that the product is used normally and correctly.

2. We do not offer free warranty for faults caused by personal reasons of the user, as listed below:

- 1) Faults caused by unauthorized disassembly or modification of the watch.
- 2) Faults caused by accidental falls during use.
- 3) Any artificial damage or misuse (e.g., water damage, impact from external forces, scratches/damage to peripheral components), as these are beyond the scope of the warranty.
3. When requesting free warranty service, you must provide a warranty card with a purchase seal and the date of purchase.
4. If you encounter any issues during use, please contact the customer service of the shop from which you made the purchase.
5. Please refer to the actual product as the standard.

Main functions**EN**

1. **Dial-up:** Connect to the mobile phone to dial, you can make a call on the watch side.
2. **Call history:** You can synchronise the call history of your mobile phone.
3. **SMS:** Synchronise the messages from your phone.
4. **Music:** In the music control interface, you can control the mobile phone to play/pause the music, the previous/next song, and the volume +/- of the music.
5. **Camera:** The watch can be used as a remote control for the mobile phone camera, after opening the camera on the phone, click on the camera control page of the watch to trigger the shutter of the mobile phone camera.
6. **Weather:** The watch connects with APP and synchronises the data automatically.
7. **Notification:** You can check QQ/WeChat and other timely messages, this function needs to be used after connecting to the mobile phone APP.
8. **Smart alarm clock:** You can set the smart alarm clock of the watch in the client, and you can set up to 5 alarms. The watch will display the alarm icon and vibrate when the time is set.
9. **Sports:** The watch has a variety of sports: such as running, hiking, cycling, badminton, basketball, football, cycling, rope skipping, free training; can be connected to the APP synchronised view of the watch end sports data.
10. **Sleep monitoring:** The watch will automatically record night sleep, to help you better adjust your work schedule and improve the quality of sleep.

11. Heart rate monitoring: The watch will be close to the wrist, the best wearing position in the wrist bone by the arm above, can detect the real-time heart rate value, the normal value of 60-100 beats / minute.

12. Settings: System settings, screen display, incoming call reminder, music mode, animation effect, brightness, lock screen password, USB mode and so on.

13. Find device: Click 'Find Watch' in the app, the watch will start vibrating.

14. Pedometer: You can view the whole day's steps, historical steps, calorie consumption and walking distance. Every night after 24:00, the data of the day will be stored as historical data, and the interface data will be reset to zero.

15. Oxygen: Enter the measurement, please keep your arm in a stationary state, about 20 seconds after the value, off the wrist that is the end of the test.

16. Breathing: Trainer ah, set 1 to 3 minutes of training time / three gears vibration speed.

17. Reminder: Sedentary reminder / water reminder.

18. Charging data transmission: The charger can choose USB mode and charging-only mode. In USB mode, you can quickly import music and photos from the computer to the watch.

19. MP3 player: Can save mp3 format music, sports outing with music.

20. MP4 Video: Support 466x466 resolution video playback on the smart watch.

21. Smart voice recorder: Easy to record with one click, automatically generate a recording list, and the longest recording can be up to 4 hours.

FCC Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.