


User Manual



Model No. :HS005

Please read the instructions carefully before using this product!

Content

Package details	1
Wireless mug warmer instructions	2
Wireless charger instructions	2
Specifications	3
Care and Cleaning	5
Troubleshooting	5
Warranty	6

Package Details

1. Wireless charger
2. Type-c cable
3. User manual

Important Tips

1. Do not disassemble or modify this product by yourself.
2. Keep the charger away from water and other liquids.
3. To clean the charger, make sure that no power is plugged in.
4. Do not put any metal on the charger, such as coins, keys, bank cards.

1

Wireless charger instructions



Put the phone in the middle of the wireless charger and the wireless charging light turned on.

2

Specifications (1)

Name: Wireless Phone Charger

Input: 12V/1.67A

Charging output: 5V/1A, 9V/1.2A, 12V/1.67A

Power: 5W, 7.5W, 10W, 15W

Transmission distance: less than 6mm

Charging efficiency: about 80%

LED indicator	Description
The light is not bright	Standby
The light is bright	Wireless charging is on
Flashing lights	The location is not in place or security is activated

Applicable equipment

1. Built-in wireless charging receiver (Iphone12,Iphonex,iphone8, iphoneX, Samsung S6, etc.)
2. Add an extra receiver (iphone7 etc.)

Note: These receivers must comply with the WPC Qi standard for compatibility.

4

Care and Cleaning

1. Wipe the adapter, data cable, and charging stand with a rag or paper towel. Never enter the water.

Troubleshooting

Problem	Possible causes	What to do
No power	The grid is out of power	Change the power socket
No power	The power cord plug is not in place	Put the power cord plug in place
No power	Adapter or power cord is broken	Replace
No power	Charging block circuit is bad	Contact the dealer
Flashing light	The appliance is not in place	Put the appliance in place

5

Warranty

Thank you for purchasing our product, which has been made to meet high quality standards. The manufacturer's warranty covers the product for a period of 12 months from the date of purchase against manufacturing faults.

Warranty Card

Article: _____

Model: _____

Owner's Name: _____

Address: _____

Tel: _____

Purchase Date: _____

Dealer's Name&Stamp: _____

Address: _____

Tel: _____

Please fill in this table and email it within 10 days from the date of purchase.

Due to continuous product improvement, we reserve the right to change the product specification without prior notice.

FCC Warning	not expressly approved by the	harmful interference in a	television reception, which	into an outlet on a circuit	operation of device a distance
This device complies with part	party responsible for	residential installation. This	can be determined by turning	different from that to which	of 15 cm surrounding the
15 of the FCC Rules. Operation	compliance could void the	equipment generates uses and can	the equipment off and on, the	the receiver is connected.	device and 20 cm above the top
is subject to the following	user's authority to operate	radiate radio frequency energy	user is encouraged to try to	– Consult the dealer or	surface of the device must be
two conditions:(1) This device	the equipment.	and, if not installed and used in	correct the interference by	an experienced radio/TV	respected
may not cause harmful		accordance with the instructions,	one or more of the following	technician for help.	
interference, and (2) this	This equipment has been tested	may cause harmful interference to	measures:		
device must accept any	and found to comply with the	radio communications. However,	– Reorient or relocate		
interference received,	limits for a Class B digital	there is no guarantee that	the receiving antenna.	FCC RF exposure statement:	
including interference that	device, pursuant to part 15 of	interference will not occur in a	– Increase the	The equipment complies with	
may cause undesired operation.	the FCC Rules. These limits	particular installation. If this	separation between the	FCC radiation exposure limits	
	are designed to provide	equipment does cause harmful	equipment and receiver.	set forth for an uncontrolled	
Any Changes or modifications	reasonable protection against	interference to radio or	– Connect the equipment	environment. During the	

