

Thank you for choosing our product, hope the fashionable appearance arhigh quality stereo can enrich your life. Note: Please fully charge it with the charging case before the first use

When charging, the light on the side of the charging case will flicker in a circle, and the light will stay on constantly after being fully charged. Charging when the indicator light flashes.When all four indicators are on, the battery is fully charged.

• • • 100% • • 0 0 50% O O O 25% 0 0 0 0 0 %

Getting Starts

pairing mode.

turn on and into the bluetooth

2 Open the Bluetooth of your phone system, search the Bluetooth name "Mibro Earbuds S1", click the device name and complete the pairing. 3 Take out the earbuds and wear it.

5. Start voice assistant ou will hear a "beep" sound, n the Bluetooth connection state, Ouick triple hit MFB(L or R) to activate th indicating that both ears are voice assistant. connected and music can be played

2.Play / Pause

3.Previous Track /Next Track

4. Volume Increase Or Decrease

The earbuds turn off automatically if:

for 8 seconds to Power ON.

1) You put earbuds back to the charging case.

naven' t connect to any devices within 5 minutes.

For above situation, please press and hold theMFB

You can operate MFB to get certain functions as below:

n the on/off state, long press for 8 seconds to switch off/or

When playing music, Quick triple hit MFB(L) to previous track,

nen playing music, double-click MFB(R or L) to pause, double-click

Ouick triple hit MFB(R) to next track.

Click MFB(R) once to increase the volume.

③ When the earphone battery is low (please charge

6 Answer/Fnd a call

When there's an incoming call,Click MFB once to answer, you can end it by double-click MFB again.

7.Reject An Incoming Call

When there's an incoming call press and hold the MFB for 3 seconds to reject.

Safety Rules

Use original or certified cables.

 Never disassemble or modify your earbuds for any reasons to avoid any damages and dangers.

 Keep the earbuds dry and do not submerge it in water. • Keep out of reach of children, small parts included may be a choking hazard,and avoid using the LED indicator close to the eyes of children or

 Do not use this earbuds during a thunderstorm to avoid irregular f and increased risk of the electric shock.

 Clean with a dry, soft lint-free cloth, do not use harsh chemicals or strong detergents to clean. • The product shall not be exposed to excessive hot or wet.

To avoid hearing damage, do not listen for long time

Do not turn the volume so high that you're unable to

discontinue using in potentially hazardous situations

Do not use earbuds while driving.

FC ( E

|            | Hazardous substances |    |    |        |     |      |  |  |  |
|------------|----------------------|----|----|--------|-----|------|--|--|--|
| Part name  | Pb                   | Hg | Cd | Cr(VI) | PBB | PBDE |  |  |  |
| Earbuds    | 0                    | 0  | 0  | 0      | 0   | 0    |  |  |  |
| Battery    | 0                    | 0  | 0  | 0      | 0   | 0    |  |  |  |
| Earplugs   | 0                    | 0  | 0  | 0      | 0   | 0    |  |  |  |
| Charge Box | 0                    | 0  | 0  | 0      | 0   | 0    |  |  |  |
|            |                      |    |    |        |     |      |  |  |  |

This table is prepared in accordance with GB/T 26572.

O Indicates that the content of the hazardous substance in all homogeneous materials of the component is below the limit specified in GB/T 26572. X It means that the content of the hazardous substance in at least

one homogeneous material of the component exceeds the limit 5. Non compliance with performance faults listed in the performance fault specified in GB/T 26572.

The illustrations of products and accessories in the manual are schematic diagrams for users' reference only. Due to the update and upgrading of this product, the actual product may be different from the schematic diagram. Please take the actual product as the standard!

Performance fault table

3. Unable to charge, the charging indicator is not on.

The earbuds is silent during use.

Non warranty regulations

falling, extrusion and deformation:

Website: www.mibrofit.com

customer service: 400-0908-508

Earbuds 2. During the call, the other party cannot hear the sound.

L. Wear and dirt caused by users' use, such as scratches and color changes; As

well as damage caused by contact with chemical reagents, sharp objects,

2. Unauthorized maintenance, collision, misuse, negligence, abuse, water

3. Tearing, altering labels, forging anti-counterfeiting marks, etc.

If you need after-sales service, please contact Mibro customer service:

ngress, accidents, and failures caused by the use of non-standard accessories

Mibro brand owns the final right to interpret the goods.

O: The earbuds is silent while another is sound. : 1. It may be that both earbuds can not be connected normally. In extreme ses, this kind of situation will occur. Please put the earbuds back into the

harging box, take it out and reconnect it after 8 seconds of reset: . It may be that the silent earbuds is dead. Please put both ebuds back int the charging box and fully charge them before taking them out for reuse.

Q: The earbuds didn't responsive when I get them from the charging case, A: Please check the power of charging case, if there is no power the earbuds

n't turn on automatically or you can manually turn it on (long touch MFB for Q: I have established connection with my smartphonea, but I am not

earing any sounds? A: Please make sure that you have turned up the volume of both devices martphone requires you to set up the Bluetooth earbuds as an audio outpu evices before transimition of sound. Please check the instruction of your

martphone for details. If you are using a music player or other Bluetooth devices, please make sure it supports A2DP stereo music profile.

Q: Why the connection is not stable and cuts out intermittently? A: Please make sure there are no obstacles between the earbuds and your Bluetooth device; please make sure there is no radio or WiFi interference

Q: The sound is not very clear or the caller cannot hear my voice clearly A: Please adjust the volume on your phone and earbuds. Make sure there no source of interference nearby. Stay close to your smartphone check if

Charging Box X1, Earbuds X2, Charging cable X1, User Manual X1

**Earbuds Basic Parameters:** BT Model XPEJ003

BT Version V5.0 BT Range ≤10m/33ft **Battery Capacity** 35mAh (Per Earbuds)

Charging Time About 1.5 hours Play Time About 5 hours Stand By About 60 hours **Battery Type** 

5V === 100mA Lithium ion polymer About 3.8g (Per Earbuds)

Weight Waterproof

**Charge Box Basic Parameters:** 


5V == 500mA Output


5V === 150mA Charging Time About 4 hours Lithium ion polymer Battery Type


About 42g Weight


Zhenshi Information Technology (Shanghai) Co., Ltd.

Room 4015, Building 2, No. 588, Zixing Road, Minhang District, Shanghai











# 功能使用 可使用多功能触摸按键获得以下某种功能:

1、开/关机

开/关机状态下,长按8秒可实现关/开机。

2. 播放/暂停 音乐播放状态下,双击暂停播放,再次双击恢复播放。

播放音乐时,快速三击左耳(L)多功能按键可切换至上一曲; 快速三击右耳(R)多功能按键可切换至下一曲。

单击右耳 (R) 多功能按键音量增加。

5. 启动语音助手

蓝牙连接状态下, 快速三击多功能触摸按键 (L或R), 启动语音助手。

## 6、接听来电/结束通话

当有来电时,单击(L或R)多功能按键可接听来电,再次双击可挂断本电。

7、拒接来电 当有来电时,长按任一耳机3秒

# 安全事项

● 请勿挤压或者碰撞,避免跌落。 ● 请使用原装或经过认证的充电线。

• 请勿自行拆卸/修改耳机,以防损坏或危险。

请保持互机干燥,切勿丢入水中。

● 远离儿童,以避免有可能伤害儿童的意外情况。

● 请勿在雷电天气使用耳机以防意外情况。 ● 请使用干软布擦拭,避免使用刺激性化学物货强力洗涤剂清洗。

● 请勿在严重高温/潮湿/腐蚀性环境下使用本产品。

听力保护

● 请勿长时间在高音量状态下使用,以防损害听力。

请勿将声音调整过大以防听不到周围声音。

● 请勿开车时使用。

|      |   | <b>有害</b> 物质 |      |      |          |       |        |  |  |  |  |
|------|---|--------------|------|------|----------|-------|--------|--|--|--|--|
| 部件名称 |   | 铅            | 汞    | 镉    | 六价铬      | 多溴联苯  | 多溴二苯醚  |  |  |  |  |
|      | ( | (Pb)         | (Hg) | (Cd) | (Cr(VI)) | (PBB) | (PBDE) |  |  |  |  |
| 耳机主体 |   | 0            | 0    | 0    | 0        | 0     | 0      |  |  |  |  |
| 电 池  |   | 0            | 0    | 0    | 0        | 0     | 0      |  |  |  |  |
| 耳 塞  |   | 0            | 0    | 0    | 0        | 0     | 0      |  |  |  |  |
| 充电盒  |   | 0            | 0    | 0    | 0        | 0     | 0      |  |  |  |  |

本表格依据GB/T 26572的规定编制。

表示该有害物质在该部件所有均质材料中的含量均 在GB/T 26572规定的限量要求一下。

X 表示该有害物质至少在该部件的某一均质材料中的 含量超出GB/T 26572规定的限量要求。



名称 性能故障表 1、使用过程中耳机无声; 蓝牙耳机 2、通话过程中,对方听不到声音; 3、无法充电,充电指示灯不亮。

# 非保修条例

1、因用户使用造成的磨损脏污,如划痕、颜色改变的;以及接触化学试剂、尖锐 物体碰伤、掉落挤压变形等人为损坏的情况;

2、未经授权维修、碰撞、误用、疏忽、滥用、讲水、事故,以及使用非本产品标准 配件造成故障的情况:

3、撕毁、涂改标贴、伪造防伪标识等情况。 4、因不可抗力造成的损坏;

5、不符合《性能故障表》所列性能故障的情况;

若有售后服务需求,请联系Mibro客服 网 址: www.mibrofit.com 客服电话: 400-0908-508

说明书中的产品、配件等插图均为示意图,仅供用户参考。由于本产品的更新 升级,产品实物与示意图可能会有差异,请以实物为准!

● 商品最终解释权归Mibro品牌所有!

问:耳机一边有声一边无声。 答:1、可能是双耳无法正常连接,极端情况下才会出现此类情况,请将耳机放回 充电盒内,8秒复位后取出重新连接使用; 2、可能是无声耳机没电,请将双耳放回充电盒内充满电再取出重新使用。

问:耳机从充电盒取出后未自动开机。

答:请首先检查充电盒电量,若充电盒没电,耳机取出时将无法自动开机。 此时可手动开机(手动触摸多功能按键约8秒)

问:连接着蓝牙设备聆听音乐并浏览网页时,网页音频将同时播放。 答:通常状态都会如此,与手机软件有关,可关闭网页音频即可,无需担心。

# 问:已经和手机连接但是没有任何声音。

答:首先请确保耳机和手机声音均已开启日未设置在最低音量。智能手机有时 要求先设置蓝牙耳机为音频输出设备,此操作可查询智能手机使用说明。若使 用音乐播放器或其他蓝牙设备,请确保设备支持A2DP音乐文件。

### 问:打电话时声音不清晰或对方无法听到我的声音。 答: 调大耳机及手机音量,靠近手机并确保周围无强烈干扰信号。

问:为什么蓝牙连接不稳定或间歇性断开。 答:请确保耳机与设备间没有障碍物,请确保周围无强烈WIFI或磁场干扰。

充电盒 x1个、耳机 x2个、充电线 x1条、说明书 x1本

耳机基本参数: 蓝牙名称 XPEJ003 蓝牙版本 V5.0 传输距离 ≤10m/33ft 电池容量 35mAh (每只耳机) 充电时间 约1.5小时 通话时间 约5小时 待机时间 约60小时 **输入参数** 5V == 100mA

电池类型 锂离子聚合物 **耳机重量** 约3.8g(每只耳机)

> 防水级别 IPX5 充电盒基本参数:

> > **输入参数** 5V == 500mA **输出参数** 5V === 150mA **充电时间** 约4小时 电池类型 锂离子聚合物

制造商: 甄十信息科技(上海)有限公司 地 址:上海市闵行区紫星路588号2幢4015室

盒子重量 约42g

mibro

### **FCC Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### **RF** Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.