# 风琴折: 75mm×75mm



OWS Sports Earphone

功能操作说明



### ■ 产品信息

·型 号:S5	·工作时间:9小时
·蓝牙版本: V5.3+EDR	·工作电压:3.3V-4.2V
·耳机电池容量:70mAh	·充电时长:1小时
·充电仓电池容量:500mAh	·喇叭阻抗:Φ14.2mm 16Ω
·电源输入:5V	·频率响应:20-20KHZ
·待机时间: ≤190小时	·传输距离:10米以上

### ■ 包装明细





·蓝牙耳机





### ■ 蓝牙配对

步骤一:将耳机从充电仓取出。 步骤二:将手机蓝牙打开。 步骤三: 找到耳机蓝牙名S5。

步骤四:点击连接,连接成功后语音提醒。

注意: 如果已有配对设备信息, 耳机会在2-4S内自动回连设备; 若未连接到设备, 耳机待机3分钟后自动关机。

### ■ 开机

- (1) 打开充电仓上盖并取出耳机,此时耳机自动开机匹配,等待连接手机。
- (2) 耳机不在充电仓里并且耳机是关机的状态,长按任一侧3秒开机。

## ■ 关机

- (1) 将左右耳机放入充电仓, 关上充电仓上盖, 耳机会自动关机并充电。
- (2) 在耳机连接状态下、长按仟一侧5秒关机。

### ■耳机操作说明

( 待机状态	耳机手动开机	任一侧长按3秒
1寸/1/1人/公	耳机手动关机	任一侧长按5秒
播放状态	播放/暂停	任一侧单击
	上一曲	双击左耳
	下一曲	双击右耳
	音量+	三击左耳
	音量 -	三击右耳
通话状态	接听/挂断	任一侧单击
	拒接电话	长按MFB
语音助手	召唤语音助手	长按MFB键2S

### ■ LED灯显示

开机	红白灯交替闪
关机	红灯闪3次
低电状态	红灯闪烁 提示音提示
充电状态	数显数字跳动
充满电状态	显示100%充满

### ■使用注意事项

- ① 耳机需存放在干燥通风的环境下,避免与油、水汽、蒸触. 以免影响产品性能。
- ②避免使用刺激的,有机溶剂或含有这些成份的物品清洁。
- ③ 耳机需按正确规范要求使用,注意使用环境对耳机的影响, 为保证连接顺畅,建议手机和耳机之间的距离在10米范围内。
- ④ 如耳机有连接不上或通讯不畅等其他问题,请勿私自拆卸耳 机本体及其配件否则不予保修。
- 5 给耳机充电,请选用标配的车载充电器或本公司指定的符合 要求的充电器。
- 6 为保证您正常使用耳机,请确保耳机的电量充足。

<u>S5</u>

OWS Sports Earphone

Function instructions

# ■ Diagrammatic sketch



### ■ Specifications

·Model: S5	·Working time: 9 hours
·Bluetooth version: V5.3+EDR	·Working voltage: 3.3V-4.2V
·Earbud battery: 70mAh	·Charging time: 1 hours
·Charging case battery: 500mAh	-Speaker impedance : Φ14.2mm 16Ω
·Power input: 5V	·Frequency response : 20-20KHZ
·Standby time : $\leq$ 190 days	·Transmission distance: over 10 meters

# ■ Package list



·Charging box







·User manual

### ■ Bluetooth pairing

Step 1: Take the earphones out of the charging case.

Step 2: Turn on bluetooth.

Step 3: Find the earphone bluetooth name S5.

Step 4: Click Connect, voice reminder after successful connection.

Note:If there is pairing device information,the earphone will automatically connect to the device within 2-4s. If the earphone is not connected to the device, The earphone automatically turns off after 3 minutes of standby.

### ■ Turn on

(1) Open the top cover of the charging compartment and take out the earphone. At this time, the earphone automatically starts and matches, waiting for the connection of the mobile phone.

(2) The earphone is not in the charging compartment and the earphone is off. Long press either side for 3 seconds to turn on the earphone.

### ■ Turn off

(1) Put the left and right earphones into the charging case, close the top cover of the charging case, and the earphones will automatically shut down and charge.

(2) When the earphone is connected, press and hold either side for 5 seconds to power off.

## ■ Operation of earphone

Standby State	Turn on manually	Tap and hold for 3 seconds
Staridby State	Turn off manually	Tap and hold for 5 seconds
Playing State	Play/Pause	Single tap
	Previous track	Double click left
	Next track	Double click right
	Volume+	Triple tap left
	Volume -	Triple tap right
Call State	Answer/End a phone call	Single tap
	Reject a phone call	Long press MFB
In Siri	Activate voice assistant	Long press MFB buttun for 2s

# ■ LED light display

Turn On	The red and white lights blink alternately
Turn Off	Red light blinks three times
Low power status	Red light flash, with a voice prompt
Charging status	Digital numbers blink/counting down
Full charge	Display 100%

### ■ Precautions for use

- ① Headphones should be stored in a dry and ventilated environment to avoid contact with oil, water vapor and steam. In order to avoid affecting product performance.
- 2 Avoid cleaning with irritating, organic solvents or materials containing these ingredients.
- 3 The headset should be used according to the correct specification requirements, and pay attention to the influence of the using environment on the headset.
- To ensure smooth connection, it is recommended that the distance between the mobile phone and the earphone be within 10 meters.
- 4 If the earphone fails to connect or communicate properly, do not remove the earphone without permission

The machine body and its accessories are not guaranteed otherwise.

- (5) To charge the earphone, please use the standard car charger or the one specified by our company Chargers required.
- 6 To ensure normal use of the earphone, ensure that the power of the earphone is sufficient.



#### **FCC Warning**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.