

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### FCC RF Exposure Warning Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment can be used in portable exposure conditions.


# Wireless Helmet Headset



**C1**

# User Manual

## Product Overview




## Important Notes

Before installing the earphones, connect to a mobile phone to test the volume level. If the volume differs significantly after installation, adjust the speaker position inside the helmet.

Charge the device promptly upon hearing the low battery alert.

# •Phone Functions



→  
Switch to Receive Mode

Switch to receive mode

Auto Mode (Wait 10 Seconds  
to Automatically Answer)



Double Click Next Track Button to Switch  
Between Manual and Auto Answer



→  
(Incoming Call)  
(After 10 Seconds)



Auto

Auto Answer



→  
Incoming Call  
Manual Answer



Answer Call



→  
(Incoming Call)



Press and Hold  
for 2 Seconds

Decline Call



→  
"Short Press"  
During Call



End Call



→  
Redial Last Number



Double Click



→  
Short Press



During Ongoing  
Call


Cancel Current Call

## •Power On/Off

---

### ► Turn On/Off Power

Press and Hold for 3 Seconds  
to Turn On the Device




(Beep Prompt)



LED Lights Up

## •Pairing

---



(Beep Prompt)

Bluetooth Not Connected




Bluetooth Not Connected, LED Flashing

## •Voice Assistant

---

Triple Click



Wake Voice Assistant

# •Music Functions

## ► Pause/Play Music



(Music Stopped)

Short Press



(Music Playing)



Pause



(Music Stopped)

Volume Down Button



(Music Playing)



Long press to decrease volume



(Music Stopped)

Volume Up Button




(Music Playing)




Long press to increase volume

# •Charging Mode



Red LED stays on during charging



Blue LED stays on when fully charged


(Device automatically powers off when charging cable is connected while turned on)

## •Accessories List


---



C1\*1




Earphone and Microphone\*1



Microphone Velcro\*2



Speaker Velcro\*4



Charging Cable\*1



User Manual\*1

## •Note

---



For optimal call quality, ensure the < ► > symbol aligns with the mouth direction after installing the rigid microphone, otherwise noise may occur.