




802.11ax-HE80 - Ant 0 (Nss = 1)

Channel 39 (6145MHz)




Channel 55 (6225MHz)




Channel 87 (6385MHz)




Channel 103 (6465MHz)




Channel 119 (6545MHz)



Channel 135 (6625MHz)






802.11ax-HE160 - Ant 0 (Nss = 1)


Channel 47 (6185MHz)




Channel 79 (6345MHz)



Channel 111 (6505MHz)



Channel 143 (6665MHz)



Channel 175 (6825MHz)





Channel 207 (6985MHz)



802.11ax-HE20 - Ant 1 (Nss = 1)



Channel 33 (6115MHz)


Channel 61 (6255MHz)




Channel 93 (6415MHz)

Channel 97 (6435MHz)









802.11ax-HE40 - Ant 1 (Nss = 1)


Channel 35 (6125MHz)




Channel 59 (6245MHz)




Channel 91 (6405MHz)




Channel 99 (6445MHz)




Channel 107 (6485MHz)



Channel 115 (6525MHz)








802.11ax-HE80 - Ant 1 (Nss = 1)

Channel 39 (6145MHz)




Channel 55 (6225MHz)




Channel 87 (6385MHz)



Channel 103 (6465MHz)



Channel 119 (6545MHz)



Channel 135 (6625MHz)

